

Digital Control

Assoc. Prof. Dr.Ing.

Mohammed Ahmed


mnahmed@eng.zu.edu.eg

goo.gl/GHZZio

Lecture 10: Discrete Controller Design

(PID Controller)

06.12.2016





Copyright o2016 Dr.Ing. Mohammed Nour Abdelgwad Ahmed as part of the course work and learning material. All Rights Reserved.

Where otherwise noted, this work is licensed under a Creative Commons Attribution-NonCommercial-ShareAlike 4.0 International License.

Zagazig University | Faculty of Engineering | Computer and Systems Engineering Department

Lecture: 10

Discrete Controller Design (PID Controller)

PID Controller


PID controller

- The proportional-integral-derivative (PID), also called three-term, is the most widely used controller in process industry.
- The output u(t) of the PID controller is the sum of three terms:

$$u(t) = K_p \left(e(t) + rac{1}{T_i} \int\limits_0^t e(au) d au + T_d rac{de(t)}{dt}
ight)$$

- where
 - e(t) = r(t) y(t), is the error (controller input)
 - ightharpoonup r(t) is the reference input
 - \triangleright y(t) is the plant output.
 - $ightharpoonup T_i$ is known as the integral time.
 - $ightharpoonup T_d$ is known as the derivative time.

PID controller



https://commons.wikimedia.org/wiki/File:PID_Compensation_Animated.gif

PID controller actions

- **Proportional**: the error is multiplied by a gain. The higher is the gain, the faster is the response. However, very high gain may cause instability. Note that system with only P-control has a steady-state error (Offset).
- **Integral**: is used to remove steady-state error. However, integral action increases the overshoot and reduces system stability.
- **Derivative**: is used to improve the transient response by reducing overshoot.

PID controller

Transfer Function

• By taking Laplace transform of the equation:

$$u(t) = K_p \left(e(t) + rac{1}{T_i} \int\limits_0^t e(au) d au + T_d rac{de(t)}{dt}
ight)$$

• we obtain the transfer function of the continuous-time PID controller:

$$\frac{U(s)}{E(s)} = K_p \left(1 + \frac{1}{T_i s} + T_d s \right)$$

Discrete PID Controller

 To implement PID control using a digital computer we convert the following continuous-time equation into a discrete form:

$$u(t) = K_{p}\left(e(t) + rac{1}{T_{i}}\int\limits_{0}^{t}e(au)d au + T_{d}rac{de(t)}{dt}
ight)$$

 To do this, a simple method is to approximate integral and derivative using finite differences:

$$\int\limits_0^t e(au)d au pprox \sum_{k=1}^n T\,e(kT), \ rac{de(t)}{dt} pprox rac{e(nT)-e(nT-T)}{T}$$

Discrete PID controller

position form

• Using finite difference approximations, we can write:

$$u(nT) = K_p \left[e(nT) + \frac{1}{T_i} \sum_{k=1}^n Te(kT) + T_d \frac{e(nT) - e(nT - T)}{T} \right]$$

Using subscripts instead of arguments, then

$$u_n = K_p \left[e_n + \frac{1}{T_i} \sum_{k=1}^n T e_k + T_d \frac{e_n - e_{n-1}}{T} \right]$$

• This is called the **position form** of discrete PID controller. The drawback of this form is that: to calculate the controller output un we need error values e_k , $k = 1 \rightarrow n$.

Discrete PID controller

velocity form

• From the position form:

$$u_n = K_p \left[e_n + \frac{1}{T_i} \sum_{k=1}^n T e_k + T_d \frac{e_n - e_{n-1}}{T} \right]$$

We can write

$$u_{n-1} = K_p \left[e_{n-1} + \frac{1}{T_i} \sum_{k=1}^{n-1} T e_k + T_d \frac{e_{n-1} - e_{n-2}}{T} \right]$$

• Subtracting these two equations, we obtain:

$$u_n = u_{n-1} + K_p[e_n - e_{n-1}] + \frac{K_pT}{T_i}e_n + \frac{K_pT_d}{T}[e_n - 2e_{n-1} + e_{n-2}]$$

• Here the current control signal un is an update of the previous value u_{n-1} . This is called the **velocity form**.

Transfer function of Discrete PID controller

• The velocity form of discrete PID controller is:

$$u_{n} = u_{n-1} + K_{p}[e_{n} - e_{n-1}] + \frac{K_{p}T}{T_{i}}e_{n} + \frac{K_{p}T_{d}}{T}[e_{n} - 2e_{n-1} + e_{n-2}],$$

$$u_{n} - u_{n-1} = \underbrace{K_{p}\left(1 + \frac{T}{T_{i}} + \frac{T_{d}}{T}\right)}_{K_{0}}e_{n} + \underbrace{K_{p}\left(-1 - 2\frac{T_{d}}{T}\right)}_{K_{1}}e_{n-1} + \underbrace{K_{p}\left(\frac{T_{d}}{T}\right)}_{K_{2}}e_{n-2}.$$

• Taking z-transform of both sides, we get the transfer function of discrete PID controller:

$$\frac{U(z)}{E(z)} = \frac{K_0 + K_1 z^{-1} + K_2 z^{-2}}{1 - z^{-1}}$$

Transfer function of Discrete PID controller

• Transfer function of discrete PID controller is:

$$\frac{U(z)}{E(z)} = \frac{K_0 + K_1 z^{-1} + K_2 z^{-2}}{1 - z^{-1}}$$

where:

$$k_0 = K_p \left(1 + \frac{T}{T_i} + \frac{T_d}{T} \right)$$

$$k_1 = -K_p \left(1 + 2 \frac{T_d}{T} \right)$$

$$k_2 = K_p \left(\frac{T_d}{T} \right)$$

Thanks for your attention.

Questions?

Assoc. Prof. Dr.Ing.

Mohammed Ahmed
mnahmed@eng.zu.edu.eg
goo.gl/GHZZio





Zagazig University | Faculty of Engineering | Computer and Systems Engineering Department



Copyright ©2016 Dr.Ing. Mohammed Nour Abdelgwad Ahmed as part of the course work and learning material. All Rights Reserved. Where otherwise noted, this work is licensed under a Creative Commons Attribution-NonCommercial-ShareAlike 4.0 International License.