
POS360 SYSTEMS MADE SIMPLE


360 Pro Quick-start guide

MEET YOUR KEYBOARD




1. Log in and refresh
2. Quantity and fixes
3. Numbers
4. Departments
5. Lotto and store services
6. Cash hot keys
7. Pay: CASH, CARD, EBT
8. Home
9. Price and inventory tools

Log in




Open the drawer, no sale



RING UP AND PAY

Amount, then key


Type the dollar amount, then press the key. For cents, use the . key.



TAX NON-TAX	Sale with no barcode
SODA TOBACCO LIQUOR BEER	Sale by department
CASH	Customer pays cash. Press it twice for exact change.
$5 $10 $20 $50 $100	Cash hot keys. No amount needed.
SCRATCHER	Sell scratchers
LOTTO PAYOUT	Pay a winner. Shows as ($100.00).
MONEY ORDER	Money order. The fee adds itself.
CASH BACK	Cash back. Then ENTER for no fee.

Something not right?

Go home, then refresh.
We're happy to help.



STILL STUCK? CALL US

805.496.1800


POS360 SYSTEMS MADE SIMPLE

360 Pro Quick-start guide

1 Scan an item


It adds to the invoice on its own.

No keys: just scan




2 Change the quantity

Shortcut: 2X or 3X




3 Remove an item

CLEAR deletes the whole invoice




4 Change a price

For this sale only.




5 Take a card

NO SVC skips the service fee. Swipe after 3 tries.




6 Take EBT

Items not marked FS need another payment.




7 Split cash and card

Cash first. The card pays the rest.




8 Hold a sale for later




9 Reprint a receipt

Older sale: RECALL INVOICE, Select, PRINT



10 Refund or void a sale

A refund is the same steps.



11 Settle credit cards

Happens on its own every night.

No keys: on screen



STILL STUCK? CALL US

805.496.1800