## **OPC 40084-11 Instance for umati Demonstrator**

→ 2:MachineryOperationMode

CurrentState

Id

The namespace for the instances is manufacturer specific, e.g. http://samplemanufacturer.com/umati sample corrugator instance/

Table 2 shows the complete structure of the instance needed for the umati demonstrator. The demonstrator requires, that all mandatory elements of the *Corrugator\_InterfaceType* are existent, even if there are not displayed in the dashboard. If the value of a variable a not displayed, is can be filled with a static dummy value (e.g. empty string). All displayed values are highlighted in **light-blue**.

Important: Version 2.0 of OPC 40084-11 must be used which defines, that the instance of the *Corrugator\_InterfaceType* is located under the Machines folder defined by OPC UA for machinery and that the *MachineIdentificationType* (also defined in OPC UA for Machinery) is used for the identification.

NamespaceURI Namespace Index Example http://opcfoundation.org/UA/ 0:NodeVersion http://opcfoundation.org/UA/DI/ 2 2:DeviceClass http://opcfoundation.org/UA/PlasticsRubber/GeneralTypes/ 3 3:UsersType http://opcfoundation.org/UA/PlasticsRubber/Extrusion\_v2/GeneralTypes/ 4 4:ExtrusionDeviceType http://opcfoundation.org/UA/PlasticsRubber/Extrusion\_v2/HaulOff/ 5 5:ClampClosed http://opcfoundation.org/UA/Machinery/ 6 6:MachineIdentificationType

Table 1 - Namespaces used in this document

The default namespace OPC 40084-11 is not listed since all *BrowseNames* without prefix use this default namespace.

BrowseName	Туре	Example Value	Remarks
Objects			
→ Machines			
→ Corrugator_ <manufacturer>_<serialnumber></serialnumber></manufacturer>	Corrugator_InterfaceType		
<ul><li>4:IsPresent</li></ul>	0:Boolean	true	1)
<ul><li>4:LineId</li></ul>	0:String	"Line 1"	1)
<ul> <li>3:SupportedLogbookEvents</li> </ul>	3:LogbookEventsEnumeration[]	empty array / NULL	1)
→ 2:Identification	6:MachineIdentificationType		
<ul> <li>2:ProductInstanceUri</li> </ul>		"https://samplemanufacturer.com/ Corrugator1234"	1)
<ul><li>2:Manufacturer</li></ul>	0:LocalizedText	"Sample Manufacturer"	
<ul><li>2:Model</li></ul>	0:LocalizedText	"Corrugator 3000"	2)
<ul><li>2:SerialNumber</li></ul>	0:String	"1234"	
<ul><li>2:DeviceClass</li></ul>	0:String	"Corrugator"	
<ul><li>5:Location</li></ul>	0:String	"K 14 F42/N 51.260407 E 6.744588"	2), 3)
<ul><li>ControllerName</li></ul>	0:String	"My Controller"	1)
→ 6:MachineryBuildingBlocks	0:FolderType		
→ 2:Identification	6:MachineIdentificationType	Reference to the instance Identification above	
→ 2:MachineryItemState	4:ExtrusionMachineryItemState_ StateMachineType		
<ul><li>CurrentState</li></ul>	0:LocalizedText	"Executing"	
– Id	0:Nodeld	ns=4;i=5092	1)
→ 4:ExtrusionExecutingSubState	4:ExtrusionExecutingSubState_ StateMachineType		1)
<ul><li>CurrentState</li></ul>	0:LocalizedText	"ControlledRun"	1)
- Id	0:Nodeld	ns=4;i=5070	1)
		1	

6:MachineryOperationMode StateMachineType

"Processing"

ns=6;i=5026

0:LocalizedText

0:Nodeld

Table 2 - Sample instance of OPC 40084-11

BrowseName	Туре	Example Value	Remarks
<ul><li>5:ClampClosed</li></ul>	0:Boolean	true	
<ul><li>ExtruderEnabled</li></ul>	0:Boolean	true	1)
<ul><li>MouldId</li></ul>	0:String	"Mould 42"	1)
→ 5:Drives	3:DrivesType		
<ul><li>0:NodeVersion</li></ul>	0:String	"1"	1)
	3:DriveType		
<ul><li>Position</li></ul>	0:String	"Main Drive"	
<ul> <li>3:ActualValue</li> </ul>	0:AnalogItemType → 0:Double	40.5	
- EURange	0:Range	Low: 0	
		High: 80	
<ul> <li>EngineeringUnits</li> </ul>	0:EUInformation	namespaceUri: "http://www.opcfoundation.org/UA/ units/un/cefact" unitId: 12888	
		displayName: "m/min"	
		description: "metre per minute"	
	15:		
→ 5:TemperatureZones	4:ExtrusionTemperature ZonesType		
<ul><li>0:NodeVersion</li></ul>	0:String	"1"	1)
→ TemperatureZone_1	4:ExtrusionTemperature ZoneType		
- Id	0:String	"Mould Temperature"	
<ul><li>IsPresent</li></ul>	0:Boolean	true	1)
<ul><li>ControlMode</li></ul>	3:ControlModeEnumeration	= (=AUTOMATIC)	1)
<ul><li>3:ActualValue</li></ul>	0:AnalogItemType → 0:Double	37.5	
<ul> <li>EURange</li> </ul>	0:Range	Low: 0	
		High: 100	
<ul> <li>EngineeringUnits</li> </ul>	0:EUInformation	namespaceUri: "http://www.opcfoundation.org/UA/ units/un/cefact" unitId: 4408652 displayName: "°C"	
		description: "degree Celsius"	'

- 1) This variable is mandatory in the model but will not be displayed in the demonstrator
- 2) Not mandatory in used specifications but for this model and will be displayed in the demonstrator
- 3) See <a href="https://showcase.umati.org/Dashboard.html#location-of-fair-machine-and-software-icons-on-the-dashboard">https://showcase.umati.org/Dashboard.html#location-of-fair-machine-and-software-icons-on-the-dashboard</a> for rules for filling the location.
- 4) Container object is mandatory in the model, but no instances inside (besides Variable *NodeVersion*) needed.