


GMS 10.8 Tutorial

RT3D – BTEX Degradation with Multiple Electron Acceptors



Objectives

This tutorial shows how to use GMS and RT3D to model BTEX degradation using a multiple electron acceptor model.

Prerequisite Tutorials

 RT3D – Instantaneous Aerobic Degradation

Required Components

- GMS Core
- MODFLOW Interface
- RT3D

Time

20–35 minutes



1 Introduction2			
1.1	Description of the Reaction Model	2	
1.2	Description of Problem		
1.3	Getting Started		
2 Imr	porting the MODFLOW Model	6	
3 Building the TransportModel			
4 Init	ializing the Model	6	
5 The BTN Package6			
5.1	Starting Concentrations		
5.2	Porosity		
5.3	Stress Periods		
5.4	Output Options	7	
6 Assigning Concentrations to the Left Boundary8			
7 The Advection Package8			
8 The Dispersion Package8			
9 The Source/Sink Mixing Package9			
10 The Chemical Reaction Package9			
11 Running RT3D			
12 Viewing the Results			
12.1 Overlaying Contours			
	ner Post-Processing Options		
	nclusion		
17 00	101031011	12	

1 Introduction

This tutorial illustrates the steps involved in using GMS and RT3D to model BTEX degradation using a multiple electron acceptor model. Since the flow model used in this simulation is similar to the flow model used in the "RT3D – Instantaneous Aerobic Degradation" tutorial, the steps involved in building the flow model will not be described in this tutorial. A predefined version of the flow model will be used.

This tutorial will begin with importing a MODFLOW model followed by defining RT3D inputs and boundary conditions, running RT3D, and viewing results by overlaying the contours.

1.1 Description of the Reaction Model

The reaction that will be simulated is biodegradation of BTEX compounds via different aerobic/anaerobic pathways using multiple electron acceptors. Five different processes considered in this model are Aerobic Respiration (AR), Denitrification (DN), Iron (III) Reduction (IR), Sulfate Reduction (SR), and Methanogenesis (MG). All of these biochemical reactions are assumed to occur in the aqueous phase, mediated by the existing subsurface microbes, and are expected to happen in the following sequence:

$$AR \rightarrow DN \rightarrow IR \rightarrow SR \rightarrow MG$$
(1)

The following reaction kinetic framework is used to model the degradation rate of hydrocarbon via different electron acceptor pathways:

$$r_{HC,O_2} = -k_{HC,O_2}[HC] \frac{[O_2]}{K_{O_2} + [O_2]}$$
(2)

$$r_{\text{HC},\text{NO}_3} = -k_{\text{HC},\text{NO}_3} [\text{HC}] \frac{\left[\text{NO}_3\right]}{K_{\text{NO}_3} + \left[\text{NO}_3\right]} \bullet \frac{K_{\text{i},\text{O}_2}}{K_{\text{i},\text{O}_2} + \left[\text{O}_2\right]} \dots (3)$$

Where:

- r_{HC.O2} is the rate at which hydrocarbon is destroyed by utilizing oxygen,
- r_{HC.NO3} is the rate at which hydrocarbon is destroyed by utilizing Nitrate,
- r_{HC,Fe2+} is the rate at which hydrocarbon is destroyed by producing Fe²⁺ (or utilizing Fe³⁺),
- r_{HC,SO4} is the rate at which hydrocarbon is destroyed by utilizing sulfate,
- r_{HC,CH4} is the rate at which hydrocarbon is destroyed by producing methane,
- [O₂] is the oxygen concentration [ML⁻³],
- k_{O2} is the first-order rate constant [T⁻¹],
- Ko₂ is the Monod half saturation constant [ML⁻³] (by setting all the half-saturation constants to a small value, zero-order dependency can be simulated with respect to the electron donor and hence a first-order degradation model with respect to hydrocarbon; the default values simulate this option),
- and K_{i,o2} is the oxygen inhibition constant [ML⁻³] (by setting all inhibition constants to a small value, reactions can be forced to occur in a sequential fashion; the default values simulate this process).

Similar nomenclature is used to identify other Monod constants and inhibition coefficients.

Since the concentrations of Fe^{3+} and CO_2 are not readily measurable under normal field conditions, these terms were replaced with the "assimilative capacity" for iron reduction and methanogenesis, defined as the following:

$$[Fe^{3+}] = [Fe^{2+}_{max}] - [Fe^{2+}]$$
(7)

$$[MC]=[CO_2]=[CH_4_{max}]-[CH_4]...$$
 (8)

where $[Fe^{2+}_{max}]$ and $[CH_{4\,max}]$ are the maximum possible aquifer levels of these species that represent the aquifer's maximum capacity for iron reduction and methanogenesis. Note: the concentration of CO_2 used here is the CO_2 evolved while the hydrocarbon is

destroyed via methanogenesis, which may be thought of as the "Methanogenic Capacity" (MC) of the aquifer. Using these relations, iron (III) reduction and methanogenesis processes may be related back to measurable Fe²⁺ and CH₄ concentration levels.

The total rate of hydrocarbon destruction, via all the above described processes, is the sum of each of the individual rates and is given as the following:

$$\frac{d[HC]}{dt} = r_{HC,O_2} + r_{HC,NO_3} + r_{HC,Fe^{2+}} + r_{HC,SO_4} + r_{HC,CH_4}$$
 (9)

Rates of electron acceptor utilization are given as the corresponding rate of hydrocarbon destruction multiplied by the appropriate yield coefficient (Y):

$$\frac{d[O_2]}{dt} = Y_{O_2/HC} r_{HC,O_2}$$
 (10)

$$\frac{d[NO_3]}{dt} = Y_{NO_3/HC} r_{HC,NO_3}$$
 (11)

$$\frac{d[Fe^{2+}]}{dt} = -Y_{Fe^{2+}/HC} r_{HC,Fe^{2+}}$$
 (12)

$$\frac{d[SO_4]}{dt} = Y_{SO_4/HC} r_{HC,SO_4}$$
 (13)

$$\frac{d[CH_4]}{dt} = -Y_{CH_4/HC}r_{HC,CH_4}$$
 (14)

The yield values (the mass ratio of electron acceptors removed or metabolic byproducts produced to total BTEX degraded) are as follows:

- $Y_{02/HC} = 3.14$,
- $Y_{NO3/HC} = 4.9$
- $Y_{\text{Fe}2+/\text{HC}} = 21.8$
- $Y_{SO4/HC} = 4.7$
- $Y_{CH4/HC} = 0.78$

Typical values of all inhibition coefficients, except for K_{iFe}^{3+} , should be in the range of 1.0 to 0.01 mg/L. K_{iFe}^{3+} should always be set around 40% to 80% of the max Fe^{2+} value. Monod half-saturation constants should be in the range of 1.0 to 0.1 mg/L.

As pointed out in Lu et al., it is important to note that this model is based on several assumptions. The model should be used with caution only at sites where these assumptions are valid.

In summary, the key assumptions used in the model are:

 The fuel chemical species benzene, toluene, ethylbenzene, and xylene are assumed to degrade at similar rates and, hence, are combined and modeled as a single electron donor species BTEX;

-

¹ Lu, G., Clement, T.P., Zheng, C., and Wiedemeier, T.H. (1999). Natural attenuation of BTEX compounds: Model development and field-scale application. *Ground Water*. 37(5):707–717.

- 2. Production of Fe²⁺ and methane are restricted at a node to a "maximum-observed level"; however, the model assumes that an infinite supply of electron acceptors will be available for iron-reduction and methanogenic reactions;
- More complex processes are not considered; these include processes such as the rate-limited interaction of bioavailable, solid-phase Fe³⁺ and aqueous-phase Fe²⁺, interaction of oxygen and Fe²⁺, and/or variations in the spatial pattern of methanogenic activity and CO₂ availability;
- 4. Growth and decay of various microbial populations and their interactions with contaminants and aquifer solids are assumed to be negligible; and
- 5. All BTEX decay reactions are approximated as first-order reactions, and, hence, the model ignores the Monod limitation due to the electron donor (BTEX) availability.

Fortunately, these assumptions are expected to be reasonable approximations for most field sites. However, there will always be some exceptions.

1.2 Description of Problem

The problem in this tutorial is the same as the problem described in "RT3D – Instantaneous Aerobic Degradation" tutorial. The site is a 510 m x 310 m section of a confined aquifer with a flow gradient from left to right. An underground storage tank is leaking fuel hydrocarbon contaminants at 2 m³/day at the location shown. Concentration of BTEX is 1000 mg/L. Initial levels of hydrocarbon, oxygen, nitrate, Fe²+, sulfate, and methane in the aquifer are assumed to be as follows: 0.0, 4.0, 20.0, 0.0, 10.0, and 0.0 mg/L, respectively. The reaction constants to be used are as follows:

Constant	Value
Max Fe ²⁺	25.0 mg/L
Max Methane	30.0 mg/L
$k_{\text{HC,O2}}$	0.1 day ⁻¹
k _{HC,No3}	0.008 day ⁻¹
k _{HC,Fe3+}	0.0005 day ⁻¹
k _{HC,SO4}	0.00025 day ⁻¹
k _{HC,CH4}	0.0001 day ⁻¹

Values of all inhibition coefficients, except K_{iFe}^{3+} , are assumed to be 0.01 mg/L and all Monod constants are assumed to 0.5 mg/L. The value of K_{iFe}^{3+} is set at 12.5 mg/L (50% of max Fe). The yield values are the same as those described in the previous section.

The first part of the problem will be to import a previously computed MODFLOW flow model of the site. Using this flow field, a reactive transport model will then be defined using RT3D.

1.3 Getting Started

Do the following to get started:

- 1. If GMS is not running, launch GMS.
- 2. If GMS is already running, select the *File* | **New** command to ensure the program settings are restored to the default state.

2 Importing the MODFLOW Model

The first part of the simulation is to import the MODFLOW flow model. A steady state flow model has been previously computed and is supplied with the tutorial files.

- 1. Select the File | Open... command to bring up the Open dialog.
- 2. Locate the directory entitled flowmod\flowmod.
- 3. Select the file entitled "flowmod.gpr".
- 4. Click **Open** to import the project file.




Figure 1 The MODFLOW flow model

3 Building the TransportModel

Now that the flow model is imported, the next step is to set up the RT3D simulation. For this part of the simulation, select the reaction, define the reaction data, define the supplemental layer data needed by RT3D, and assign concentrations to the well.

4 Initializing the Model

The first step is to initialize the RT3D data.

- 1. Expand the " 3D Grid Data" folder in the Project Explorer.
- 2. Right-click on the "grid" item in the Project Explorer.
- 3. Select the **New MT3DMS**... command to open the *Basic Transport Package* dialog.

5 The BTN Package

The next step is to initialize the data in the Basic Transport Package. First, initialize the data, select RT3D as the transport model, and select the appropriate packages.

- 1. In the Model section, select the RT3D option.
- 2. Select **Packages...** to open the MT3DMS/RT3D Packages dialog.
- 3. Select the following packages:

- Advection package
- Dispersion package
- Source/sink mixing package
- Chemical reaction package
- For the RT3D reactions, select the "Kinetic-Limited Deg. of BTEX w/ MEA" option.
- 5. Select **OK** to exit the *MT3DMS/RT3D Packages* dialog.

5.1 Starting Concentrations

Note that in the *Layer Data* section of the dialog, the species associated with the reaction being modeled are listed by name. The next step is to define the starting concentration for each of these species. The default starting concentration is zero. Use the default value for BTEX, Fe²⁺, and methane, but use non-zero values for oxygen (4.0 mg/L), nitrate (20.0 mg/L), and sulfate (10.0 mg/L).

- 1. Enter a value of "4.0" for the Starting Conc. (mg/l) for Oxygen.
- 2. Enter a Starting Conc. (mg/l) value of "20.0" for Nitrate.
- 3. Enter a Starting Conc. (mg/l) value of "10.0" for Sulfate.

5.2 Porosity

The porosity to be used is 0.3. Since this is the default in GMS, nothing needs to be changed.

5.3 Stress Periods

The next step is to define the stress periods. Since the injection rate of the well and the other boundary conditions do not change, a single stress period will be used.

- 1. Select Stress Periods... to open the Stress Periods dialog.
- 2. Enter a value of "730" for the *Length*.
- 3. Enter a value of "10" for Num Time Steps.
- 4. Select **OK** to exit the Stress Periods dialog.

5.4 Output Options

The next step is to define the output options. One binary solution file is created by RT3D for each of the species. By default, RT3D saves a solution at each transport step for each species. Since this results in large files containing more solutions than needed for the simple post-processing, it would be better to specify that a solution be saved every 73 days (every time step).

- 1. Select **Output Control**... to open the *Output Control* dialog.
- 2. Select the *Print or save at specified times* option.
- 3. 3. Select **Times**... to open the Variable Time Steps dialog.
- 4. 4. Select Initialize Values... to open the Initialize Time Steps dialog.

- 5. 5. Enter "73.0" for the Initial time step size.
- 6. 6. Enter "73.0" for the Maximum time step size.
- 7. 7. Enter "730.0" for the Maximum simulation time.
- 8. 8. Select **OK** to exit the Initialize Time Steps dialog.
- 9. 9. Select **OK** to exit the Variable Time Steps dialog.
- 10. 10. Select **OK** to exit the Output Control dialog.

This completes the input for the Basic Transport package.

11. Select **OK** to exit the Basic Transport Package dialog.

6 Assigning Concentrations to the Left Boundary

The left boundary of the model is a constant head boundary. Since the head at the left boundary is greater than the head at the right boundary, the left boundary acts as a source and water enters the model from the left. Thus, the concentrations of the species at the left boundary must be defined. The simplest way to do this is to mark the cells as specified concentration cells. :

- 1. Using the **Select Cells** tool, select the column of cells on the left boundary by dragging a box that just surrounds the cells.
- 2. Right-click on any of the selected cells and select the **Properties**... command from the pop-up menu to open the 3D Grid Cell Properties dialog. Select "Project Files (*.gpr)" from the *Save as type* drop-down list.
- 3. Switch to the RT3D tab.
- 4. Change the ICBUND value to "-1".
- 5. Select **OK** to close the 3D Grid Cell Properties dialog.

7 The Advection Package

The next step is to initialize the data for the Advection package.

To define the model boundary with an arc, do the following:

- Select the RT3D | Advection Package ... command to open the Advection Package dialog.
- 2. Select the "Standard finite-difference method" solver from the *Solution scheme* drop-down menu of the dialog.
- 3. Select **OK** to close the *Advection Package* dialog.

8 The Dispersion Package

The next step is to enter the data for the Dispersion package. The aquifer has a longitudinal dispersivity of 10.0 m and a transverse (horizontal) dispersivity of 3.0 m. The vertical dispersivity is assumed to be equal to the longitudinal dispersivity:

1. Select the RT3D | **Dispersion Package...** command to open the Dispersion Package dialog.

- Select Longitudinal Dispersivity... to open the Longitudinal Dispersivity dialog..
- 3. Select **Constant** → **Grid**... to open the *Grid Value* dialog.
- 4. Enter a value of "10.0".
- 5. Select **OK** to close the *Grid Value* dialog.
- 6. Select **OK** to exit the Longitudinal Dispersivity dialog.
- 7. Enter a value of "0.3" for the TRPT value.
- 8. Select **OK** to exit the *Dispersion Package* dialog.

9 The Source/Sink Mixing Package

Next to define the concentration at the spill location:

- 1. Using the **Select Cells** tool, select the cell containing the injection well (spill location) by clicking anywhere in the interior of the cell..
- 2. Select the RT3D | Point Sources/Sinks... command to open the MODFLOW/RT3D Source/Sinks dialog.
- 3. Click the **Add BC** button near the bottom of the dialog.
- 4. Change the Type (ITYPE) to "well (WEL)".
- 5. In the BTEX column, enter a concentration of "1000" (mg/L).
- 6. Select the **OK** button to exit the MODFLOW/RT3D Source/Sinks dialog.

10 The Chemical Reaction Package

Next to initialize the Chemical Reaction package and define appropriate reaction rate constants:

- 1. Select the RT3D | **Chemical Reaction Package...** command to open the RT3D Chemical Reaction Package dialog..
- 2. In the *Reaction parameters* section, click on the *Max_Fe2*+ item and set its value to "25.0".
- 3. Set the value of Max Methane to "30.0".
- 4. Set the value of kHCO2 to "0.1".
- 5. Set the value of kHCNO3 to "0.008".
- 6. Set the value of *kHCFE*3+ to "0.0005".
- 7. Set the value of kHCSO4 to "0.00025".
- 8. Set the value of kHCCH4 to "0.0001".

All monod constants, inhibition coefficients, and yield values, except KiFe 3+, will be left at the default values. The value of KiFe 3+ will be set at 12.5 mg/L (50% of max Fe).

- 9. Set the value of kiFE3+ to "12.5".
- 10. Select **OK** to exit the *RT3D Chemical Reaction Package* dialog.

11 Running RT3D

At this point, it is possible to save the model and run RT3D.

- 1. Select the *File* | Save As... command to bring up the Save As dialog. Enter "tahoe.gpr" in the *File name* field.
- 2. Locate and open the directory entitled *flowmod\flowmod*.
- 3. Enter "btmod" for the File name.
- 4. Select Save to exit the Save As dialog..

Since the name of the project has changed, it is necessary to either use the Run Options command to tell RT3D where the MODFLOW solution is, or re-run MODFLOW.

- 5. Select the *MODFLOW* | **Run MODFLOW** command to start the *MODFLOW* model wrapper.
- 6. When the simulation is finished, select **Close** to exit the *MODFLOW* model wrapper. The solution will automatically be imported.

To run RT3D:

- 7. Select the RT3D | Run RT3D... command to start the RT3D model wrapper.
- 8. Select **Yes** at the prompt to save the changes.
- 9. When the simulation is finished, select **Close** to exit the *RT3D* model wrapper.

GMS reads in the solution automatically.

12 Viewing the Results

First, to view the BTEX solution at 730 days:.

- 1. Select the "BTEX" dataset from the Project Explorer. (if needed, expand the "btmod (RT3D)" solution in the Project Explorer.)
- 2. Select the time step at 730 days from the Time Steps Window.




Figure 2 BTEX solution at 730 days

12.1 Overlaying Contours

Next, it is possible to view concentration contours for the other species. When working with multiple species, it is often convenient to overlay contours of one species on top of contours from another species. As an example, this tutorial will overlay the contours of the other species on top of the BTEX contours. To do this, the display of the BTEX contours will need to be set to be in the background as a CAD layer.

Before creating the CAD layer, it is first necessary to turn off most of the display options other than the contours (to avoid saving the grid cell lines to the CAD file).

- 1. Select the **Display Options** Tmacro to open the Display Options dialog.
- 2. Turn off the Cells edges option.
- 3. Switch to the RT3D tab.
- 4. Select the Check None button.
- 5. Switch to the MODFLOW tab.
- 6. Select the Check None button.
- 7. Select **OK** to close the *Display Options* dialog.

To create the CAD layer:

- 8. In the Project Explorer, right-click on the empty space then, from the pop-up menu, select the **Convert to CAD** command to open the *Save CAD data* dialog.
- 9. Enter "BTEX contours" as the File name.
- 10. Select Save to create the CAD data.

Now to reset the display options and view the oxygen solution at 730 days:

- 11. Select the **Display Options** \blacksquare macro to open the Display Options dialog.
- 12. Turn on the Layer Borders option.
- 13. Select the **OK** button to close the *Display Options* dialog.
- 14. Select the " Oxygen" dataset from the Project Explorer.

Now to turn on a color ramp and a legend:

- 15. Select the **Contour Options** macro to open the *Dataset Contour Options 3D Grid Oxygen* dialog.
- 16. Select the "Color Fill" option for the Contour method.
- 17. Change the Transparency value to "50".
- 18. Select **OK** to exit the *Dataset Contour Options 3D Grid Oxygen* dialog.
- 19. Select the time step at 730 days from the *Time Steps Window*.




Figure 3 The Oxygen solution at 730 days

Next to view the nitrate solution at 730 days:

- 20. Select the " Nitrate" dataset from the Project Explorer.
- 21. Select the time step at 730 days from the Time Steps Window.

Finally, view the iron solution at 730 days.

- 22. Select the " Iron (Fe2+)" dataset from the Project Explorer.
- 23. Select the time step at 730 days from the Time Steps Window.

13 Other Post-Processing Options

At this point, feel free to experiment with the other post-processing options, including film loop animation

14 Conclusion

This concludes the tutorial. Continue to explore RT3D applications or close the program.