

VMware vSphere: NetApp HCI with Cisco ACI

NetApp Solutions

Kevin Hoke, Dorian Henderson, Nikhil M Kulkarni February 19, 2021

This PDF was generated from https://docs.netapp.com/us-en/netapp-solutions/infra/hcicaci_vmware_vsphere.html on August 03, 2021. Always check docs.netapp.com for the latest.

Table of Contents

VMware vSphere: NetA	pp HCI with Cisco AC	J	 	 1
Workflow			 	 1

VMware vSphere: NetApp HCI with Cisco ACI

VMware vSphere is an industry-leading virtualization platform that provides a way to build a resilient and reliable virtual infrastructure. vSphere contains virtualization, management, and interface layers. The two core components of VMware vSphere are ESXi server and the vCenter Server. VMware ESXi is hypervisor software installed on a physical machine that facilitates hosting of VMs and virtual appliances. vCenter Server is the service through which you manage multiple ESXi hosts connected in a network and pool host resources. For more information on VMware vSphere, see the documentation here.

Workflow

The following workflow was used to up the virtual environment. Each of these steps might involve several individual tasks.


- 1. Install and configure Nexus 9000 switches in ACI mode and APIC software on the UCS C-series server. See the Install and Upgrade documentation for detailed steps.
- 2. Configure and setup ACI fabric by referring to the documentation.
- 3. Configure the tenants, application profiles, bridge domains, and EPGs required for NetApp HCI nodes. NetApp recommends using one BD to one EPG framework, except for iSCSI. See the documentation here for more details. The minimum set of EPGs required are in-band management, iSCSI, iSCSI-A, iSCSI-B, VM motion, VM-data network, and native.
 - 1

iSCSI multipathing requires two iSCSI EPGs: iSCSI-A and iSCSI-B, each with one active uplink.

a


NetApp mNode requires an iSCSI EPG with both uplinks active.

4. Create the VLAN pool, physical domain, and AEP based on the requirements. Create the switch and interface profiles for individual ports. Then attach the physical domain and configure the static paths to the EPGs. See the configuration guide for more details.



?×

Leaf Access Port Policy Group - HCI-Compute-ESX



a

Use an access port policy group for interfaces connecting to NetApp HCl compute nodes, and use vPC policy group for interfaces to NetApp HCl storage nodes.


5. Create and assign contracts for tightly-controlled access between workloads. For more information on

- configuring the contracts, see the guide here.
- Install and configure NetApp HCI using NDE. NDE configures all the required parameters, including VDS port groups for networking, and also installs the mNode VM. See the deployment guide for more information.
- 7. Though VMM integration of Cisco ACI with VMware VDS is optional, using the VMM integration feature is a best practice. When not using VMM integration, an NDE-installed VDS can be used for networking with physical domain attachment on Cisco ACI.
- 8. If you are using VMM integration, NDE-installed VDS cannot be fully managed by ACI and can be added as read-only VMM domain. To avoid that scenario and make efficient use of Cisco ACI's VMM networking feature, create a new VMware VMM domain in ACI with a new VMware vSphere Distributed Switch (vDS) and an explicit dynamic VLAN pool. The VMM domain created can integrate with any supported virtual switch.
 - a. Integrate with VDS. If you wish to integrate ACI with VDS, select the virtual switch type to be VMware Distributed Switch. Consider the configuration best practices noted in the following table. See the configuration guide for more details.

Properties			
Name:	: hci-aci-vds-02		
Virtual Switch:	: Distributed Switch		
Associated Attachable Entity Profiles:	▲ Name		
Profiles.	HCI-Internal		
Encapsulation:	vlan		
Delimiter:			
Enable Tag Collection:	✓		
Enable VM Folder Data Retrieval:			
Access Mode:	Read Only Mode	Read Write Mode	
Endpoint Retention Time (seconds):	0	\$	
VLAN Pool:	hci-aci-vmware(dynam	nic 🗸 🗗	

b. **Integrate with Cisco AVE.** If you are integrating Cisco AVE with Cisco ACI, select the virtual switch type to be Cisco AVE. Cisco AVE requires a unique VLAN pool of type Internal for communicating between internal and external port groups. Follow the configuration best practices noted in this table. See the installation guide to install and configure Cisco AVE.


Properties



9. Attach the VMM domain to the EPGs using Pre-Provision Resolution Immediacy. Then migrate all the VMNICs, VMkernel ports, and VNICs from the NDE-created VDS to ACI-created VDS or AVE and so on. Configure the uplink failover and teaming policy for iSCSI-A and iSCSI-B to have one active uplink each. VMs can now attach their VMNICs to ACI-created port groups to access network resources. The port groups on VDS that are managed by Cisco ACI are in the format of <tenant-name>|<application-profile-name>|<application-profile-name>|<application-profile-name>|<application-profile-name>|



Pre-Provision Resolution Immediacy is required to ensure the port policies are downloaded to the leaf switch even before the VMM controller is attached to the virtual switch.




10. If you intend to use micro-segmentation, then create micro-segment (uSeg) EPGs attaching to the right BD. Create attributes in VMware vSphere and attach them to the required VMs. Ensure the VMM domain has Enable Tag Collection enabled. Configure the uSeg EPGs with the corresponding attribute and attach the VMM domain to it. This provides more granular control of communication on the endpoint VMs.




The networking functionality for VMware vSphere on NetApp HCI in this solution is provided either using VMware VDS or Cisco AVE.

VMware VDS

VMware vSphere Distributed Switch (VDS) is a virtual switch that connects to multiple ESXi hosts in the cluster or set of clusters allowing virtual machines to maintain consistent network configuration as they migrate across multiple hosts. VDS also provides for centralized management of network configurations in a vSphere environment. For more details, see the VDS documentation.





The following table outlines the necessary parameters and best practices for configuring and integrating Cisco ACI with VMware VDS.

Resource	Configuration Considerations	Best Practices
Endpoint groups	 Separate EPG for native VLANs Static binding of interfaces to HCI storage and compute nodes in native VLAN EPG uses 802.1P mode. This is required for node discovery to run NDE. Separate EPGs for iSCSI, iSCSI-A, and iSCSI-B with a common BD iSCSI-A and iSCSI-B are for iSCSI multipathing and are used for VMkernel ports on ESXi hosts Physical domain to be attached to iSCSI EPG before running NDE VMM domain to be attached to iSCSI, iSCSI-A, and iSCSI-B EPGs 	 Contracts between EPGs to be well defined. Allow only required ports for communication. Use unique native VLAN for NDE node discovery For EPGs corresponding to port-groups being attached to VMkernel ports, VMM domain to be attached with Pre-Provision for Resolution Immediacy
Interface policy	 A common leaf access port policy group for all ESXi hosts One vPC policy group per NetApp HCI storage node LLDP enabled, CDP disabled 	 Separate VLAN pool for VMM domain with dynamic allocation turned on Recommended to use vPC with LACP Active port-channel policy for interfaces towards NetApp HCI storage nodes Recommended to use individual interfaces for compute nodes, no LACP.
VMM Integration	 Local switching preference Access mode is Read Write. 	 MAC-Pinning-Physical-NIC- Load for vSwitch policy LLDP for discovery policy Enable Tag collection if micro- segmentation is used
VDS	Both uplinks active for iSCSI port-group One uplink each for iSCSI-A and iSCSI-B	 Load balancing method for all port-groups to be 'Route based on physical NIC load' iSCSI VMkernel port migration to be done one at a time from NDE deployed VDS to ACI integrated VDS


Resource	Configuration Considerations	Best Practices
Easy Scale	 Run NDE scale by attaching the same leaf access port policy group for ESXi hosts to be added 	LACP Active port-channel
	 One vPC policy group per NetApp HCl storage node 	individual interfaces for
	 Individual interfaces (for ESXi hosts) and vPCs (for storage nodes) should be attached to native, in-band management, iSCSI, VM motion EPGs for successful NDE scale 	compute nodes, no LACP.
	LLDP enabled, CDP disabled	




For traffic load-balancing, port channels with vPCs can be used on Cisco ACI along with LAGs on VDS with LACP in active mode. However, using LACP can affect storage performance when compared to iSCSI multipathing.

Cisco AVE

Cisco ACI Virtual Edge (AVE) is a virtual switch offering by Cisco that extends the Cisco ACI policy model to virtual infrastructure. It is a hypervisor- independent distributed network service that sits on top of the native virtual switch of the hypervisor. It leverages the underlying virtual switch using a VM-based solution to provide network visibility into the virtual environments. For more details on Cisco AVE, see the documentation. The following figure depicts the internal networking of Cisco AVE on an ESXi host (as tested).





The following table lists the necessary parameters and best practices for configuring and integrating Cisco ACI with Cisco AVE on VMware ESXi. Cisco AVE is currently only supported with VMware vSphere.

Resource	Configuration Considerations	Best Practices
Endpoint Groups	 Separate EPG for native VLANs Static binding of interfaces towards HCI storage and compute nodes in native VLAN EPG uses 802.1P mode. This is required for node discovery to run NDE. Separate EPGs for iSCSI, iSCSI-A and iSCSI-B with a common BD iSCSI-A and iSCSI-B are for iSCSI multipathing and are used for VMkernel ports on ESXi hosts Physical domain to be attached to iSCSI EPG before running NDE VMM domain is attached to iSCSI, iSCSI-A, and iSCSI-B EPGs 	required ports for communication. • Use unique native VLAN for NDE node discovery • Use native switching mode in VMM domain for EPGs that correspond to port groups being attached to host's VMkernel adapters • Use AVE switching mode in VMM domain for EPGs corresponding to port groups carrying user VM traffic
Interface Policy	 One vPC policy group per NetApp HCI storage node LLDP enabled, CDP disabled Before running NDE, for NDE discovery: Leaf Access port policy group for all ESXi hosts After running NDE, for Cisco AVE: One vPC policy group per ESXi host 	 vPCs to ESXi hosts for Cisco AVE Use static mode on port-channel policy for vPCs to ESXi Use Layer-4 SRC port load balancing hashing method for port-channel policy NetApp recommends using vPC with LACP active port-

Resource	Configuration Considerations	Best Practices	
VMM Integration	 Create a new VLAN range [or Encap Block] with role Internal and Dynamic allocation' attached to the VLAN pool intended for VMM domain Create a pool of multicast addresses (one address per EPG) Reserve another multicast address different from the pool of multicast addresses intended for AVE fabric-wide multicast address Local switching preference Access mode to be Read Write mode 	 Static mode on for vSwitch policy Ensure that vSwitch port-channel policy and interface policy group's port-channel policy are using the same mode LLDP for discovery policy Enable Tag collection if using micro-segmentation Recommended option for Default Encap mode is VXLAN 	
VDS	 Both uplinks active for iSCSI port-group One uplink each for iSCSI-A and iSCSI-B 	 iSCSI VMkernel port migration is done one at a time from NDE deployed VDS to ACI integrated VDS Load balancing method for all port-groups to be Route based on IP hash 	
Cisco AVE	 Run NDE with access port interface policy groups towards ESXi hosts. Individual interfaces towards ESXi hosts should be attached to native, in-band management, iSCSI, VM motion EPGs for successful NDE run. Once the environment is up, place the host in maintenance mode, migrate interface policy group to vPC with static mode on, assign vPC to all required EPGs and remove the host from maintenance mode. Repeat the same process for all hosts. Run the AVE installation process to install AVE control VM on all hosts 		

Resource	Configuration Considerations	Best Practices
Easy Scale	 Run NDE scale with access port interface policy group for ESXi hosts to be added. Individual interfaces should be attached to native, in-band management, iSCSI, VM motion EPGs for successful NDE run. Once the ESXi host is added to the vSphere cluster, place the host in maintenance mode and migrate the interface policy group to vPC with static mode on. Then attach the vPC to required EPGs. Run AVE installation process on the new host for installing AVE control VM on that host One vPC policy group per NetApp HCI storage node to be added to the cluster LLDP enabled, CDP disabled 	 Use network protocol profile on the in-band management VLAN if DHCP is not available on that network Recommended to use vPC with LACP Active port-channel policy for interfaces towards NetApp HCI storage nodes



For traffic load balancing, port channel with vPCs can be used on Cisco ACI along with LAGs on ESXi hosts with LACP in active mode. However, using LACP can affect storage performance when compared to iSCSI multipathing.

Next: Red Hat Virtualization: NetApp HCl with Cisco ACl

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.