Alcanzar	R10B	7.1	7.1	R8B	Alcanzar
Tomar	G1A	3.0	3.0	G1A	Asir
			6.9	M16C	Mover
			20.7	P2SSE	Colocar en posición
Soltar	RL1	2.0	2.0	RL1	Soltar
Esp32-c6					Cable USB
Alcanzar	R10B	10.5	10.5	G1A	Asir
Tomar	G1A	3.0	3.0	P2SSE	Colocar en posición
Soltar	RL1		2.0	RL1	Soltar
		2.0			
Multicontac					Cable USB
to					
Alcanzar	R10B	10.5	10.5	G1A	Asir
Tomar	G1A	3.0	3.0	P2SSE	Colocar en posición
			2.0	RL1	Soltar
Soltar	RL1	2.0			
Multicontac					Conector
0					
Alcanzar	R10B	10.5	10.5	G1A	Asir
Tomar	G1A	3.0	3.0	P2SSE	Colocar en posición
			2.0	RL1	Soltar
Soltar	RL1	2.0			
Descansar					Multicontacto
		2.0	2.0	M16C	Prender