

EH&S/General Safety SHOP SAFETY

Procedure No.: SS-AC

Authorized By: JOHN M. SEAMAN

Contact No.: (805)893-5288

Issue Date:

Review Date:

Page Number: 1 of 1

WARNING!

Do not use this machine unless an instructor or shop supervisor has instructed you in the safe use and operation and has authorized you to operate this equipment!

Equipment/Machine: | AIR COMPRESSOR

Description of Work: Using an air compressor

Potential Hazards: *Electrical and compression hazard with the potential to cause harm through exposure to noise and compressed air.*

Safe Work Procedure Checklist:

1. PRE-Operation:

- Task (e.g. Drawings, instructions, specifications etc) is clearly understood.
- Appropriate quarding is in place.
- Make sure release valve is clean and free from obstruction.
- Lock the wheels to prevent movement.
- Check all fittings are securely connected prior to being pressurised.
- Identify ON/OFF switch.

2. Operation:

- Start compressor noting pressure increase and cut out/cut in pressure.
- Do not kink or squash the hose.
- Listen for any air leaks when using the compressor and report these immediately.
- Check the compressor pressure at regular intervals.
- Release the pressure in hose prior to uncoupling.

3. POST-Operation:

- Release the pressure from the hose and vessel.
- Store air hose off the ground to prevent contamination from dirt.
- Return air tools to their storage area.