Step1


Choose the target options as highlighted below and enter.

```
srv@srv-GE75-Raider-9SG: ~/Downloads/buildroot-2020.02.4
/home/srv/Downloads/buildroot-2020.02.4/.config - Buildroot 2020.02.4 Configura
                    Buildroot 2020.02.4 Configuration
   Arrow keys navigate the menu. <Enter> selects submenus ---> (or empty
   submenus ----). Highlighted letters are hotkeys. Pressing <Y>
   selects a feature, while <N> excludes a feature. Press <Esc>> to
   exit, <?> for Help, </> for Search. Legend: [*] feature is selected
       Target options --->
           Build options --->
           Toolchain --->
           System configuration --->
          Kernel --->
           Target packages --->
           Filesystem images --->
          Bootloaders --->
          Host utilities --->
          Legacy config options --->
         <Select>
                                < Help >
                                                       < Load >
                    < Exit >
                                            < Save >
```

Step 2 Choose "Target Architecture (i386)" and enter


Step 3

Scroll down and select "AArch64 (little endian) as highlighted below. Use "space bar" to choose the option and hit enter.



Step 4

You will see this page. Here you should choose **<Exit>** to go back to main menu



Step 5

You will be back to the main menu. Now go to "Toolchain section" (hit enter on Toolchain)

```
srv@srv-GE75-Raider-9SG: ~/Downloads/buildroot-2020.02.4
/home/srv/Downloads/buildroot-2020.02.4/.config - Buildroot 2020.02.4 Configura
                     Buildroot 2020.02.4 Configuration
   Arrow keys navigate the menu. <Enter> selects submenus ---> (or empty
   submenus ----). Highlighted letters are hotkeys. Pressing <Y>
   selects a feature, while <N> excludes a feature. Press <Esc> to
   exit, <?> for Help, </> for Search. Legend: [*] feature is selected
           Target options --->
           Build options
          Toolchain --->
           System configuration
           Kernel --->
           Target packages --->
           Filesystem images --->
           Bootloaders --->
           Host utilities --->
           Legacy config options --->
         <Select>
                     < Exit >
                                < Help >
                                                        < Load >
                                            < Save >
```


Step 6

You will see the tool chain menu like the below image. Hit enter on the "Toolchain type" as highlighted below

```
srv@srv-GE75-Raider-9SG: ~/Downloads/buildroot-2020.02.4
/home/srv/Downloads/buildroot-2020.02.4/.config - Buildroot 2020.02.4 Configura
                                 Toolchain
   Arrow keys navigate the menu. <Enter> selects submenus ---> (or empty
   submenus ----). Highlighted letters are hotkeys. Pressing <Y>
   selects a feature, while <N> excludes a feature. Press <Esc>> to
   exit, <?> for Help, </> for Search. Legend: [*] feature is selected
       Toolchain type (Buildroot toolchain) --->
           *** Toolchain Buildroot Options **
       (buildroot) custom toolchain vendor name (NEW)
           c library (uClibc-ng) --->
           *** Kernel Header Options ***
           Kernel Headers (Linux 5.4.x kernel headers) --->
           *** uClibc Options ***
       (package/uclibc/uClibc-ng.config) uClibc configuration file to us
       () Additional uClibc configuration fragment files (NEW)
       [ ] Enable WCHAR support (NEW)
         <Select>
                     < Exit > < Help > < Save >
                                                        < Load >
```

Step 7:

Now you will see the following options. Choose "External toolchain" (use arrow to move the cursor and hit "space bar" to select: the 'x' mark should move to the option External toolchain).



After this, come back to the main menu (use exit)

Step 8

Enter "System Configuration" as below

```
🕽 🖨 📵 srv@srv-GE75-Raider-9SG: ~/Downloads/buildroot-2020.02.4
home/srv/Downloads/buildroot-2020.02.4/.config - Buildroot 2020.02.4 Configura
                      Buildroot 2020.02.4 Configuration
   Arrow keys navigate the menu. <Enter> selects submenus ---> (or empty
   submenus ----). Highlighted letters are hotkeys. Pressing <Y> selects a feature, while <N> excludes a feature. Press <Esc> to
   exit, <?> for Help, </> for Search. Legend: [*] feature is selected
            Target options --->
            Build options --->
            Toolchain --->
        System configuration --->
            Kernel --->
            Target packages --->
            Filesystem images --->
            Bootloaders --->
           Host utilities --->
            Legacy config options --->
         <Select>
                      < Exit > < Help >
                                                             < Load >
                                                < Save >
```


Step 9


After entering system configuration, scroll down until you see the "Enable root login with password (NEW) line item as below:

```
🕒 🗊 srv@srv-GE75-Raider-9SG: ~/Downloads/buildroot-2020.02.4
home/srv/Downloads/buildroot-2020.02.4/.config - Buildroot 2020.02.4 Configura
   System configuration
Arrow keys navigate the menu. <Enter> selects submenus ---> (or empty
   submenus ----). Highlighted letters are hotkeys. Pressing <Y>
   selects a feature, while <N> excludes a feature. Press <Esc> to
   exit, <?> for Help, </> for Search. Legend: [*] feature is selected
        (system/device_table.txt) Path to the permission tables (NEW)
[ ] support extended attributes in device tables (NEW)
        ] Use symlinks to /usr for /bin, /sbin and /lib (NEW)
[*] Enable root login with password (NEW)
        (asdf) Root password
            /bin/sh (busybox' default shell) --->
        [*] Run a getty (login prompt) after boot (NEW) --->
        [*] remount root filesystem read-write during boot (NEW)
        () Network interface to configure through DHCP (NEW)
        (/bin:/sbin:/usr/bin:/usr/sbin) Set the system's default PATH (NE
          <Select>
                        < Exit >
                                                   < Save >
                                     < Help >
                                                                 < Load >
```

Step 10

Hit enter on the "(asdf) Root passoword" and change your password.





Step 11

After changing the password. Scroll down in the menu and hit enter on the line item "Run a getty (login prompt) after boot (NEW)" as shown below

```
🖶 💷 srv@srv-GE75-Raider-9SG: ~/Downloads/buildroot-2020.02.4
/home/srv/Downloads/buildroot-2020.02.4/.config - Buildroot 2020.02.4 Configura
 System configuration
                           System configuration
   Arrow keys navigate the menu. <Enter> selects submenus ---> (or empty
   submenus ----). Highlighted letters are hotkeys. Pressing <Y>
   selects a feature, while <N> excludes a feature. Press <Esc> to
   exit, <?> for Help, </> for Search. Legend: [*] feature is selected
       (system/device_table.txt) Path to the permission tables (NEW)
         ] support extended attributes in device tables (NEW)
       [ ] Use symlinks to /usr for /bin, /sbin and /lib (NEW)
       [*] Enable root login with password (NEW)
       (asdf) Root password
           /bin/sh (busybox' default shell)
       [[*] Run a getty (login prompt) after boot (NEW)
       [*] remount root filesystem read-write during boot (NEW)
       () Network interface to configure through DHCP (NEW)
       (/bin:/sbin:/usr/bin:/usr/sbin) Set the system's default PATH (NE
         <Select>
                                              < Save >
                     < Exit >
                                 < Help >
                                                          < Load >
```


This will show the following menu

```
home/srv/Downloads/buildroot-2020.02.4/.config - Buildroot 2020.02.4 Configura/
  System configuration 
ightarrow Run a getty (login prompt) after boot
                   Run a getty (login prompt) after boot
   Arrow keys navigate the menu. <Enter> selects submenus ---> (or empty
   submenus ----). Highlighted letters are hotkeys. Pressing <Y>
   selects a feature, while <N> excludes a feature. Press <Esc> to
   exit, <?> for Help, </> for Search. Legend: [*] feature is selected
       ---- Run a getty (login prompt) after boot
       (ttyAMA0) TTY port
             Baudrate (keep kernel default) --->
       (vt100) TERM environment variable (NEW)
       other options to pass to getty (NEW)
         <Select>
                     < Exit >
                                 < Help >
                                                         < Load >
                                             < Save >
```

Step 12

Scroll down and hit enter on "TTY port". You will see the following page.

Enter the string value as "ttyAMA0"



Step 13

Go back to the main menu (use exit) and enter the Target packages as below

```
🕽 🗐 🗊 srv@srv-GE75-Raider-9SG: ~/Downloads/buildroot-2020.02.4
home/srv/Downloads/buildroot-2020.02.4/.config - Buildroot 2020.02.4 Configura/
                     Buildroot 2020.02.4 Configuration
   Arrow keys navigate the menu. <Enter> selects submenus ---> (or empty
   submenus ----). Highlighted letters are hotkeys. Pressing <Y>
   selects a feature, while <N> excludes a feature. Press <Esc> to
   exit, <?> for Help, </> for Search. Legend: [*] feature is selected
           Target options --->
           Build options --->
           Toolchain --->
           System configuration --->
           Kernel --->
         Target packages --->
           Filesystem images --->
           Bootloaders --->
           Host utilities --->
           Legacy config options --->
         <Select>
                     < Exit > < Help >
                                            < Save >
                                                        < Load >
```

You will see the following menu. Scroll down and choose "Show packages that are also provided by busybox" (Use "space bar" to choose the option)


```
□ srv@srv-GE75-Raider-9SG: ~/Downloads/buildroot-2020.02.4
/home/srv/Downloads/buildroot-2020.02.4/.config - Buildroot 2020.02.4 Configura
Target packages
                              Target packages
   Arrow keys navigate the menu. <Enter> selects submenus ---> (or empty
   submenus ----). Highlighted letters are hotkeys. Pressing <Y>
   selects a feature, while <N> excludes a feature. Press <Esc> to
   exit, <?> for Help, </> for Search. Legend: [*] feature is selected
       -*- BusyBox
       (package/busybox/busybox.config) BusyBox configuration file to us
             Additional BusyBox configuration fragment files (NEW)
           Show packages that are also provided by busybox
           Individual binaries (NEW)
            Install the watchdog daemon startup script (NEW)
           Audio and video applications --->
           Compressors and decompressors --->
           Debugging, profiling and benchmark --->
           Development tools
         <Select>
                     < Exit >
                                 < Help >
                                                         < Load >
                                             < Save >
```

Step 14

After the above step, exit and navigate back to the main menu. Choose "Filesystem Images" as shown below.

```
home/srv/Downloads/buildroot-2020.02.4/.config - Buildroot 2020.02.4 Configura
                    Buildroot 2020.02.4 Configuration
   Arrow keys navigate the menu. <Enter> selects submenus ---> (or empty
   submenus ----). Highlighted letters are hotkeys. Pressing <Y>
   selects a feature, while <N> excludes a feature. Press <Esc><to>to</to>
   exit, <?> for Help, </> for Search. Legend: [*] feature is selected
           Target options --->
           Build options --->
           Toolchain --->
           System configuration --->
           Kernel --->
           Target packages --->
       || Filesystem images --->
           Bootloaders --->
           Host utilities --->
           Legacy config options --->
         <Select>
                     < Exit >
                                < Help >
                                            < Save >
                                                        < Load >
```

You will see the following menu. Scroll down and choose the "cpio the root filesystem" option as shown below



Step 15

Exit the menu all the way out. Save the configuration during exit.

You will see the following in the terminal

```
srv@srv-GE75-Raider-9SG:~/Downloads/buildroot-2020.02.4$ make menuconfig
configuration written to /home/srv/Downloads/buildroot-2020.02.4/.config

*** End of the configuration.

*** Execute 'make' to start the build or try 'make help'.

srv@srv-GE75-Raider-9SG:~/Downloads/buildroot-2020.02.4$
```

Step 16

Run "make" here and the output file will be saved to output/images.

```
🔊 🖨 📵 srv@srv-GE75-Raider-9SG: ~/Downloads/buildroot-2020.02.4/output/images
fakeroot
PATH="/home/srv/Downloads/buildroot-2020.02.4/output/host/bin:/home/srv/Download
s/buildroot-2020.02.4/output/host/sbin:/home/srv/.pyenv/plugins/pyenv-virtualenv
/shims:/home/srv/.pyenv/shims:/home/srv/.pyenv/bin:/home/srv/.pyenv/plugins/pyen
v-virtualenv/shims:/home/srv/.pyenv/shims:/home/srv/.pyenv/bin:/home/srv/autowar
e/ros/install/sick_ldmrs_driver/bin:/opt/ros/kinetic/bin:/home/srv/bin:/home/srv
/.local/bin:/usr/local/sbin:/usr/local/bin:/usr/sbin:/usr/bin:/sbin:/bin:/usr/ga
mes:/usr/local/games:/snap/bin:/usr/local/cuda/bin" FAKEROOTDONTTRYCHOWN=1 /home
/srv/Downloads/buildroot-2020.02.4/output/host/bin/fakeroot -- /home/srv/Downloa
ds/buildroot-2020.02.4/output/build/buildroot-fs/tar/fakeroot
rootdir=/home/srv/Downloads/buildroot-2020.02.4/output/build/buildroot-fs/tar/ta
table='/home/srv/Downloads/buildroot-2020.02.4/output/build/buildroot-fs/full de
vices table.txt'
ln -snf /home/srv/Downloads/buildroot-2020.02.4/output/host/aarch64-buildroot-li
nux-gnu/sysroot /home/srv/Downloads/buildroot-2020.02.4/output/staging
srv@srv-GE75-Raider-9SG:~/Downloads/buildroot-2020.02.4$ ls
                           DEVELOPERS linux
arch
         Config.in
                                                        package
                                                                 toolchain
         Config.in.legacy
board
                           dι
                                       Makefile
                                                        README
                                                                 utils
                                       Makefile.legacy
boot
         configs
                           docs
                                                        support
CHANGES COPYING
                           fs
                                       output
                                                        system
srv@srv-GE75-Raider-9SG:~/Downloads/buildroot-2020.02.4$ cd output/
srv@srv-GE75-Raider-9SG:~/Downloads/buildroot-2020.02.4/output$ ls
build host images staging target
srv@srv-GE75-Raider-9SG:~/Downloads/buildroot-2020.02.4/output$ cd images/
srv@srv-GE75-Raider-9SG:~/Downloads/buildroot-2020.02.4/output/images$ ls
srv@srv-GE75-Raider-9SG:~/Downloads/buildroot-2020.02.4/output/images$
```