Document ID: 1780393 Page 1 of 1

2009 Chevrolet Express - AWD | Express, Savana (VIN G/H) Service Manual | Body Repair | Bumpers and Fascias | Specifications | Document ID: 1780393

Fastener Tightening Specifications

	Specif	Specification	
Application	Metric	English	
Filler Panel Applique	2 N·m	18 lb in	
Front Bumper Bracket Bolts	25 N·m	18 lb ft	
Front Bumper To Frame Bolts	50 N·m	37 lb ft	
Rear Bumper Impact Bar Brace Nuts	50 N·m	37 lb ft	
Rear Inner Bumper Brace Bolts	25 N·m	18 lb ft	
Rear Outer Bumper Brace Bolts	50 N·m	37 lb ft	
Rear Outer Bumper Brace Nuts	50 N·m	37 lb ft	
Rear Step Pad Extension Nuts	1.5 N·m	13 lb in	
Upper Fender Filler Panel To The Body	2 N·m	18 lb in	


Document ID: 2123518 Page 1 of 2

2009 Chevrolet Express - AWD | Express, Savana (VIN G/H) Service Manual | Body Repair | Bumpers and Fascias |
Repair Instructions | Document ID: 2123518

Front Bumper Replacement

Removal Procedure


- 1. Remove the grille. Refer to Grille Replacement.
- 2. Mark the location of the fasteners and the brackets to the bumper.
- 3. Remove the outboard bumper bracket bolt.



- 4. Remove the bolts retaining the bumper to the frame.
- 5. Remove the front bumper from the vehicle.
- 6. Remove the step pad from the front bumper. Refer to Front Bumper Step Pad Replacement.
- 7. Remove the air deflector from the front bumper. Refer to <u>Front Bumper Fascia Air Deflector Replacement</u>.

- 1. Install the air deflector to the front bumper. Refer to <u>Front Bumper Fascia Air Deflector</u> Replacement.
- 2. Install the step pad to the front bumper. Refer to Front Bumper Step Pad Replacement.

Document ID: 2123518 Page 2 of 2



3. Install the front bumper to the vehicle.

Caution: Refer to <u>Fastener Caution</u> in the Preface section.

- 4. Install the bolts that retain the front bumper to the frame and tighten to 50 N⋅m (37 lb ft).
- 5. Install the grille. Refer to Grille Replacement.


Document ID: 751914 Page 1 of 2

2009 Chevrolet Express - AWD | Express, Savana (VIN G/H) Service Manual | Body Repair | Bumpers and Fascias |
Repair Instructions | Document ID: 751914

Front Bumper Filler Replacement


Removal Procedure

1. Remove the radiator grille from the vehicle. Refer to Grille Replacement .





- 2. Remove the push pin retainers (2) retaining the front bumper filler (1) to the radiator support.
- 3. Remove the front bumper filler (1) from the vehicle.



© 2010 General Motors Corporation. All rights reserved.

Page 2 of 2 Document ID: 751914




- 1. Install the front bumper filler (1) to the vehicle.
- 2. Install the push pin retainers (2) in order to retain the front bumper filler (1) to the radiator
- 3. Install the radiator grille to the vehicle. Refer to **Grille Replacement** .

2009 Chevrolet Express - AWD | Express, Savana (VIN G/H) Service Manual | Body Repair | Bumpers and Fascias |
Repair Instructions | Document ID: 2123520


Upper Front Fender Filler Panel Replacement Removal Procedure

1. Place a protective covering at the top of the fender.





- 2. Remove the upper fender filler panel applique. Refer to <u>Windshield Frame Filler Panel</u> <u>Applique Replacement</u>.
- 3. Remove the bolt (4) retaining the upper filler panel (1) to the body.
- 4. Remove the upper filler panel (1) from the retaining clips.
- 5. Remove the upper filler panel (1) from the vehicle.





- 1. Install the upper fender filler panel (1) to the vehicle.
- 2. Install the upper fender filler panel (1) under the windshield molding.

Install the upper fender filler panel (1) onto the retaining clips.


Caution: Refer to <u>Fastener Caution</u> in the Preface section.

- 3. Install the bolt (4) in order to retain the upper fender filler panel (1) to the body and tighten to 2 N·m (18 lb in).
- 4. Install the upper fender filler panel applique. Refer to <u>Windshield Frame Filler Panel Applique Replacement</u>.
- 5. Remove the protective covering from the fender.


Document ID: 2123522 Page 1 of 2

2009 Chevrolet Express - AWD | Express, Savana (VIN G/H) Service Manual | Body Repair | Bumpers and Fascias |
Repair Instructions | Document ID: 2123522

Front Bumper Impact Bar Bracket Replacement Removal Procedure



- 1. Remove the bolts that retain the bracket (2) to the bumper (1).
- 2. Remove the bracket (2) from the bumper (1).



© 2010 General Motors Corporation. All rights reserved.

Document ID: 2123522 Page 2 of 2



1. Install the bracket (2) to the bumper (1).

Caution: Refer to <u>Fastener Caution</u> in the Preface section.

2. Install the bolts that retain the bracket (2) to the bumper (1) and tighten to 25 N·m (18 lb ft).

Document ID: 751873 Page 1 of 2


2009 Chevrolet Express - AWD | Express, Savana (VIN G/H) Service Manual | Body Repair | Bumpers and Fascias |
Repair Instructions | Document ID: 751873

Front Bumper Step Pad Replacement

Removal Procedure

- 1. Remove the front bumper from the vehicle. Refer to Front Bumper Replacement .
- 2. Using pliers, gently squeeze the retainer tabs on the molding.

Push the retainer tabs through the slots in the bumper.






3. Remove the front bumper step pad (1) from the bumper.

Installation Procedure

Document ID: 751873 Page 2 of 2






- 1. Align the retainer tabs on the front bumper step pad (1) with the slots in the bumper.
- 2. Using a rubber mallet, set the retainer tabs in place starting at the center of the front bumper step pad and work toward each end of the pad.
- 3. Install the front bumper to the vehicle. Refer to Front Bumper Replacement .

Document ID: 777383 Page 1 of 2

2009 Chevrolet Express - AWD | Express, Savana (VIN G/H) Service Manual | Body Repair | Bumpers and Fascias |
Repair Instructions | Document ID: 777383

Front Bumper Fascia Air Deflector Replacement (Light Duty)

Removal Procedure






- 1. Using pliers, gently squeeze the retainer tabs to release the air deflector (2) from the front bumper (1).
- 2. Remove the air deflector (2) from the front bumper (1).

Installation Procedure

Document ID: 777383 Page 2 of 2






- Install the air deflector (2) to the front bumper (1).
 Install and fully seat the retainer tabs that retain the air deflector (2) to the front bumper (1).

Document ID: 777385 Page 1 of 2

2009 Chevrolet Express - AWD | Express, Savana (VIN G/H) Service Manual | Body Repair | Bumpers and Fascias |
Repair Instructions | Document ID: 777385

Front Bumper Fascia Air Deflector Replacement (Heavy Duty)

Removal Procedure






- 1. Release the push-pins that retain the air deflector (2) to the front impact bar (1).
- 2. Remove the air deflector (2) from the front impact bar (1).

Installation Procedure

Document ID: 777385 Page 2 of 2






 Install the air deflector (2) to the front impact bar (1).
 Install and fully seat the push-pins that retain the air deflector (2) to the front impact bar (1).

2009 Chevrolet Express - AWD | Express, Savana (VIN G/H) Service Manual | Body Repair | Bumpers and Fascias |
Repair Instructions | Document ID: 2123524

Rear Bumper Replacement

Removal Procedure

1. Mark the location of the braces and the fasteners.






- 2. Remove the nuts (1) that retain the rear bumper outer and inner braces to the frame.
- 3. Remove the bumper (3) from the vehicle.
- 4. Remove the rear bumper braces from the bumper. Refer to Rear Bumper Bracket Replacement.
- 5. Remove the rear bumper step pad from the bumper. Refer to Rear Bumper Step Pad Replacement.
- 6. Remove the rear bumper step pad extensions from the bumper, if equipped. Refer to <u>Rear Bumper Step Pad Extension Replacement</u>.

- 1. Install the rear bumper step pad to the bumper. Refer to Rear Bumper Step Pad Replacement.
- 2. Install the rear bumper step pad extensions to the bumper. Refer to <u>Rear Bumper Step Pad Extension Replacement</u>.
- 3. Install the rear bumper braces to the bumper. Refer to Rear Bumper Bracket Replacement.

Document ID: 2123524 Page 2 of 2





4. Install the bumper (3) to the vehicle.

Caution: Refer to <u>Fastener Caution</u> in the Preface section.

5. Install the inner and outer bumper impact bar brace retaining nuts (1) to the frame and tighten to 50 N·m (37 lb ft).


Document ID: 2123527 Page 1 of 2

2009 Chevrolet Express - AWD | Express, Savana (VIN G/H) Service Manual | Body Repair | Bumpers and Fascias |
Repair Instructions | Document ID: 2123527

Rear Bumper Bracket Replacement

Removal Procedure


- 1. Raise and support the vehicle with suitable safety stands. Refer to <u>Lifting and Jacking the Vehicle</u>.
- 2. Remove the rear bumper step pad from the bumper. Refer to Rear Bumper Step Pad Replacement.
- 3. Remove the rear bumper from the vehicle. Refer to Rear Bumper Replacement.
- 4. Mark the location of the inner bumper brace to the bumper.





- 5. Remove the nuts (8) that retain the outer bumper brace (1) to the frame.
- 6. Remove the nuts and the bolts (6) that retain the outer bumper brace to the bumper.
- 7. Remove the bolts (10) that retain the inner bumper brace (2) to the bumper.
- 8. Remove the outer (1) then the inner (2) bumper brace from the frame and the bumper.

Installation Procedure





- 1. Install the outer (1) then the inner (2) bumper brace to the frame and bumper.
- 2. Align the inner bumper brace with the marks made prior to removal.

Caution: Refer to <u>Fastener Caution</u> in the Preface section.

- 3. Install the inner bumper brace retaining bolts to the bumper and tighten to 25 N·m (18 lb ft).
- 4. Install the outer bumper brace retaining nuts and bolts (6) to the bumper and tighten to 50 N·m (37 lb ft).
- 5. Install the outer bumper brace nuts (8) and stud plate (7) to the frame and tighten to 50 N·m (37 lb ft).
- 6. Install the rear bumper to the vehicle. Refer to Rear Bumper Replacement.
- 7. Install the rear bumper step pad to the bumper. Refer to Rear Bumper Step Pad Replacement.
- 8. Lower the vehicle.

Document ID: 751886 Page 1 of 2


2009 Chevrolet Express - AWD | Express, Savana (VIN G/H) Service Manual | Body Repair | Bumpers and Fascias |
Repair Instructions | Document ID: 751886

Rear Bumper Step Pad Replacement

Removal Procedure

1. Using pliers, gently squeeze the tangs of the step pad.


Push the tangs through the slots in the bumper.





2. Remove the step pad (1) from the bumper (4).

Installation Procedure






- Install the step pad (1) on the bumper (4).
 Align the tangs on the step pad with the slots in the bumper.
- 3. Using a rubber mallet, set the tangs in place starting at the center of the step pad and work toward each end of the pad.

Document ID: 2123529 Page 1 of 2


2009 Chevrolet Express - AWD | Express, Savana (VIN G/H) Service Manual | Body Repair | Bumpers and Fascias |
Repair Instructions | Document ID: 2123529

Rear Bumper Step Pad Extension Replacement Removal Procedure





- 1. Remove the nuts (3) that retain the step pad extension to the bumper.
- 2. Remove the step pad extension (2) from the bumper (4).



© 2010 General Motors Corporation. All rights reserved.

Page 2 of 2 Document ID: 2123529



1. Install the step pad extension (2) to the bumper (4).

Caution: Refer to <u>Fastener Caution</u> in the Preface section.

2. Install the step pad extension retaining nuts (3) to the bumper and tighten to 1.5 N·m (13 lb in).