

Project (If Applicable)		TRA Ref. No.		DOUS-TRA-023	
Location / Worksite					
Sub Location / Area					
Equipment Spread (Optional)					
Task / Activity					
Approver					
Responsible Persons					
Date TRA Created					
Reference Supporting Documents & Task Plan					
S3RA:			Hot Work Checklist:		
Task Plan:			Work at Height Checklist:		
Lift Plan:			Confined Space Work Checklist:		
PTW:			Electrical Equipment Checklist:		
COSHH / SDS:			Electrical Isolation Checklist:		
Rescue Plan:			Machinery Isolation Checklist:		
Work Equipment Assessment:			Pressure Systems Checklist:		
Other:			Other:		
Reason for TRA (Tick where Applicable)					
Identification of New Task		Annual Review	Review following Incident	Management of Change Record	Other, Please Specify
☐		☐	☐	☐	☒
Other (Details): Performance of task.					
TRA Participants					
Name		Position		Signature	
NOTE: STANDARD PPE OF SAFETY FOOTWEAR, SAFETY HELMET, COVERALLS, GLASSES AND GLOVES MUST BE WORN. ANY ADDITIONAL PPE REQUIRED SHALL BE CAPTURED IN THE MITIGATING CONTROLS SECTION OF THE TRA TEMPLATE BELOW.					

No.	Task /Activity	Hazard and Consequence		Initial Risk			Mitigating Controls	Residual Risk		
	Sequential Steps	Hazard	Consequence	Probability	Consequence Severity	Risk Rating	Measures to Reduce Risk to ALARP	Probability	Consequence Severity	Risk Rating
1	Review TRA and TBT	Miscommunication	Personnel Injury / Environmental Pollution	1	2	2	Situational awareness and proper use of PPE. Hard hats, impact gloves, cotton gloves, latex gloves, steel toed boots, safety glasses, side shields and face shield	1	1	1
2	Prior to any task being undertaken ensure that all personnel are aware of the hazards involved.	Electrical shock, possible slips trips and falls. Pinch points poor body position. Hydraulic discharge and spills.	Personnel Injury / Environmental Pollution	2	3	6	All personnel must be aware of their surrounds and weather conditions. Use proper Manual Handling techniques, i.e., Always use proper body positioning, lift with legs, and obtain second personnel when loads are over 40lbs. Read all SDS on chemicals used, use PPE that is specified in SDS and be aware of where all spill kits are located.	2	2	4
3	Personnel will set up transfer pump on LARS	Slips, trips, and falls	Personnel Injury / Environmental Pollution	2	2	4	Ensure proper hand and foot placement while setting up pump.	1	1	1
4	Personnel will set up suction and discharge hoses from LARS to oil drain location. PERSONNEL MUST VERIFY HOSE LINE UP PRIOR TO PUMPING TO TOTE TANK	Environmental spills	Personnel Injury / Environmental Pollution	2	2	4	Ensure that all connections are tight and sealed, have spill kit on hand for accidental discharge.	1	1	1
5	STATION ONE PERSON AT TOTE TANK WITH RADIO COMMUNICATION TO PERSONNEL AT THE PUMP.	Environmental spills	Environmental Pollution				To ensure immediate shut down of the pump if leaks/spills are observed	2	2	1
6	Begin pumping LARS oily water into used oil tote provided.	Spills or overflow around oil drain area	Personnel Injury / Environmental Pollution	2	2	4	Personnel will not leave oil drain unattended.	1	1	1
7	LARS pit empty of oily water	Damage to equipment, possible slips, trips, and falls.	Personnel Injury / Environmental Pollution	2	2	4	Keep area clear of possible slips, trips, and falls.	1	1	1

8	Clean up hoses, pump, drain and LARS of all equipment.	Slips, trips, and falls from any residual oil or equipment left out.	Personnel Injury / Environmental Pollution	2	2	4	Wipe all hoses and pumps down ensure that all valves are closed, and no oil remains in any areas. Store equipment properly and in proper location.	1	1	1
TRA Approval		Name	Position		Signature		Date			
By signing, the Approver confirms that the TRA has been reviewed and considers the task acceptable to proceed with residual risk meeting the acceptance criteria of DO Risk Matrix.										

*Reference DO-HSE-FRM-140 for DeepOcean Risk Assessment Matrix (RAM) and Guidewords