# Atlanta\_Eff\_ExtrmSum\_RB\_2004\_TypOcc\_TypBehav\_NoTES\_09242022\_082224\_Fail

# Fail

24-Jul-2024

## **Commuication delay: Pass (evaluated period: 0:01-24:00)**

Maximum delay: 72.229 sec Average delay: 25.0291 sec

## Simulation data completeness: Pass

SimData: 1441

Measurements: 1441 OccupantMatrix: 1441 SupvCtrlSig: 1441 EPlusOutput: 2880

#### Hardware missing data: Pass

random missing: Pass continuous missing: Pass

# Emulation accuracy: Fail (evaluated period: 0:01 - 24:00)

# T\_z emulation: Warning

Criteria: RMSE <= 0.44 °C

RMSE: 1.0681 °C NRMSE: 0.040518

Simulated Mean: 26.3617 °C Emulated Mean: 26.2414 °C

## T\_out emulation: Fail

Criteria: RMSE <= 0.44 °C

RMSE: 1.1727 °C NRMSE: 0.040226

Simulated Mean: 29.1534 °C Emulated Mean: 29.0956 °C

## Td\_z emulation: Warning

Criteria: RMSE <= 0.44 °C

RMSE: 1.4244 °C NRMSE: 0.094713

Simulated Mean: 15.0387 °C Emulated Mean: 14.3524 °C

#### h\_sen\_out emulation (hourly): Warning

hour # w/ significant errors: 1 2 9

significant errors: -9.117 3.615 -0.517%

#### Qtot\_z emulation (hourly): Pass

hour # w/ significant errors:


significant errors: %

#### System performance: Pass (evaluated period: 0:01 - 24:00)


#### zone temperature control: Pass

Zone temperature is 1 °C higher than the setpoint for 19 timesteps Zone temperature is 1 °C lower than the setpoint for 0 timesteps


# Plots communication delay




T\_z emulation




Td\_z emulation




# **T\_out emulation**




# **Qsen\_z** emulation




## Qlat\_z emulation




# Qtot\_z emulation




Qsen\_z load emulation error




Qlat\_z load emulation error




## Qtot\_z load emulation error




# **Qsen\_z** emulation (hourly)




## Qlat\_z emulation (hourly)




## **Qtot\_z** emulation (hourly)




## **Qsen\_zemulation significant %error**




# **Qlat\_zemulation significant %error**




## **Qtot\_zemulation significant %error**




T\_z control




## personal fan power



# personal heater power



## **HVAC** power



# total power

