Cgmx Reference Manual: An Overture Solver for Maxwell's Equations on Composite Grids

William D. Henshaw Department of Mathematical Sciences, Rensselaer Polytechnic Institute, Troy, NY, USA, 12180. February 6, 2016

Abstract:

Cgmx is a program that can be used to solve the time-dependent Maxwell's equations of electromagnetics on composite overlapping grids in two and three space dimensions. This document is a companion to the Cgmx User Guide. This reference guide provides additional details about the equations and approximations used along with additional examples and numerical results.

Contents

5.1 Perfect electric 5.2 Engquist-Majd 5.3 Perfectly match 5.3.1 PML ed	of far field boundary conditions for scattering from a PEC cylinder	9
4 Accuracy and con 4.1 A comparison of 5 Boundary Condit. 5.1 Perfect electric 5.2 Engquist-Majd 5.3 Perfectly match 5.3.1 PML ed	of far field boundary conditions for scattering from a PEC cylinder	6 7 9
 4.1 A comparison of 5 Boundary Condit 5.1 Perfect electric 5.2 Engquist-Majd 5.3 Perfectly match 5.3.1 PML ed 	of far field boundary conditions for scattering from a PEC cylinder	7
5.1 Perfect electric 5.2 Engquist-Majd 5.3 Perfectly match 5.3.1 PML ed	al conductor boundary condition	
5.3.2 PML co	a absorbing boundary conditions	9 9 10
6 Computing the m	agnetic field and intensity from a time harmonic electric field	12
7 Maxwell's Equation	ons	14
8 Acknowledgments		14
A.2 Second-order a A.3 Fourth-order a A.4 Absorbing bour	ary Conditions a one-way wave equations	16 16 16

1 Introduction

Cgmx is a program that can be used to solve Maxwell's equations of electromagnetics on composite overlapping grids [?]. It is built upon the **Overture** framework [?],[?],[?].

For an introduction to Cgmx and its usage see the Cgmx User Guide [?]

More information about **Overture** can be found on the **Overture** home page, http://www.llnl.gov/casc/-Overture.

2 Method NFDTD

3 Method Yee

4 Accuracy and convergence examples

In this section we provide some examples that demonstrate the accuracy of the methods.

4.1 A comparison of far field boundary conditions for scattering from a PEC cylinder

In this example we compare the accuracy of different far-field boundary conditions for the scattering of a plane wave from a PEC cylinder.

(1) Generate the grid using the command file cicArg.cmd in Overture/sampleGrids:

```
ogen -noplot cicArg -order=4 -interp=e -factor=4
```

(2) Run cgmx with the Engquist-Majda BC abcEM2 and the PML BC abcPML:

```
cgmx -noplot cic.planeWaveBC -g=cice4.order4.hdf -diss=.5 -ic=zero -rbc=abcEM2 ...
    -tp=1. -tf=100. -show="cylEM2.show"

cgmx -noplot cic.planeWaveBC -g=cice4.order4.hdf -diss=.5 -ic=zero -rbc=abcPML ...
    -pmlWidth=21 -pmlStrength=50. -tp=1. -tf=100. -show="cylPML.show"
```

(3) To plot errors use plotStuff to display the show file. Plot the "sequence" with the errors and then save to a matlab file.

```
plot sequence:errors
  add Ey_error
  add Hz_error
  save results to a matlab file
   scatCyl.m
```




Figure 1: abcEM2: scattering of a plane wave by a PEC cylinder. Errors in E_y at t=2., 4. and 6.0.




Figure 2: abcPML: scattering of a plane wave by a PEC cylinder. Errors in E_y t = 2, 4 and 6.

Figures 1-2 shows the errors in E_y for the EM2 and PML farfield conditions. Figure 3 shows the maximum errors over time for the two conditions.

Notes:

1. The initial conditions are taken as zero with inhomogeneous boundary conditions on the cylinder boundary.




Figure 3: Scattering of a plane wave by a PEC cylinder. Errors over time for abcEM2 (left) and abcPML (right).

- 2. The errors are initially large as the exact solution develops and propagates outward from the cylinder. These initial large errors can be seen in the plots at t = 2.
- 3. The EM2 errors show a fast growth for long times, except for the error in H_z . The H_z field seems to propagate more strongly in the x- and y- directions (rather than along diagonals) and thus will be treated more accurately by the far field conditions. The PML errors do not grow as fast but eventually seem to start to grow.

5 Boundary Conditions

5.1 Perfect electrical conductor boundary condition

The perfect electrical conductor boundary condition sets the tangential components of the electric field to zero

$$\boldsymbol{\tau}_m \cdot \mathbf{E} = 0, \quad \text{for } \mathbf{x} \in \partial \Omega_{\text{pec}}.$$
 (1)

Here τ_m , m = 1, 2, denote the tangent vectors to the boundary surface, $\partial \Omega_{\rm pec}$.

5.2 Engquist-Majda absorbing boundary conditions

The boundary condition abcEM2 uses the Engquist-Majda absorbing boundary condition (defined here of a boundary x = constant),

$$\partial_t \partial_x u = \alpha \partial_x^2 u + \beta (\partial_y^2 + \partial_z^2) u \tag{2}$$

With $\alpha = c$ and $\beta = \frac{1}{2}c$, this gives a *second-order accurate* approximation to a pseudo-differential operator that absorbs outgoing traveling waves. Here u is any field which satisfies the second-order wave equation.

Notes on the Engquist-Majda absorbing boundary conditions can be found in Appendix A.

5.3 Perfectly matched layer boundary condition

The boundary condition abcPML imposes a perfectly matched layer boundary condition. With this boundary condition, auxiliary equations are solved over a layer (of some number of specified grid points) next to the boundary. The PML equations we solve are those suggested in Hagstrom [?] and given by (defined here of a boundary x = constant), (*check me*)

$$u_{tt} = c^2 \left(\Delta u - \partial_x v - w \right), \tag{3}$$

$$v_t = \sigma(x)(-v + \partial_x u),\tag{4}$$

$$w_t = \sigma(x)(-w - \partial_x v + \partial_x^2 u). \tag{5}$$

Here u is any field which satisfies the second-order wave equation and v and w are auxillary variables that only live in the layer domain. The PML damping function $\sigma_1(\xi)$ is given by

$$\sigma(\xi) = a\xi^p \tag{6}$$

where a is the strength, p is the power and where ξ varies from 0 to 1 through the layer.

A second-order accurate approximation to equations (3)-(5) is

$$\frac{u_{\mathbf{i}}^{n+1} - 2u_{\mathbf{i}}^n + u_{\mathbf{i}}^{n-1}}{\Delta t} = c^2 \left(\Delta_{2h} u_{\mathbf{i}} - D_{0x} v_{\mathbf{i}} - w_{\mathbf{i}} \right),\tag{7}$$

$$\frac{v_{\mathbf{i}}^{n+1} - v_{\mathbf{i}}}{\Delta t} = \frac{3}{2} f_{\mathbf{i}}^{n} - \frac{1}{2} f_{\mathbf{i}}^{n-1},\tag{8}$$

$$f_{\mathbf{i}}^n = \sigma(-v_{\mathbf{i}}^n + D_{0x}u_{\mathbf{i}}^n), \tag{9}$$

$$\frac{w_{\mathbf{i}}^{n+1} - w_{\mathbf{i}}}{\Delta t} = \frac{3}{2}g_{\mathbf{i}}^{n} - \frac{1}{2}g_{\mathbf{i}}^{n-1},\tag{10}$$

$$g_{\mathbf{i}}^{n} = \sigma(-w_{\mathbf{i}}^{n} - D_{0x}v_{\mathbf{i}}^{n} + D_{+x}D_{-x}u_{\mathbf{i}}^{n}).$$
(11)

Here we have used a centered in time approximation for the first equation and Adams-Bashforth for the v and w equations.

Aside: Since $\sigma(\mathbf{x})$ is large we could use an integrating factor for the v and w equations and instead solve

$$\partial_t(e^{\sigma t}v) = \sigma e^{\sigma t}\partial_x u,\tag{12}$$

$$\partial_t(e^{\sigma t}v) = \sigma e^{\sigma t}(\partial_x v + \partial_x^2 u). \tag{13}$$

A fourth-order accurate approximation to (3)-(5) can be determined using the relations

$$\frac{u_{\mathbf{i}}^{n+1} - 2u_{\mathbf{i}}^n + u_{\mathbf{i}}^{n-1}}{\Delta t^2} = \partial_t^2 u + \frac{\Delta t^2}{12} \partial_t^4 u + \mathcal{O}(\Delta t^4)$$

$$\tag{14}$$

$$=c^{2}\left(\Delta u-\partial_{x}v-w\right)+\frac{\Delta t^{2}}{12}\left(\Delta\partial_{t}^{2}u-\partial_{t}^{2}\partial_{x}v-\partial_{t}^{2}w\right),\tag{15}$$

$$=c^{2}\left(\Delta u-\partial_{x}v-w\right)+\frac{\Delta t^{2}}{12}\left(c^{2}\left(\Delta^{2}u-\partial_{x}\Delta v-\Delta w\right)-\partial_{t}^{2}\partial_{x}v-\partial_{t}^{2}w\right),\tag{16}$$

$$v_{\mathbf{i}}^{n+1} = v_{\mathbf{i}}^{n} + \Delta t \partial_{t} v + \frac{\Delta t^{2}}{2} \partial_{t}^{2} v + \frac{\Delta t^{3}}{3!} \partial_{t}^{3} v + \frac{\Delta t^{4}}{4!} \partial_{t}^{4} v + \mathcal{O}(\Delta t^{5})$$

$$\tag{17}$$

$$w_{\mathbf{i}}^{n+1} = w_{\mathbf{i}}^{n} + \Delta t \partial_{t} w + \frac{\Delta t^{2}}{2} \partial_{t}^{2} w + \frac{\Delta t^{3}}{3!} \partial_{t}^{3} w + \frac{\Delta t^{4}}{4!} \partial_{t}^{4} w + \mathcal{O}(\Delta t^{5})$$

$$\tag{18}$$

By taking derivatives of the governing equations (3)-(5) we can approximate the various terms in the previous expansions. For example,

$$\partial_t^2 v = \sigma(x)(-\partial_t v + \partial_t \partial_x u), \tag{19}$$

$$\partial_t^3 v = \sigma(x)(-\partial_t^2 v + \partial_t^2 \partial_x u), \tag{20}$$

$$= \sigma(x) \Big(-\partial_t^2 v + c^2 \partial_x (\Delta u - \partial_x v - w) \Big)$$
 (21)

$$\partial_t \partial_x v = \sigma(x)(-\partial_x v + \partial_x^2 u) + \partial_x \sigma(-v + \partial_x u), \tag{22}$$

$$\partial_t^2 \partial_x v = \sigma(x)(-\partial_t \partial_x v + \partial_t \partial_x^2 u) + \partial_x \sigma(-\partial_t v + \partial_t \partial_x u), \tag{23}$$

We obtain second-order approximations for $\partial_t u$, $\partial_t \partial_x u$ and $\partial_t \partial_x^2 u$ from the following approximation to $\partial_t u$,

$$\partial_t u = \frac{u_i^n - u_i^{n-1}}{\Delta t} - \frac{\Delta t}{2} \partial_t^2 u + \mathcal{O}(\Delta t^2)$$
 (24)

(25)

5.3.1 PML edge regions

In the edge region outside an x and y boundary, we solve

$$u_{tt} = c^2 \left(\Delta u - \partial_x v^x - w^x - \partial_y v^y - w^y \right), \tag{26}$$

$$v_t^x = \sigma(x)(-v^x + \partial_x u), \tag{27}$$

$$w_t^x = \sigma(x)(-w^x - \partial_x v^x + \partial_x^2 u), \tag{28}$$

$$v_t^y = \sigma(y)(-v^y + \partial_y u), \tag{29}$$

$$w_t^y = \sigma(y)(-w^y - \partial_y v^y + \partial_y^2 u). \tag{30}$$

Thus we require 4 auxiliary variables in the edge region. A second-order accurate approximation can be otained in a similar manner to (7)-(11).

A fourth-order accurate approximation follows the procedure used to develop (14)-(18).

$$\frac{u_{\mathbf{i}}^{n+1} - 2u_{\mathbf{i}}^n + u_{\mathbf{i}}^{n-1}}{\Delta t^2} = \partial_t^2 u + \frac{\Delta t^2}{12} \partial_t^4 u + \mathcal{O}(\Delta t^4)$$
(31)

$$= c^2 \left(\Delta u - \partial_x v^x - w^x - \partial_y v^y - w^y \right) + \frac{\Delta t^2}{12} \left(\Delta \partial_t^2 u - \partial_t^2 \partial_x v^x - \partial_t^2 w^x - \partial_t^2 \partial_y v^y - \partial_t^2 w^y \right), \tag{32}$$

$$=c^{2}\left(\Delta u-\partial_{x}v^{x}-w^{x}-\partial_{y}v^{y}-w^{y}\right)$$
(33)

$$+\frac{\Delta t^2}{12} \left(c^2 \left(\Delta^2 u - \partial_x \Delta v^x - \Delta w^x - \partial_y \Delta v^y - w^y \right) - \partial_t^2 \partial_x v^x - \partial_t^2 w^x - \partial_t^2 \partial_y v^y - \partial_t^2 w^y \right), \tag{34}$$

NOTE: Currently the PML edge and corner regions are only approximated to 2nd order for the 4th-order version.

5.3.2 PML corner regions

In the corner region outside an x, y and z boundary we use 6 auxillary variables and solve

$$u_{tt} = c^2 \Big(\Delta u - \partial_x v^x - w^x - \partial_y v^y - w^y - \partial_z v^z - w^z \Big), \tag{35}$$

$$v_t^x = \sigma(x)(-v^x + \partial_x u), \tag{36}$$

$$w_t^x = \sigma(x)(-w^x - \partial_x v^x + \partial_x^2 u), \tag{37}$$

$$v_t^y = \sigma(y)(-v^y + \partial_y u), \tag{38}$$

$$w_t^y = \sigma(y)(-w^y - \partial_y v^y + \partial_y^2 u), \tag{39}$$

$$v_t^z = \sigma(z)(-v^z + \partial_z u), \tag{40}$$

$$w_t^z = \sigma(z)(-w^z - \partial_z v^z + \partial_z^2 u). \tag{41}$$

6 Computing the magnetic field and intensity from a time harmonic electric field

For time harmonic solutions we can easily compute the magnetic field given the electric field and its time derivative (or the electric field at two times). Thus we can compute the intensity given the electric field without having to explicitly solve Maxwell's equations for the magnetic field.

Consider a (complex valued) time harmonic solution to Maxwell's equations,

$$\widetilde{\mathbf{E}}(\mathbf{x}, t) = e^{-i\omega t} \widehat{\mathbf{E}}(\mathbf{x}),$$

$$\widetilde{\mathbf{H}}(\mathbf{x}, t) = e^{-i\omega t} \widehat{\mathbf{H}}(\mathbf{x}),$$

where the real and imaginary parts of $\hat{\mathbf{E}}$ and $\hat{\mathbf{H}}$ are denoted as

$$\widehat{\mathbf{E}}(\mathbf{x}) = \widehat{\mathbf{E}}_r(\mathbf{x}) + i\widehat{\mathbf{E}}_i(\mathbf{x}),$$

$$\widehat{\mathbf{H}}(\mathbf{x}) = \widehat{\mathbf{H}}_r(\mathbf{x}) + i\widehat{\mathbf{H}}_i(\mathbf{x}).$$

We actually compute the real part of $\widetilde{\mathbf{E}}$ and $\widetilde{\mathbf{H}}$,

$$\mathbf{E}(\mathbf{x},t) = \Re\{(\cos(\omega t) - i\sin(\omega t))(\widehat{\mathbf{E}}_r + i\widehat{\mathbf{E}}_i)\}\$$

$$= \cos(\omega t)\widehat{\mathbf{E}}_r + \sin(\omega t)\widehat{\mathbf{E}}_i$$

$$\mathbf{H}(\mathbf{x},t) = \cos(\omega t)\widehat{\mathbf{H}}_r + \sin(\omega t)\widehat{\mathbf{H}}_i$$

From the time harmonic form of Maxwell's equations

$$-i\omega\epsilon\widehat{\mathbf{E}} = \nabla \times \widehat{\mathbf{H}},$$
$$i\omega\mu\widehat{\mathbf{H}} = \nabla \times \widehat{\mathbf{E}},$$

we obtain the relation for $(\hat{\mathbf{H}}_r, \hat{\mathbf{H}}_i)$ in terms of $(\hat{\mathbf{E}}_r, \hat{\mathbf{E}}_i)$

$$\omega \mu \widehat{\mathbf{H}}_r = \nabla \times \widehat{\mathbf{E}}_i, \tag{42}$$

$$-\omega \mu \hat{\mathbf{H}}_i = \nabla \times \hat{\mathbf{E}}_r. \tag{43}$$

Thus if we know $(\widehat{\mathbf{E}}_r, \widehat{\mathbf{E}}_i)$, we can determine **H**. Given the computed solution for the electric field at two times,

$$\mathbf{E}(\mathbf{x}, t_1) = \cos(\omega t_1) \hat{\mathbf{E}}_r + \sin(\omega t_1) \hat{\mathbf{E}}_i,$$

$$\mathbf{E}(\mathbf{x}, t_2) = \cos(\omega t_2) \hat{\mathbf{E}}_r + \sin(\omega t_2) \hat{\mathbf{E}}_i,$$

we can solve for $(\widehat{\mathbf{E}}_r, \widehat{\mathbf{E}}_i)$,

$$\widehat{\mathbf{E}}_r(\mathbf{x}) = \left(\sin(\omega t_2) \mathbf{E}(\mathbf{x}, t_1) - \sin(\omega t_1) \mathbf{E}(\mathbf{x}, t_2) \right) / \sin(\omega (t_2 - t_1)), \tag{44}$$

$$\widehat{\mathbf{E}}_{i}(\mathbf{x}) = \left(-\cos(\omega t_{2})\mathbf{E}(\mathbf{x}, t_{1}) + \cos(\omega t_{1})\mathbf{E}(\mathbf{x}, t_{2})\right) / \sin(\omega(t_{2} - t_{1})). \tag{45}$$

Given $(\widehat{\mathbf{E}}_r, \widehat{\mathbf{E}}_i)$ we can compute $(\widehat{\mathbf{H}}_r, \widehat{\mathbf{H}}_i)$ from (42)-(43). Thus we can compute $\mathbf{H}(\mathbf{x}, t)$ given \mathbf{E} at two times. The intensity is given by

$$\mathcal{I} = \frac{1}{P} \int_0^P \frac{1}{2} c\epsilon |\mathbf{E}|^2 + \frac{1}{2} c\mu |\mathbf{H}|^2 dt,$$

where P is the period. Now we could compute the intensity from the electric field and magnetic field values determined above,

$$\frac{1}{P} \int_0^P |\mathbf{E}|^2 dt = \frac{1}{P} \int_0^P |\cos(\omega t) \widehat{\mathbf{E}}_r + \sin(\omega t) \widehat{\mathbf{E}}_i|^2 dt$$
$$= \frac{1}{2} \left(|\widehat{\mathbf{E}}_r|^2 + |\widehat{\mathbf{E}}_i|^2 \right)$$

and thus the intensity can be computed using

$$\mathcal{I} = \frac{1}{4}c\epsilon \left(|\widehat{\mathbf{E}}_r|^2 + |\widehat{\mathbf{E}}_i|^2 \right) + \frac{1}{4}c\mu \left(|\widehat{\mathbf{H}}_r|^2 + |\widehat{\mathbf{H}}_i|^2 \right), \tag{46}$$

$$= \frac{1}{4}c\epsilon \left(|\widehat{\mathbf{E}}_r|^2 + |\widehat{\mathbf{E}}_i|^2 \right) + \frac{1}{4} \frac{c}{\mu\omega^2} \left(|\nabla \times \widehat{\mathbf{E}}_i|^2 + |\nabla \times \widehat{\mathbf{E}}_r|^2 \right), \tag{47}$$

Alternatively, knowing **E** and $\nabla \times \mathbf{E}$, we could compute the intensity by the time average

$$\mathcal{I} = \frac{1}{P} \int_0^P \frac{1}{2} c\epsilon |\mathbf{E}|^2 + \frac{1}{2} c\mu |\mathbf{H}|^2 dt,$$
$$= \frac{1}{P} \int_0^P \frac{1}{2} c\epsilon |\mathbf{E}|^2 + \frac{1}{2} \frac{c}{\mu \omega^2} |\nabla \times \mathbf{E}|^2 dt,$$

which follows from (47).

Here is the suggested approach for computing the intensity whenever it is needed for output. Given $\mathbf{E}(\mathbf{x},t)$ at times $t_2 = t$, and the previous time $t_1 = t - \Delta t$,

- 1. Compute $\widehat{\mathbf{E}}_r(\mathbf{x})$ and $\widehat{\mathbf{E}}_i(\mathbf{x})$ from (44)-(45).
- 2. Compute $\nabla \times \widehat{\mathbf{E}}_r(\mathbf{x})$ and $\nabla \times \widehat{\mathbf{E}}_i(\mathbf{x})$ by difference approximation.
- 3. Compute \mathcal{I} from (47).

Approach 2: If we know **H** as well as **E** then we can compute $\widehat{\mathbf{H}}_r(\mathbf{x})$ and $\widehat{\mathbf{H}}_i(\mathbf{x})$ (following (44)-(45)) and then use (46) without the need to compute $\nabla \times \widehat{\mathbf{E}}_r(\mathbf{x})$ etc.

7 Maxwell's Equations

The time dependent Maxwell's equations for linear, isotropic and non-dispersive materials are

$$\partial_t \mathbf{E} = \frac{1}{\epsilon} \nabla \times \mathbf{H} - \frac{1}{\epsilon} \mathbf{J},\tag{48}$$

$$\partial_t \mathbf{H} = -\frac{1}{\mu} \nabla \times \mathbf{E},\tag{49}$$

$$\nabla \cdot (\epsilon \mathbf{E}) = \rho, \quad \nabla \cdot (\mu \mathbf{H}) = 0, \tag{50}$$

Here $\mathbf{E} = \mathbf{E}(\mathbf{x}, t)$ is the electric field, $\mathbf{H} = \mathbf{H}(\mathbf{x}, t)$ is the magnetic field, $\rho = \rho(\mathbf{x}, t)$ is the electric charge density, $\mathbf{J} = \mathbf{J}(\mathbf{x}, t)$ is the electric current density, $\epsilon = \epsilon(\mathbf{x})$ is the electric permittivity, and $\mu = \mu(\mathbf{x})$ is the magnetic permeability. This first-order system for Maxwell's equations can also be written in a second-order form. By taking the time derivatives of (49) and (48) and using (50) it follows that

$$\epsilon \mu \ \partial_t^2 \mathbf{E} = \Delta \mathbf{E} + \nabla \left(\nabla \ln \epsilon \ \cdot \mathbf{E} \right) + \nabla \ln \mu \times \left(\nabla \times \mathbf{E} \right) - \nabla \left(\frac{1}{\epsilon} \rho \right) - \mu \partial_t \mathbf{J}, \tag{51}$$

$$\epsilon \mu \ \partial_t^2 \mathbf{H} = \Delta \mathbf{H} + \nabla \left(\nabla \ln \mu \ \cdot \mathbf{H} \right) + \nabla \ln \epsilon \times \left(\nabla \times \mathbf{H} \right) + \epsilon \nabla \times \left(\frac{1}{\epsilon} \mathbf{J} \right). \tag{52}$$

It is evident that the equations for the electric and magnetic field are decoupled with each satisfying a vector wave equation with lower order terms. In the case of constant μ and ϵ and no charges, $\rho = \mathbf{J} = 0$, the equations simplify to the classical second-order wave equations,

$$\partial_t^2 \mathbf{E} = c^2 \Delta \mathbf{E}, \qquad \partial_t^2 \mathbf{H} = c^2 \Delta \mathbf{H}$$
 (53)

where $c^2 = 1/(\epsilon \mu)$. There are some advantages to solving the second-order form of the equations rather than the first-order system. One advantage is that in some cases it is only necessary to solve for one of the variables, say **E**. If the other variable, **H** is required, it can be determined by integrating equation (49) as an ordinary differential equation with known **E**. Alternatively, as a post-processing step **H** can be computed from an elliptic boundary value problem formed by taking the curl of equation (48). Another advantage of the second-order form, which simplifies the implementation on an overlapping grid, is that there is no need to use a staggered grid formulation. Many schemes approximating the first order system (49-50) rely on a staggered arrangement of the components of **E** and **H** such as the popular Yee scheme [?] for Cartesian grids.

8 Acknowledgments

Thanks to Kyle Chand who contributed to parts of Cgmx. Thanks to Tom Hagstrom for contributing some far field boundary condition routines.

This work was performed under the auspices of the U.S. Department of Energy (DOE) by Lawrence Livermore National Laboratory under Contract DE-AC52-07NA27344 and by DOE contracts from the ASCR Applied Math Program.

A Absorbing Boundary Conditions

In this section we discuss absorbing boundary conditions (ABC's).

A.1 Engquist-Majda one-way wave equations

Consider the wave equation

$$u_{tt} = u_{xx} + u_{yy} + u_{zz}$$

We consider a boundary at x = 0. The wave equation can be formally factored using pseudo-differential operators

$$(D_x - D_t \sqrt{1 - S^2})(D_x + D_t \sqrt{1 - S^2}) = 0$$

where

$$S^2 = (D_y^2 + D_z^2)/D_t^2$$

The operator $G^- = D_x - D_t \sqrt{1 - S^2}$ only supports waves moving to the left. Applying G^- to a wave function U will absorb waves moving to left (at any angle). To see this consider a wave that moves in the negative x-direction

$$U(\mathbf{x},t) = e^{i(\mathbf{k}\cdot\mathbf{x} + \omega t)}$$

with $k_x > 0$ and $\omega = \sqrt{\mathbf{k} \cdot \mathbf{k}} > 0$. In Fourier space

$$\mathcal{F}{G^-U} = ik_x - i\omega\sqrt{1 - (k_y^2 + k_z^2)/\omega^2}$$
$$= ik_x - i\sqrt{\omega^2 - k_y^2 + k_z^2}$$
$$= ik_x - i|k_x|$$
$$= 0$$

thus giving $D_t G^- U = 0$.

We will apply $G^- = D_x - D_t \sqrt{1 - S^2}$ as a non-reflecting boundary condition. If applied exactly it will absorb (treat exactly without reflection) all outgoing plane waves. It will not handle evanescent modes.

Aside: Evanescent waves When a plane wave hits a material interface there will be a reflected wave and a refracted wave (transmitted wave). If the refracted ray bends toward the normal we have what is called external reflection. If it bends away from the normal it is called internal reflection. At a critical angle θ_c the refracted wave is parallel to the interface. For angles greater than θ_c there is no refracted wave and we have total internal reflection. There is however an evanescent wave that travels parallel to the boundary and decays exponentially into the second medium. The evanescent wave ensures that the tangential component of the electric field is continuous across the interface.

If the wave approaching the boundary is nearly normal incidence then $k_x^2 \gg k_y^2 + k_z^2$ and thus

$$\widehat{S^2} = (k_y^2 + k_z^2)/\omega^2 = (k_y^2 + k_z^2)/(k_x^2 + k_y^2 + k_z^2) \ll 1$$

Thus S^2 is thought of as being small and we approximate

$$\sqrt{1-S^2} \approx p_0 + p_2 S^2$$

Whence

$$D_t G^- \approx D_t D_x - D_t^2 (p_0 + p_2 S^2)$$

$$\approx D_t D_x - p_0 D_t^2 - p_2 (D_y^2 + D_z^2)$$

$$= D_t D_x - p_0 D_x^2 - (p_0 + p_2) (D_y^2 + D_z^2)$$

For $p_0 = 1$, $p_2 = -1/2$ this gives the approximate (second-order) Engquist-Majda ABC,

$$L_2^{em} u = \partial_t \partial_x u - \partial_t^2 u + \frac{1}{2} (\partial_y^2 + \partial_z^2) u = 0$$

$$= \partial_t \partial_x u - \partial_x^2 u - \frac{1}{2} (\partial_y^2 + \partial_z^2) u = 0$$
(54)

which is exact for waves impinging on the boundary in the normal direction (angle of incidence of zero). Mur's scheme is a discretization of the above BC – Mur centered his scheme at $t + \Delta/2$ and $\Delta x/2$ to give a second order approximation using only two time levels.

We can use a better approximation

$$\sqrt{1 - S^2} \approx \frac{p_0 + p_2 S^2}{q_0 + q_2 S^2}$$

This give a third-order boundary condition

$$L_3^{em} u = \partial_x (q_0 \partial_t^2 + q_2 (\partial_y^2 + \partial_z^2)) - \partial_t (p_0 \partial_t^2 + p_2 (\partial_y^2 + \partial_z^2))$$

$$\tag{56}$$

$$= q_0 \partial_x \partial_t^2 + q_2 \partial_x (\partial_y^2 + \partial_z^2) - p_0 \partial_t^3 - p_2 \partial_t (\partial_y^2 + \partial_z^2)$$

$$(57)$$

Engquist and Majda suggested $p_0 = q_0 = 1$ and $p_2 = -3/4$, $q_2 = -1/4$ which is the Padé approximation (minimizing the error near S = 0.

Trefethen and Halpern considered other possibilities such as a Chebyshev or least squares. One could choose the coefficients to make the approximation exact at other angles.

A.2 Second-order accurate discretization

Consider Engquist-Majda ABC,

$$\partial_t \partial_x u = \alpha \partial_x^2 u + \beta (\partial_y^2 + \partial_z^2) u \tag{58}$$

where, for example $\alpha = c$ and $\beta = \frac{1}{2}c$, will give a second-order accurate approximation. We can discretize this equation with the centered second-order accurate approximation

$$D_0^t D_0^x U_{ij}^n = \alpha D_+^x D_-^x U_{ij}^n + \beta (D_+^y D_-^y + D_+^z D_-^z) U_{ij}^n$$
(59)

This equation will give the ghost point value U_{-1j}^{n+1} given interior and boundary values at time t^{n+1} and old values at time t^n .

Here is another second-order approximation, centred at $t^{n+\frac{1}{2}}$ that uses only two time levels,

$$D_{+}^{t}D_{0}^{x}U_{ij}^{n} = \mathcal{A}_{+}^{t} \left(\alpha D_{+}^{x}D_{-}^{x}U_{ij}^{n} + \beta (D_{+}^{y}D_{-}^{y} + D_{+}^{z}D_{-}^{z})U_{ij}^{n} \right)$$

$$(60)$$

$$\mathcal{A}_{+}^{t} f^{n} = \frac{1}{2} (f^{n+1} + f^{n}) \tag{61}$$

The value at the ghost point U_{-1j}^{n+1} in equation (60) can be explicitly solved for given interior and boundary values at time t^{n+1} and old values at time t^n .

This gives the approximation

$$\left(\frac{1}{2\Delta t \Delta x} + \frac{\alpha}{2\Delta x^2}\right) U_{-1j}^{n+1} = D_+^t D_0^x U_{ij}^n + \frac{1}{2\Delta t \Delta x} U_{-1j}^{n+1}$$
(62)

$$-\mathcal{A}_{+}^{t}\left(\alpha D_{+}^{x}D_{-}^{x}U_{ij}^{n}-\beta(D_{+}^{y}D_{-}^{y}+D_{-}^{z}D_{-}^{z})U_{ij}^{n}\right)+\frac{\alpha}{2\Delta x^{2}}U_{-1j}^{n+1}$$
(63)

or

$$\left(1 + \alpha \frac{\Delta t}{\Delta x}\right) U_{-1j}^{n+1} = 2\Delta t \Delta x \left[D_{+}^{t} D_{0}^{x} U_{ij}^{n} + \frac{1}{2\Delta t \Delta x} U_{-1j}^{n+1} \right]$$
(64)

$$- \mathcal{A}_{+}^{t} \left(\alpha D_{+}^{x} D_{-}^{x} U_{ij}^{n} - \beta (D_{+}^{y} D_{-}^{y} + D_{+}^{z} D_{-}^{z}) U_{ij}^{n} \right) + \frac{\alpha}{2\Delta x^{2}} U_{-1j}^{n+1}$$
 (65)

Note: The right-hand-side of the above expression does not depend on U_{-1i}^{n+1} .

A.3 Fourth-order accuracy

For fourth-order accuracy we have two ghost points and need an additional numerical boundary condition. We could use the normal derivative of one of the above approximations,

$$\partial_x L_2^{em} u = D_t D_x^2 - p_0 D_x^3 - (p_0 + p_2) D_x (D_y^2 + D_z^2)$$

It might be appropriate to use the first order approximation $L_1^{em} = \partial_t - \partial_x$ times the second-order

$$L_1^{em} L_2^{em} u = (\partial_t - \partial_x) \left[D_t D_x - p_0 D_x^2 - (p_0 + p_2) (D_y^2 + D_z^2) \right]$$

A.4 Absorbing boundary conditions on a curvilinear grid

Consider a rotated rectangular grid. The wave equation in transformed coordinates is

$$u_{tt} = (r_x^2 + r_y^2 + r_z^2)u_{rr} + (s_x^2 + s_y^2 + s_z^2)u_{ss} + \dots$$

= $D_n^2 u + \Delta_\tau u$
 $D_n = \|\nabla_{\mathbf{x}} r\|\partial_r$

where D_n is the normal derivative to a boundary r = const. Following the same argument as before we can derive the (second-order) Engquist-Majda ABC as

$$\partial_t D_n u = \alpha D_n^2 u + \beta \Delta_\tau u$$

Now consider a general curvilinear grid. The wave equation in transformed coordinates is

$$u_{tt} = Lu$$

$$= (r_x^2 + r_y^2 + r_z^2)u_{rr} + (s_x^2 + s_y^2 + s_z^2)u_{ss} + 2(r_x s_x + r_y s_y + r_z s_z)u_{rs}$$

$$+ (r_{xx} + r_{yy} + r_{zz})u_r + (s_{xx} + s_{yy} + s_{zz})u_s + \dots$$

$$= D_n^2 u + \Delta_\tau u$$

$$D_n = \|\nabla_{\mathbf{x}} r\| \partial_r$$

$$\Delta_\tau = (L - D_r^2)u$$

where we have arbitrarily chosen D_n to be an approximation to the normal derivative. This gives the ABC

$$\partial_t D_n u = \alpha D_n^2 u + \beta \Delta_\tau u$$

which may reasonably accurate for a nearly orthogonal grid.

A more accurate approximation for non-orthogonal grids could be to set D_n to the actual normal derivative:

$$D_n = \mathbf{n} \cdot \nabla = \frac{\nabla_{\mathbf{x}} r}{|\nabla_{\mathbf{x}} r|} \cdot \nabla_{\mathbf{x}}$$
$$= |\nabla_{\mathbf{x}} r| \partial_r + (\mathbf{n} \cdot \nabla s) \partial_s$$

A.5 Non-reflecting Boundary Conditions and Incident Fields

The non-reflecting boundary conditions were derived assuming that there are no incoming waves, just waves leaving the domain. We can treat the case of an incident field arriving from outside the computational domain in a couple of ways.

Approach I: In this approach we write the total electric field in the neighbourhood of the boundary as the sum of a given incident field $\mathbf{E}^{i}(\mathbf{x},t)$ and a scattered field $\mathbf{E}^{s}(\mathbf{x},t)$,

$$\mathbf{E}(\mathbf{x},t) = \mathbf{E}^{i}(\mathbf{x},t) + \mathbf{E}^{s}(\mathbf{x},t) .$$

We assume that the incident field is an exact solution of Maxwell's equations near the boundary. We can apply the non-reflecting boundary condition to $\mathbf{E}^{s}(\mathbf{x},t)$ by subtracting $\mathbf{E}^{i}(\mathbf{x},t)$ from the total field. In the discrete case, at each time step we can subtract $\mathbf{E}^{i}(\mathbf{x},t)$ from $\mathbf{E}(\mathbf{x},t)$ on a few points near the boundary, apply the NRBC, and then add back $\mathbf{E}^{i}(\mathbf{x},t)$.

Approach II: In this approach we change the NRBC or ABC to account for the incident field. Given the NRBC,

$$\mathcal{L}\mathbf{E}^s = 0,\tag{66}$$

by substituting $\mathbf{E}^{s}(\mathbf{x},t) = \mathbf{E}(\mathbf{x},t) - \mathbf{E}^{i}(\mathbf{x},t)$ we get the new condition for the total field

$$\mathcal{L}\mathbf{E} = \mathcal{L}\mathbf{E}^i \tag{67}$$

For example,

$$\partial_t \partial_x \mathbf{E} - \left(\alpha \partial_x^2 \mathbf{E} + \beta (\partial_y^2 + \partial_z^2) \mathbf{E} \right) = \partial_t \partial_x \mathbf{E}^i - \left(\alpha \partial_x^2 \mathbf{E}^i + \beta (\partial_y^2 + \partial_z^2) \mathbf{E}^i \right)$$
(68)

Note: We could potentially set the RHS to $G^-\mathbf{E}^i$ if $\mathcal{L} \approx G^-$.