Config File Structures / Layout

Name	Len	Example Data			
File Header	9 Bytes	RLVB3iCFG			
Endian Signature	UINT16	0xAA55		Or 0x55AA	
Version code	UINT16			Currently 0x0000	
Structures in File	UINT32		Bit fields	Comments	0x01
				ADAS_SingleLane	0x02
				ADAS_CornerInfo	0x03
				ADAS_StaticPoints	0x04
				ADAS_ContactPointsSubject	0x05
				ADAS_ContactPointsTarget1	0x06
				ADAS_ContactPointsTarget2	0x07
				RobotVehicoSettings	0x08
				ADAS_ContactPointsTarget3	0x09

Structure Type				
Comments	UINT32	0x0000001		
	UINT16		String Len	
	N Bytes		String	
	UINT16		String Len	
	N Bytes		String	
ADAS_SingleLane	UINT32	0x00000002		
	UINT16		String Len	
	N Bytes		String	Friendly name of structure
	UINT16		Size	
	UINT32		Lane Type	
	N Bytes		Lane Definition	See lane definition structures
ADAS_CornerInfo	UINT32	0x00000003		
	UINT16		String Len	
	N Bytes		String	
	UINT16		Size	
	Corner_t		Front Left	
	Corner_t		Front Right	
	Corner_t		Rear Left	
	Corner_t		Rear Right	

ADAS StaticPoints	UINT32	0x00000004		
ADAS_Statici Oilits	UINT16	000000004	String Len	
	N Bytes		String	
	UINT16		Size	
	UINT32		Lane Type	
	UINT32		Points Held	
	ADAS_RawPoint_t		Reference Point	
	StaticPoint_Settings_t		Reference Form	Settings
	N * StaticPoint_t			N is from Points Held
	N StaticPoint_t			N IS HOTH POINTS HEID
ADAS_ContactPointsSubject	UINT32	0x00000005		
7.57.6_00.1140ti. 0.111504.5ject	UINT16	0.0000000	String Len	
	N Bytes		String	
	UINT16		Size	
	UINT32		Lane Type	
	UINT32		Points Held	
	ADAS_RawPoint_t		Reference Point	
	ContactPointsSettings_t		Reference Form	
	24 * ADAS_RawPoint_t			
	24 * ADAS_RawFoint_t			
	24 ADA3_FOIIIL_t			
ADAS_ContactPointsTarget1	UINT32	0x00000006		
	UINT16		String Len	
	N Bytes		String	
	UINT16		Size	
	UINT32		Lane Type	
	UINT32		Points Held	
	ADAS_RawPoint_t		Reference Point	
	ContactPointsSettings_t			
	24 * ADAS_RawPoint_t			
	24 * ADAS_Point_t			
	21 715/15_1 51115_6			
ADAS_ContactPointsTarget2	UINT32	0x00000007		
	UINT16		String Len	
	N Bytes		String	
	UINT16		Size	
	UINT32		Lane Type	
	UINT32		Points Held	
	ADAS_RawPoint_t		Reference Point	
	ContactPointsSettings_t			
	24 * ADAS_RawPoint_t			
	24 * ADAS_Point_t			

RobotVehicoSettings	UINT32	0x00000008	
	UINT16		String Len
	N Bytes		String
	UINT16		Size
	ADAS_RawPoint_t		Reference Point
	FLOAT32		Heading
ADAS_ContactPointsTarget3	UINT32	0x00000009	
	UINT16		String Len
	N Bytes		String
	UINT16		Size
	UINT32		Lane Type
	UINT32		Points Held
	ADAS_RawPoint_t		Reference Point
	ContactPointsSettings_t		
	24 * ADAS_RawPoint_t		
	24 * ADAS_Point_t		

Lane Type Values		
0x2222222	ADAS_ExternalObjectType_MutilStaticPoint	
0x5555555	ADAS_ExternalObjectType_Lane_Simple	
0x88888888	ADAS_ExternalObjectType_ACSF	
0xAAAAAAA	ADAS_ExternalObjectType_Lane_Complex	
0xCCCCCCC	ADAS_ExternalObjectType_VSep_Polygon	
0xFFFFFFF	ADAS_ExternalObjectType_Unknown	

ADAS_ExternalObjectType_Lane_Simple		
ADAS_RawPoint_t	Lane Point 1	
ADAS_RawPoint_t	Lane Point 2	
ADAS_RawPoint_t	Lane Point 3	
ADAS_RawPoint_t	Lane Point 4	
ADAS_RawPoint_t	Lane Point 5	
ADAS_RawPoint_t	Lane Point 6	
ADAS_RawPoint_t	Lane Point 7	
ADAS_RawPoint_t	Lane Point 8	

ADAS_ExternalObjectType_ACSF		
ADAS_RawPoint_t	Lane Point 1	
ADAS_RawPoint_t	Lane Point 2	
ADAS_RawPoint_t	Lane Point 3	
ADAS_RawPoint_t	Lane Point 4	
ADAS_RawPoint_t	Lane Point 5	
ADAS_RawPoint_t	Lane Point 6	
ADAS_RawPoint_t	Lane Point 7	
ADAS_RawPoint_t	Lane Point 8	

ADAS_ExternalObjectType_Lane_Complex		
UINT32	Point Held	
ADAS_RawPoint_t	Reference Point	
Lane Information	N * ADAS Point t	N is value from Points Held

```
Structure definitions
```

```
struct _ADAS_RawPoint_t {
         FLOAT64 LatRad;
         FLOAT64 LngRad;
         FLOAT64 Alt;
struct _ADAS_Point_t {
         FLOAT32 xLng;
         FLOAT32 yLat;
         FLOAT32 zUp;
         FLOAT32 Heading;
struct _Corner_t {
         FLOAT32 Width;
         FLOAT32 Length;
         FLOAT32 Height;
struct _ StaticPoint_Settings_t {
         FLOAT32 LNG_Offset;
         FLOAT32 LAT_Offset;
         FLOAT32 Max_Distance;
         FLOAT32 Min_Distance;
         FLOAT32 Start_Angle;
         FLOAT32 End_Angle;
struct _StaticPoint_t {
         FLOAT32 Point1_Easing;
         FLOAT32 Point1_Northing;
         FLOAT32 Point1_Up;
         FLOAT32 Point2_Easing;
         FLOAT32 Point2_Northing;
         FLOAT32 Point2_Up;
         FLOAT32 Angle;
struct _ContactPointsSettings_t {
         ADAS_Point_t
                            Point1;
         ADAS_Point_t
                            Point2;
         ADAS_RawPoint_t
                           ANT_A;
         ADAS_RawPoint_t
                           ANT_B;
```