

DROIDLINK QUICK START

# MagicPanel Setup & Install

A simple guide to installing, configuring,  
and connecting your MagicPanel

# 1. What You Need

---

- Your MagicPanel controller and LED matrix
- A USB **data** cable
- A computer with a compatible browser
- The DroidLink Installer
- The Wi-Fi MAC address of your DroidLink Master

**Power:** use the correct regulated power supply for the LED matrix. Large matrices should not be powered directly from a computer USB port unless the hardware is specifically designed for it.

## 2. Install the Firmware

---

1. Connect the MagicPanel controller to the computer with the USB data cable.
2. Open **DroidLink Installer**.
3. Select the serial/COM port for the ESP32-C3 controller.
4. Select **DroidLink MagicPanel** from the firmware list.
5. Start the installation and approve the browser's serial-port request if prompted.
6. Wait until the Installer reports that flashing is complete. Do not disconnect the controller during installation.

After installation, open the Installer's **Console** and set it to **9600 baud**.

## 3. Enter the Master MAC

---

When the console displays `MAGICPANEL FIRST-TIME SETUP`, paste the Wi-Fi MAC address of your DroidLink Master and press **Enter**.

Example format:  
`XX:XX:XX:XX:XX:XX`

Use your own Master's MAC address. MagicPanel saves it and immediately continues to Device ID setup.

## 4. Enter the Device ID

---

When prompted, enter an unused DroidLink Device ID from **2 through 13**.

Example:  
12

Master ID 0 and Display ID 1 are reserved. Every configured DroidLink device must have its own unique ID. MagicPanel saves the ID and continues to Matrix Profile setup.

## 5. Select the Matrix Profile

---

When prompted, enter the number matching your LED matrix:

| Enter | Matrix profile               |
|-------|------------------------------|
| 1     | 8×15 — 120 LEDs, progressive |
| 2     | 8×8 — 64 LEDs, progressive   |
| 3     | 4×8 — 32 LEDs, serpentine    |

After the profile is saved, setup is complete and MagicPanel performs one automatic reboot. The normal boot output displays the saved Device ID and Matrix profile.

## 6. Add MagicPanel to the Master

---

If the panel has not connected after about 15 seconds, the Console displays **Waiting for Master** and shows the MagicPanel's own **Device MAC**.

1. Copy the displayed MagicPanel Device MAC.
2. Add that MAC and the chosen Device ID to the DroidLink Master configuration.
3. Save the Master configuration.
4. Reboot the DroidLink Master.

**Connected:** the MagicPanel Console displays **DroidLink Connected** and **MagicPanel Online** when communication begins.

## 7. Quick Test

---

First select timed mode, then run the test:

:MPP0

:MPT56,10,C2

The MagicPanel should run pattern 56 (Animated Heart) for 10 seconds in blue. In always-on mode ( :MPP1), the heart continues instead of timing out.

# Status LED and Device Identification

The onboard status LED turns on during first-time setup. During normal operation, press the MagicPanel's matching **DEVICE ID** button on the Watch Display Settings screen to light the status LED briefly and confirm that the selected device received the identification command.

**Normal commands:** MagicPanel effect and text commands do not flash the status LED.

## Quick Troubleshooting

| Problem                  | Check                                                                                                                               |
|--------------------------|-------------------------------------------------------------------------------------------------------------------------------------|
| No serial/COM port       | Try another USB data cable or USB port. Close other programs using the serial port.                                                 |
| No Console output        | Select the correct port and set the Console to 9600 baud. Reconnect or press the controller reset button.                           |
| Master MAC rejected      | Use six hexadecimal pairs separated by colons: XX:XX:XX:XX:XX:XX .                                                                  |
| Waiting for Master       | Confirm the correct Master MAC was entered. Add the MagicPanel Device MAC and Device ID to the Master, save, and reboot the Master. |
| Display looks wrong      | Confirm that the selected matrix profile matches the connected matrix.                                                              |
| Panel flickers or resets | Check the power supply, wiring, connectors, and common ground.                                                                      |

## Setup Checklist

- MagicPanel firmware installed through DroidLink Installer
- Console opened at 9600 baud
- DroidLink Master MAC saved
- Unique Device ID saved
- Correct matrix profile selected
- MagicPanel Device MAC added to the Master
- Master configuration saved and Master rebooted
- Timed mode selected with :MPP0
- Test command :MPT56,10,C2 completed successfully

**Need the full command list?** See the separate *DroidLink MagicPanel Command Reference*.