

DROIDLINK COMMANDS

MagicPanel Command Reference

DroidLink command syntax, examples,
patterns, colors, text, and settings

Commands-only edition • MagicPanel command engine v2.6 • August 2026

1. The DroidLink Command Format

`:MPT56,10,C2`

This is a complete DroidLink MagicPanel command. In **timed mode**, it means: run **pattern 56** for **10 seconds** using **color 2 (blue)**.

Part	Meaning
:	Starts a DroidLink command.
MP	Routes the command to the MagicPanel device type.
T56	Runs MagicPanel pattern 56 (Animated Heart).
,10	Runs it for 10 seconds.
,C2	Uses preset color 2, Blue.

Use the full DroidLink form: commands in this guide begin with `:MP` . Pattern options are separated with commas.
Example: `:MPT62,30,C5` .

Basic formula

```
:MP + MAGICPanel command

:MPT<pattern>
:MPT<pattern>,<seconds>
:MPT<pattern>,C<color>
:MPT<pattern>,<seconds>,C<color>
```

Pattern examples

DroidLink command	Result
<code>:MPT56</code>	Run Animated Heart.
<code>:MPT56,10</code>	Run Animated Heart for 10 seconds.
<code>:MPT56,C2</code>	Run Animated Heart in blue.
<code>:MPT56,10,C2</code>	Run Animated Heart for 10 seconds in blue.
<code>:MPT62,30,C5</code>	Run Matrix Rain for 30 seconds in cyan.
<code>:MPT109,20,C0</code>	Run PSI Random Flicker for 20 seconds in red.

Set timed mode first: send `:MPP0` before using a duration. In always-on mode (`:MPP1`), a continuous pattern such as Animated Heart continues instead of timing out. Duration must be 1–3600 seconds; color must be 0–9.

2. Pattern and Display Commands

DroidLink command	Purpose	Example
<code>:MPT<n></code>	Run pattern n.	<code>:MPT57</code>
<code>:MPS<n></code>	Alternate pattern prefix; same result as T.	<code>:MPSS7</code>
<code>:MPT<n>,<seconds></code>	Run for a chosen duration.	<code>:MPT57,30</code>
<code>:MPT<n>,C<color></code>	Run with a preset color.	<code>:MPT57,C1</code>
<code>:MPT<n>,<seconds>,C<color></code>	Run with duration and color.	<code>:MPT56,10,C2</code>
<code>:MPDEMO</code>	Run Smart Demo, pattern 200.	<code>:MPDEMO</code>
<code>:MP!</code>	Cancel the current animation and clear the panel.	<code>:MP!</code>
<code>:MPA</code> or <code>:MPON</code>	Turn all LEDs on.	<code>:MPON</code>
<code>:MPD</code> or <code>:MPOFF</code>	Turn all LEDs off.	<code>:MPOFF</code>

3. Color Commands

DroidLink command	Purpose	Example
<code>:MPC<n></code>	Set preset color 0–8; 9 selects rainbow.	<code>:MPC2</code>
<code>:MPC<r>,<g>,</code>	Set a custom RGB color; each value is 0–255.	<code>:MPC255,80,0</code>

Number	Color	Number	Color	Number	Color
0	Red	1	Green	2	Blue
3	White	4	Yellow	5	Cyan
6	Magenta	7	Orange	8	Purple
9	Rainbow				

`:MPT56,10,C2` uses preset 2 (blue). To set a custom color separately, use a command such as `:MPC25,100,255`.

4. Brightness, Speed, and Mode

DroidLink command	Range / result	Example
:MPB<n>	Brightness from 0 to 255.	:MPB100
:MPV<n>	Animation speed from 1 to 100.	:MPV60
:MPSP<n>	Alternate speed command, 1 to 100.	:MPSP60
:MPP0	Timed mode. Required when a continuous pattern should stop after its supplied duration.	:MPP0
:MPP1	Always-on mode. Continuous patterns keep running instead of timing out.	:MPP1
:MPTRANSITION0	Disable smooth transitions.	:MPTRANSITION0
:MPTRANSITION1	Enable smooth transitions.	:MPTRANSITION1

High brightness increases current demand. If the panel flickers or resets, reduce brightness and check the power supply.

5. Text Commands

Text may contain up to 48 characters. Saved-text slots are numbered 0–9.

DroidLink command	Result
:MPTEXT:HELLO THERE	Scroll "HELLO THERE."
:MPTEXT_BOUNCE:R2-D2	Display bouncing "R2-D2" text.
:MPTEXTSAVE0:HELLO	Save "HELLO" in slot 0.
:MPTEXTLOAD0	Load and scroll the text saved in slot 0.
:MPFONT0	Use the standard font.
:MPFONT1	Use the Aurebesh font.

6. Saving, Startup, and Information

DroidLink command	Result
:MPSAVE	Save current panel settings permanently.
:MPLOAD	Reload previously saved settings.
:MPAUTOSAVE0	Disable automatic saving.
:MPAUTOSAVE1	Enable automatic saving and save current settings.
:MPSTART<n>	Set fixed startup pattern n and save it immediately.
:MPSTART0	Clear fixed startup pattern; resume the last saved pattern.
:MPSTATUS	Print current brightness, color, mode, speed, font, startup pattern, transitions, autosave, and last pattern to the panel console.
:MPHELP	Print the quick help menu to the panel console.
:MPHELP FULL	Print extended device help to the panel console.
:MPLIST	Print the complete pattern list to the panel console.

Example: create and save a normal operating setup

```
:MPC5
:MPB100
:MPV50
:MPTRANSITION1
:MPT57
:MPSAVE
```

7. Recovery Commands

DroidLink command	Result
:MPNEWMAC	Clear the stored Master MAC and reboot into Master MAC setup.
:MPNEWPROFILE	Clear the matrix profile and reboot into profile selection.

After `:MPNEWMAC`, DroidLink control cannot resume until the Master MAC is entered again through the panel's USB setup console. Recovery commands should normally be entered directly at the device when its Master connection is unavailable.

Temporary playlist

`:MPPLAYLIST_RUN:57,62,109` runs the listed patterns in sequence. Playlist save/load is not implemented.

8. Complete Pattern Numbers

ID	Pattern
0	Off
1	On Indefinite
2	On 2s
3	On 5s
4	On 10s
5	Toggle
6	Alert 4s
7	Alert 10s
8	Trace Up Fill
9	Trace Up Line
10	Trace Down Fill
11	Trace Down Line
12	Trace Right Fill
13	Trace Right Line
14	Trace Left Fill
15	Trace Left Line
16	Expand Fill
17	Expand Ring
18	Compress Fill
19	Compress Ring
20	Cross
21	Cylon Column
22	Cylon Row
23	Eye Scan
24	Fade Out/In
25	Fade Out
26	Flash All
27	Flash Vertical
28	Flash Quadrants
29	Two Loop
30	One Loop
31	Test Fill

32	Test Pixel
33	AI Logo
34	2GWD Logo
35	Quadrant TL→TR→BR→BL
36	Quadrant TR→TL→BL→BR
37	Quadrant TR→BR→BL→TL
38	Quadrant TL→BL→BR→TR
39	Random Pixel
40	Countdown 9–0
41	Countdown 3–0
42	Alert Random 4s
43	Alert Random 8s
44	Sad Face
45	Smiley Face
46	Heart
47	Checkerboard

ID	Pattern
48	Compress In Fill
49	Compress In Clear
50	Explode Out Fill
51	Explode Out Clear
52	VU Meter Columns Up
53	VU Meter Rows Left
54	VU Meter Columns Down
55	VU Meter Rows Right
56	Animated Heart
57	Rainbow Cycle
58	Fire Effect
59	Twinkle
60	Plasma
61	Game of Life
62	Matrix Rain
63	3D Cube
64	Kaleidoscope
65	Raindrops
66	Drip Effect
67	Pac-Man
68	Space Invaders
80	Bouncing Text
97	Scroll Text (English)
98	Scroll Text (Aurebesh)
99	Test All Patterns
100	PSI Solid Red
101	PSI Solid Blue
102	PSI Solid Green
103	PSI Solid Yellow
104	PSI Solid Cyan
105	PSI Solid Magenta
106	PSI Solid White
107	PSI Color Wipe Down

108	PSI Color Wipe Up
109	PSI Random Flicker
110	PSI Pulse
111	PSI Rainbow
112	PSI March Horizontal
113	PSI March Vertical
114	PSI March Diagonal
115	PSI March Checkerboard
116	PSI March Spiral
117	R2-D2 Communication
118	R2-D2 Thinking
119	R2-D2 Alert
200	Smart Demo

To run any pattern, place its number after :MPT . Examples: :MPT45 , :MPT68,15 , or :MPT117,20,C2 .

9. Quick Copy-and-Send Examples

Command	What it does
:MPT56,10,C2	Animated Heart, 10 seconds, blue.
:MPT58,20,C7	Fire Effect, 20 seconds, orange.
:MPT62,30,C1	Matrix Rain, 30 seconds, green.
:MPT109,15,C0	PSI Random Flicker, 15 seconds, red.
:MPT117,20,C2	R2-D2 Communication, 20 seconds, blue.
:MPB80	Set brightness to 80.
:MPV60	Set animation speed to 60.
:MPC0	Set red.
:MPC0,180,255	Set custom cyan-blue RGB color.
:MPTEXT:HELLO THERE	Scroll HELLO THERE.
:MPDEMO	Start Smart Demo.
:MP!	Stop and clear the current animation.
:MPOFF	Turn the display off.
:MPSAVE	Save current settings.

If a command does not work

- Confirm it begins with `:MP`.
- Do not insert spaces inside pattern commands.
- Use commas between pattern, seconds, and color: `:MPT56,10,C2`.
- Confirm the pattern number exists and is supported by the selected matrix profile.
- Confirm the MagicPanel is paired with the correct DroidLink Master MAC.
- Confirm the correct MagicPanel Device ID is configured in the Master.