KNT-213640 (HAB350-56S(Z)) JOY TEXTILES, 大身/前襠/前襠內層口袋/夾襪片(前後左右-雙層布 共4片). 84%Polyester 16%E;astane, 可裁寬 60"-直裁

HOCKEY &

0.000

NATURAL SIDE SEAM 補口

- 種口完成高 3/4"

接合處壓 1/4" 套結。

留1/8" 毛邊

- 反折壓面壓 1/4" 山本雙針;

KNT-202243 (HABMT051-00S(Z)) /JOY TEXTILES --後育克/襠底片(雙層), 88% Polyester/12% Elastane, 可裁-52"(直裁) (B)布

STYLE:

一般做工要求

- 1.所有說明均為穿著時.
- 2.成衣左右須對稱.
- 3. 所有設計線/細節均需適當放縮, 除非有特別說明.
- 4. COMPRESSION款式,交疊處需用百向套結 & 留1/8"毛邊
- 5. 每吋針數: 針密 16~18 SPI

--腰頭緊帶 (EL-102503, 2" 寬 UA文字緊帶, LH)


腰頭緊帶後中接合車1/8" 3線考克接合平均撥開, **爬網面貼皮膚, 撥開後寬度** 為1/4". 針密36 針;上端距腰頂端1/8"處打橫向1/4"寬套結固定,下端在後中 三本三針接縫處打直向1/4"寬套結固定. 緊帶後中燙熱轉印標. 緊帶與褲身接合車山本三針(腰緊帶UA文字不需置中).

車線色:

1. 見製單

**請注意 607 併縫,外露面線改為包芯線(STEP024)

接合處皆為1/4"四針六線併縫,除非以下說明特別要求.





前檔&前襠內層口袋:

- -依以下頁前襠作工圖示進行。
- 前襠片底部(雙層)B 布。

Α

- 前襠內層口袋放入護具(有分尺寸) RM-210156 (TR310091) (尺寸: SM-MD) RM-210155 (TR310090) (尺寸: LG-XXL)

HOCKEY 14 HOCKE


HOCKEY HE HOCKE

夾襪片(前後左右-雙層布共4片): -請見下頁夾襪片作工說明

魔鬼氈:

- -HaL-100206 1/2"實 勾面 1片= 23/8" 長
- 毛面 1片 = 23/8" 長
- -HaL-100110 1"寬 (勾面 3片) 毛面 2片= 27/8" 長
- 毛面1片=23/8"長
- 1"實織帶 Tap-100457 對折夾車於夾襪片底部置中,

對折後高度3/8"。




織帶: Tap-100457 1"(寬) x 3/8"(長)

- -GR-F20-0147 (穿者右腿)
- -GR-F20-0148 (穿者左腿)

育克剪接處高度為 2.75"

- -穿者左腿及右腿尺寸: 3.94"W X 15"H (右腿/左腿 共2個花型)
- -印花品質: 透明矽利康 印花
- -位置: 距前中褲口往上 2.5"

(見下頁印花說明)



WVL-101468 UA長條熱轉印標

- -位置:後中緊帶接合處
- -尺寸: 51mm(H) X 18mm(W)

HS-105206 轉印尺寸/FIT/產地/GEAR標

- -位置: 穿者後中後育克併縫線中間,往下3/4" 處。
- -尺寸: 2.25" X 0.6"

洗標,28國語言可撕尺寸/產地洗標

-位置: 穿者左側, 距側縫 1",

請件下圖

COO-908013 (KIT 1/2) COO-904438 (KIT 3/5)

VID-905974

- -位置: 置中於 洗標下
- -尺寸: 16mm*32mm



HS-107297.

尺寸: 38MM X 22MM (1.5")

位置: 見尺寸表



包裝方式

主吊卡 - 吊於穿者左後內側後腰縫處(BTM3) -Avery #HT-904678, 1pc

插卡 Avery#HT-906685, 1pc

- #ST-908032, 1pcs
- -位置: 貼於主吊卡後

條碼貼紙: (KIT 1&3) #ST-908271 , 1pc

3" 子彈-吊卡用 & 前襠口袋固定用 -#TR0931. 2pc

單件袋-折後平包 -#TR0001, 1pc



Kit Published Date: 01/24/2020 10:50 AM 【前襠內層口袋作工】

依照以下圖片說明進行。

- 前襠底寬, 距前中各 1/2"寬; 打摺 (襠底布總寬為2"-併縫線中心量到併縫線中心), 打摺方向朝外。
- 前襠內層口袋, 反摺1"寬, 壓 1/8" 山本雙針。
- 口袋頂寬距離腰縫車線底為 1/2"高。

CUP POCKET CONSTRUCTION/VISUAL- INTERIOR VIEW

護具包裝方式:

護具內貼上VID標: VID-904484(工廠印), 置入前襠口袋,並以3"槍 針固定在拷克線上(上圖)。置入單件袋內(下圖)

VID-904484











【夾襪片作工說明及實樣照片】


依照以下魔鬼氈毛面/勾面的寬度(最頂端的魔鬼氈為毛面)。

- 前後左右大腿處共4片;雙層A布,包光。
- 魔鬼氈 用1/8" 單針平車固定於A布。
- 表布壓線方式如圖示 (請注意表層下半部的外圍壓線為雙平針)。
- 最底端置中處夾車 1"寬織帶,對折後高度 3/8"。



SOCK LOCK CONSTRUCTION DETAILS

SOCK LOCKS ARE MADE UP OF VELCRO, MANUALLY CUT TO THE DIMENSIONS AS PER SLETCH BELOW. VELCRO PIECES ARE SET TO A 2 PLY SELF FABRIC BASE. EDGES ARE CLEAN FINSHED ALL AROUND W/ 1/8" 1N 301.





印花:

-GR-F20-0147 (穿者右腿)


-GR-F20-0148 (穿者左腿)


尺寸: 3.94"W X 15"H (穿者右腿/左腿)

(共2個花型)

-印花品質:透明矽利康 印花

-位置: 距前中 褲口往上 2.5"





DATE:	2020/1/30
	Serena #2336

Status: Production Lifecycle: New		1356492 - Base Hockey Compression Legging				ason: FW2(gional Fit: US	1		
Gender	Mens	Fabric ID #	KNT-213640						200
Seasonal Plan	Mens Hockey	Fabric Description	Sonic - 5oz - Soli	d - AM					
Construction Group	KNIT COMPRESSION BOTTOMS	Vendor	RELIABLE SOUR	RCE INDUSTRIA	L			UUV	1 \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \
Product Family	Baselayer	Factory/Country	GREEN MEADO	W DEVELOPME	NT CAMBODIA	CO LTD /		101/	MH
Fit Type / Reference	Compression / 1357943/1317158 details	Sample Status	Production Appro	ved 1				W W 1.9	1/1-/
Development	UA Managed	Tech Designer	Kennedy, Christin	ne				8 8 U	N N
	, -								

代碼	部位	量法
WA025	腰寬	腰頭頂邊量
WA035	腰寬-最小拉量	腰縫量
HP020	臀圍位置	腰頭頂端至量點
HP025	臀圍	量點處側邊-前中-側邊三點量
HP030	前襠寬	腰縫量(平放量) 縫至縫
HP035	前襠總寬位置	從腰頂下至量點
HP040	前襠總寬	縫至縫
WC000	前襠底寬	車縫中間 量到 車縫中間
WC038	前檔高度	自緊帶頂量到襠底(車縫中間)平量
LG015	腿圍	檔底中間下 1" 量
LG035	膝圍位置	自檔底片中心至量點
LG040	膝圍	量點處量
LG065	褲口寬	邊到邊
LG090	褲口拉量	邊到邊拉伸量
DE141	下擺完成高	邊到邊
IO100	內長	自襠底片中心至褲口邊
RS025	前檔長	自腰頂至前襠底片縫
RS030	後檔長	自腰頂至後襠底片縫
RS035	檔底片寬	量襠底片前襠縫至後襠縫
RS040	檔底片長	量襠底片中心長-內長至內長
YK040	後育克高	至後中量後育克高度
WC000	夾襪片要置中於前	前片腿圍處
WC038	【前】夾襪片位 置(垂直)	自緊帶頂量到夾襪片頂端
WC038	【後】夾襪片位 置(垂直)	自緊帶頂量到夾襪片頂端
EM245	UA標位置(垂直)	自褲口往上量到標中心
WC000	UA標位置(水平)	內長量到印花中心

Code	Description	Tol(-)	Tol(+)	SM	MD	LG	XL	XXL
Compression Pant - Gusset - K2								
WA025	Waist Width at Edge - Relaxed	1/2	1/2	12	13	14 1/2	16	17 1/2
WA035	Waist Width at Seam - Minimum Stretch	0	0	19	20	21 1/2	23	24 1/2
HP020	Low Hip/Seat Placement from Top Edge	0	0	4 1/4	4 5/8	5	5 3/8	5 3/4
HP025	Low Hip/Seat - 3pt	1/2	1/2	14 1/4	15 1/4	16 3/4	18 1/4	19 3/4
HP030	Center Front Panel Width at Waist	1/8	1/8	4	4	4	4	4
HP035	Center Front Panel Width Placement from Top	0	0	5 1/4	5 5/8	6	6 3/8	6 3/4
HP040	Center Front Panel Width at placement	1/8	1/8	3 3/4	3 3/4	3 3/4	3 3/4	3 3/4
WC000	CF panel width at btm (a gusset seam)- ctr of stitch to ctr of stitch	1/8	1/8	2	2	2	2	2
WC038	CF panel height- at center- measure from top edge of WB to gusset seam (ctr of stitch)- MEASURE FLAT- DO NOT measure along CF curved seam	1/4	1/4	9 1/4	9 5/8	10	10 3/8	10 3/4
LG015	Thigh 1" from Center of Gusset	3/8	3/8	9 1/4	9 3/4	10 1/2	11 1/4	12
LG035	Knee Placement from Center of Gusset	0	0	10 7/8	10 7/8	10 7/8	10 7/8	10 7/8
LG040	Knee Width	3/8	3/8	5 3/4	6 1/8	6 3/4	7 3/8	8
LG065	Leg Opening at Edge - Relaxed (Pant)	3/8	3/8	3 3/8	3 5/8	4	4 3/8	4 3/4
LG090	Leg Opening at Seam/Stitch - Minimum Stretch (Pant)	0	0	6	6	6	6 3/8	6 3/4
DE141	Bottom Hem Height (Bottoms)	1/8	1/8	3/4	3/4	3/4	3/4	3/4
IO100	Inseam from Center of Gusset - Full Length	1/2	1/2	27 3/4	27 3/4	27 3/4	27 3/4	27 3/4
RS025	Front Rise with Gusset - from Top Edge to Gusset Seam	1/4	1/4	9 1/4	9 5/8	10	10 3/8	10 3/4
RS030	Back Rise with Gusset - from Top Edge to Gusset Seam	1/4	1/4	11	11 3/8	11 3/4	12 1/8	12 1/2
RS035	Gusset Width - Rise to Rise	1/4	1/4	2 3/4	2 3/4	2 3/4	2 3/4	2 3/4
RS040	Gusset Length - Inseam to Inseam	1/4	1/4	18	18	18	18	18
YK040	Yoke Height at CB (Bottoms)	1/4	1/4	1 1/4	1 1/4	1 1/4	1 1/4	1 1/4
WC000	SOCK LOCK SHOULD BE CENTERED ON LEG PANELS, AS SEEN ON SKETCH	1/8	1/8	0	0	0	0	0
WC038	Sock Lock placement- FRONT-vertical from top of WB, to edge of sock lock edge	1/4	1/4	7 5/8	8	8 3/8	8 3/4	9 1/8
WC038	Sock Lock placement- BACK- vertical from top of WB, to edge of sock lock edge	1/4	1/4	9 1/4	9 5/8	10	10 3/8	10 3/4
EM245	UA Logo - Vertical from Bottom to Center of logo- Back	1/8	1/8	10 1/4	10 1/4	10 1/4	10 1/4	10 1/4
WC000	UA Logo - Horizontal from Inseam to Center of logo	1/8	1/8	2 1/2	2 5/8	2 3/4	2 7/8	3

【產前樣 意見】

Kit Published Date: 01/24/2020 10:50 AM

- 1. **請注意 607 併縫,外露面線改為包芯線(STEP024)。請大貨修正。
- 2. 款式作工OK。
- 3. 夾襪片: 注意位置要正,, PPS位置偏低, 請符合尺寸表需求位置(量測時自腰頂 量到夾襪片頂端,不是夾襪片的織帶)。大貨請注意。
- 4. 印花位置 OK。
- 5. PPS 掛卡位置位置正確,大貨-護具請貼上VID-904484。
- 6. 請進行大貨。

Code	Description	Tol (+)	Tol (-)	Target Spec	Factory	UA	Revise To		
Compres	Compression Pant - Gusset - K2								
WA025	Waist Width at Edge - Relaxed	1/2	1/2	14 1/2	14 7/8	0	0		
WA035	Waist Width at Seam - Minimum Stretch	0	0	21 1/2	21 1/2	0	0		
HP020	Low Hip/Seat Placement from Top Edge	0	0	5	5	0	0		
HP025	Low Hip/Seat - 3pt	1/2	1/2	16 3/4	16 3/4	0	0		
HP030	Center Front Panel Width at Waist	1/8	1/8	4	4	0	0		
HP035	Center Front Panel Width Placement from Top	0	0	6	6	0	0		
HP040	Center Front Panel Width at placement	1/8	1/8	3 3/4	3 3/4	0	0		
WC000	CF panel width at btm (a gusset seam)- ctr of stitch to ctr of stitch	1/8	1/8	2	0	0	0		
WC038	CF panel height- at center- measure from top edge of WB to gusset seam (ctr of stitch)- MEASURE FLAT- DO NOT measure along CF curved seam	1/4	1/4	10	0	0	0		
LG015	Thigh 1" from Center of Gusset	3/8	3/8	10 1/2	10 1/8	0	0		
LG035	Knee Placement from Center of Gusset	0	0	10 7/8	10 7/8	0	0		
LG040	Knee Width	3/8	3/8	6 3/4	7	0	0		
LG065	Leg Opening at Edge - Relaxed (Pant)	3/8	3/8	4	4	0	0		
LG090	Leg Opening at Seam/Stitch - Minimum Stretch (Pant)	0	0	6	6	0	0		
DE141	Bottom Hem Height (Bottoms)	1/8	1/8	3/4	3/4	0	0		
IO100	Inseam from Center of Gusset - Full Length	1/2	1/2	27 3/4	27 5/8	0	0		
RS025	Front Rise with Gusset - from Top Edge to Gusset Seam	1/4	1/4	10	10 1/4	0	0		
RS030	Back Rise with Gusset - from Top Edge to Gusset Seam	1/4	1/4	11 3/4	12	0	0		
RS035	Gusset Width - Rise to Rise	1/4	1/4	2 3/4	2 7/8	0	0		
RS040	Gusset Length - Inseam to Inseam	1/4	1/4	18	18 1/8	0	0		
YK040	Yoke Height at CB (Bottoms)	1/4	1/4	1 1/4	1 1/4	0	0		
WC000	SOCK LOCK SHOULD BE CENTERED ON LEG PANELS, AS SEEN ON SKETCH	1/8	1/8	0	0	0	0		
WC038	Sock Lock placement- FRONT-vertical from top of WB, to edge of sock lock edge	1/4	1/4	8 3/8	0	0	0		
WC038	Sock Lock placement- BACK- vertical from top of WB, to edge of sock lock edge	1/4	1/4	10	10	0	0		
EM245	UA Logo - Vertical from Bottom to Center of logo- Back	1/8	1/8	10 1/4	10 1/8	0	0		
WC000	UA Logo - Horizontal from Inseam to Center of logo	1/8	1/8	2 3/4	2 3/4	0	0		







DATE: