
















Peripherals








Title STM32H7 Board		
Size	Number01	Revision01
Date:	5/11/2026	Sheet of Neural Nexus
File:	C:\Work\Altium\EDR\STM32H7 Board	3-00000 By Dulana Pitawaduge



STM32H7 Board[1A] USB1 DN USB_DN
STM32H7 Board[1B] USB1 DP USB_DP




Add the out net from the toggle switch here , to choose in between the USB power and the power from the Buck 24 to 5 or 12 to 5



Title POWER		
Size B	Number	Revision
Date: 5/11/2026	Sheet of	
File: C:\Work\Altium\EDR\POWER.SchDoc	Drawn By:	



Date:	5/11/2026	Sheet of
File:	C:\Work\Altium\EDR\MicroSD.SchDoc	Drawn By:



Title QSPI&SPI FLASH		
Size B	Number	Revision
Date: 5/11/2026	Sheet of	
File: C:\Work\Altium\EDR\QSPI&SPI.SchDoc	Drawn By:	