



Technical Quick Guides

Recording Mode for Mainstream and Sub Stream

Login on the NVR



Click the SETTING at the upper left corner of the screen and select STORAGE






On the Storage Tab select the Record Mode

Note:

Auto - Follow the Recording format set on Schedule.

Manual - Follow the Recording format for General recording

Off - Don't record anything.



Select the Recording you want for Mainstream and Sub stream and click Apply.