

Technical Quick Guides

How to disable or turn down siren chirps on remote arm/disarm

By default, arming/disarming a Bosch 2/3/4000 panel via remote operation (RF Key fob) will cause the panel to pulse output 1, which is generally used for sirens/speakers. As such, using remote operation typically causes the setup siren to chirp.

While this can be a useful indication that the remote operation was received by the panel, the chirp can be loud and irritating. Turning this chirp down (or off entirely) is frequently desired and this guide outlines how to do that.

Using text keypad IUI-SOL-TEXT:

Enter the Installer code then # to enter the installer menu.

Press 3 (System), 6 (System option 1), then 7 (Speaker beep volume).

The speaker beep volume can range from 0 (silent) to 15 (max volume) and is 13 by default. Enter your desired volume (or 0 to silence the chirps) then press #.

When leaving the installer menu, make sure to press # to Confirm to Save Parameter Changes.

Using icon keypad IUI-SOL-ICON:

Enter the Installer code (default is 1234) then # to enter the installer menu. The STAY and AWAY icons will flash to indicate Installer mode.

Enter 0491# to enter the Speaker Beep Volume location.

The speaker beep volume can range from 0 (silent) to 15 (max volume) and is 13 by default. The current volume will display on the screen (unless it's 0 in which case no numbers will display).

Enter your desired volume then * (STAY) to set the new volume.

Enter 960# to save changes and reset the system.