


## **Technical Quick Guides**

## **How to record Snapshot**

## Login to NVR




On the upper left side of the screen select the camera






Under camera select the Encode tab and select the Snapshot tab




Under the Snapshot section, select the camera you want to configure. In the "Type" field, choose either "Schedule" or "Event" based on your preference. For "Schedule," snapshots will be recorded regularly, while for "Event," snapshots will only be recorded when an event is triggered. After configuring, click "Apply" and return to the dashboard.






On the upper left side click setting and select the Storage



Under storage select the Record Mode, enable the Snapshot, and then click Apply





Under the storage select Schedule and click Snapshot.

On the Snapshot tab select the type of recording you want and click Apply

