


## **Technical Quick Guides**


## Setting up IR mode through a schedule

- Log into cameras IP address
- Go to the settings tab in the top right corner and once the menu drops down select camera.





- On the camera tab go to the image tab on the left-hand side
- Then click on Customized Scene
- Set the profile to Night.
- Click on the Day/Night tab underneath WB and above Illuminator on the right of the image.
- Change Mode to B/W
- Go to Illuminator tab underneath Day/Night
- Change mode to manual
- At the bottom click on Time Plan Settings





- Grab and hold time plan day to required time of finish
- Click Night and draw in the empty space (purple= night) then click apply

