


Technical Quick Guides


Adding PIR Peripheral on Dolynk Care

Open your Dolynk Care, click the Alarm hub you set up






On the Alarm Hub tab click the Add icon





Click the Add button on the upper left corner, select Add Peripheral





Scan the QR code of the PIR





Click the Next button






Continue the process and click Next






Click the Next button






Follow the Instructions on the screen first before clicking the Next button






Wait until it completes pairing





Continue the process and click the Done button





The Added PIR will appear on the device list of the alarm hub

Put the backplate of the PIR and Test the device

