



Technical Quick Guides

Adding IPC for IP Intercom System using Web Browser

Log in to the VTOs web browser




Click the Household Setting tab






Go to IPC settings then click the Modify icon to add the IPC details



Input the IPC details, IPC Name, IP Address, Username, Password, etc.

Click Save button after completing the details





IPC Parameters

Parameter -	Description &
IPC Name ₽	Enter the camera name as you want ₽
IP Addr. ₽	IPC's IP address ₽
Username ₽	The username and password for the web interface of IPC
Password .	
Port No.	Keep default value ₽
Protocol &	Select 'Local' for Dahua IPC; Select 'Onvif' for third party IPC
Stream &	Select 'Main' or 'Extra 1', the main stream has better image quality and it also costs more bandwidth.
Channel ¿	Define a channel for the device ₽
Device Type	Select 'IPC/NVR/HCVR/XVR' as the device type as added. Here is 'IPC'.