


## **Technical Quick Guides**


## **Adding Device to EzView**

Open EZTool and search for device. If device doesn't show up, click "Refresh" at the top of the EZTool

Click on the to goto the devices webpage



Once the webpage is open and log in using your username and password (default is user: admin pass: 123456)




Please contact your local Seadan store for more information & feedback



Once logged in click "Setup" at the top of the screen.

Once "Setup" is open go to Network tab on the lefthand side.


Then click "EZCloud"





Open the EZView app on mobile device.


In the top left corner click on the hamburger button (  $\blacksquare$  ) then select device





Select how to add device (can add the device through any of the methods)

For ease use "Scan". Scan the QR code on the web browser to add the device to the EZView app.





Either log into the device with the username and password or just click "Start Live View"

Then set device name and click "Login"

EZView is now logged in and the device is added

