

Technical Quick Guides

How to add custom audio on a TIOC Camera

Note: Before adding a custom audio, make sure that you already have an audio with these settings:

WAV File Mono


Bitrate: 128kbps / 256 kbps

Project Rate: 8000Hz

First Log in to Camera web interface.




At the upper right click the Home Icon






At the Home tab select Camera




At the camera tab, click the Audio section






At Audio tab Click the Alarm Tone section




On the Alarm tone section click the Add button







Add menu will pop-up, select the Upload section and browse the File of the Audio you want to upload.



Select the file of the Audio




After selecting the file, click Upload button





Operation successful will pop-up and the audio you add will appear on the list.


You can test it after successfully adding the audio.





Adding using NVR Interface

Login to NVR




Click the Arrow pointing to the Right to navigate on Audio






Click Audio Tab




On the File Management Tab select Remote for the Type






It will show you the list of audios that are built in on the camera, click the Select Audio File




Select the Audio File you want to add and click Open.





Select the last audio on the list and click the Apply button.



Wait until it successfully adds the audio you upload and test it.

