


# **Technical Quick Guides**

## **Face Recognition and Face Detection setup**

(Al by Recorder)

## Log in to the $\ensuremath{\mathbf{NVR}}$




#### Select the AI tab






### Under AI tab collapse Parameters Tab




Under Parameters tab click **Face Detection** → Select the **channel** of the camera you want to set up → check the **Enable** check box → Click **Apply button** 






Under Parameters tab click **Face Recognition** → Select the **channel** of the camera you want to set up → check the **Enable** check box → Click **Apply button** 




Collapse the Data base tab and click Face Database config → Click Add button






Enter the name you want for the database and click OK button




After adding on data base, it will show this and click details






## On details tab click Register




Add the details for the registration like picture, name, gender etc. and click OK button






After adding the data click the close button on the upper right corner of the screen



#### The screen shows this



You can also add data on data base at live view