


Technical Quick Guides


Adding PIR Peripherals on Alarm Hub using DMSS

Open the DMSS App and click the Alarm Hub you set up






Click the Peripheral and the + icon on the bottom





Or go back to the Main Device and slide the Alarm hub to the Right to show the Add Peripheral tab then click the + icon






Scan the QR code at the back of the PIR or manually Enter the SN





Click the Next button






Continue the process and click the Next button






Continue the process and click the Next button.






Follow the instructions on the screen before clicking the Next button.






Wait until it completes the pairing process.






Once completed click the Done button.






You can see the PIR device you add on the device tab, just slide the alarm to the right.






IF the PIR has camera attached you can add by clicking the PIR tab and click the Add camera button





Wait until it completes adding the camera





When completed click the Completed button and wait until it updates the icon on the DMSS.

Put back the back plate and Test the device.

