



Technical Quick Guides

TIOC Camera activates every time there's someone at front of the camera.

Login first on the NVR




Select the AI tab






Under Al tab expand the Parameters section




Under Parameters select the SMD tab.






Under SMD → uncheck the Camera Audio and → Warning Light and → click Apply button



Under IVS → uncheck the Camera Audio, → Light and → click Apply button



NOTE:

IVS and SMD are the one that control the warning light and audio of the TIOC camera