

Technical Quick Guides

Gallagher Controller Activation Guide

- 1. If the controller has been used previously, a reset must be performed. If the controller is brand new, step 1 can be skipped.
 - Flip dip switches 1,2,3 to ON position and power cycle the controller to perform a reset.
 - Wait for the controller to reset. This may take several minutes. The LED will move into a steady state (either 2, 3 or 5 flash pattern) when the reset is complete.
 - Flip dip switches 1,2,3 to OFF position and power cycle the controller.
 - Allow the controller for 7 minutes to fully boot up and connect to the internet. It is now ready to be configured via the Gallagher Installer Portal.




- 2. When purchasing a new Gallagher SMB kit, the buyer will be sent a link to the Gallagher training portal. Once the initial training has been completed, the buyer will be sent a link to join Gallagher Installer. Follow the instructions on the email to create your account.
- 3. Log into the Gallagher Installer app online.
 - Click ADD NEW SITE and enter the details of your site, the account holder, etc.



Site Name mm testing Timezone Australia/Victoria Country	
Timezone Australia/Victoria	
Australia/Victoria	
Country	*
AU	•
Address	
126 Fairbank Road	
City Region	
Clayton South Victoria	
Postal code	
3169	

CANCEL NEXT

 Once a site is created, add the controller to the site. Either click "Scan controller QR code" and scan the QR code on the controller or click "ASSIGN CONTROLLER" to enter the controller's ID manually.





• The controller ID will be listed under the QR code on the sticker of the controller.



- 4. The site is now created and will be in test mode.
- 5. Once you've added in all required users, hardware and areas (as well as optional monitoring center setup), you can click the activate site button to activate the site.