



## **Technical Quick Guides**

## Setting white balance on Dahua cameras

Log into the camera web browser



Go to Settings -> Camera -> Conditions -> WB



Please contact your local Seadan store for more information  $\&\, feedback$ 



- Choose which setting you would prefer (Auto, Indoor, Outdoor, ATW, Manual, Natural, Street Lamp)
- **Auto** (The system compensates WB according to color temperature)
- **Natural** (The system auto compensates WB to environments without artificial light to ensure color precision)
- **Street Lamp** (The system compensates to outdoor night scene to ensure color precision)
- **Outdoor** (The system auto compensates WB to most outdoor environments with natural or artificial light to ensure color precision)
- **Manual** (Configure red and blue manually; the system auto compensates WB according to color temperature)
- **Regional Custom** (The system compensates WB only to set area according to color temperature to ensure color precision)

