


# Honda Jazz GD 1.5L L15A1 2002 - 2008 Engine Management Wiring Diagram



### Honda Jazz GD 1.5L L15A1 2002 - 2008 **Engine Management Wiring Diagram** Suppressor Intrument Cluster Suppressor From Page 1 Wire Colour Legend Example of Wire Coding B/W **ECU -** DL Sky Blue - SB Light Green - LG Shield Wire ----Dark Green - DG From Page 1 Y/B Y/B G/Y B/Y Y/B From Page 1 J B/W B/W Relay To Starter I To Starter CVT Relay Relay Page 2 of 7 EMM002321






#### Honda Jazz GD 1.5L L15A1 2002 - 2008 **Engine Management Wiring Diagram** From Page 2 From Page 1 W W/L C116 Connector BR/B-B/Y B/Y Primary Charcoal Chanister Speed Valve Sensor From Page 1 ALT Knock Sensor G/B W/R W/G Manual Wire Colour Legend Example of Wire Coding B/W Brown - BR **-** DL Sky Blue - SB **ECU** Dark Blue Light Green - LG Gray - GR Dark Green - DG Orange - O Violet - V Shield Wire ----W/B R/W R/Y G/W R/G Y/R $\rightarrow$ T $\rightarrow$ To Page 6 6 A 3 A 2 2 2 1 Throttle **EGR** ECT MAP Position BR/B Sensor Y/R -

EMM002321

Page 5 of 7

# Honda Jazz GD 1.5L L15A1 2002 - 2008 Engine Management Wiring Diagram



# Honda Jazz GD 1.5L L15A1 2002 - 2008 Engine Management Wiring Diagram

