

5. Wiring Diagram

A: POWER SUPPLY ROUTING







No.	Load
MB-1	Power window circuit breaker
MB-2	Data link connector Engine control module
	Fuel pump relay
	Main relay
	OBD-II service connector
MB-3	Diode (Daytime running light) (Daytime run-
	ning light control module)
	Lighting switch
	Cruise control sub switch Horn switch
MB-5	Transmission control module
WID 5	AT shift lock control module
MB-6	Hazard switch
	Key warning switch
MB-7	Horn
MB-8	Headlight LH
	Combination meter
MB-9	Front fog light relay
	Front fog light switch Headlight RH
MB-10	A/C relay holder
SBF-7	ABS control module
	Combination meter
ALT-1	Daytime running light control module
	Check connector
IG	Combination meter
	Hazard switch
	Key warning module Mirror heater LH
	Mirror heater RH
	Power window relay
	Vehicle speed sensor
ST	Engine control module
	Interrupt relay
FB-1	ABS control module Main fan relay
FB-2	Parking switch
FB-3	Blower motor relay
FB-4	Front fog light relay
FB-5	ABS control module
FB-6	Stop light switch
FB-7	Seat heater/rear accessory power supply
FD-7	relay
FB-8	Keyless entry control module
FB-9	Airbag control module
FB-10	Airbag control module
FB-11	Engine control module
	Fuel pump relay Ignition coil
	Transmission control module
FB-12	Blower motor relay
	Mode control panel
	Rear defogger switch
FB-13	A/C relay
	Sub fan relay

No.	Load
	AT shift lock control module
FB-14	Back-up light switch (MT)
	Cruise control main switch
	Cruise control module
	Daytime running light control module
	Daytime running light relay
	Hi-beam relay
	Inhibitor switch (AT)
	Keyless entry control module
	Security control module
	Wiper deicer relay
	Wiper deicer timer
FB-15	Rear defogger switch
FB-16	Mirror heater relay
	Rear defogger
	Rear defogger switch
FB-17	Lighting switch
FB-18	Front fog light switch
FD-10	Parking switch
FB-19	Parking switch
LD-19	Security control module
FB-20	Illumination light
	Illumination control module
	Keyless entry control module
	Illumination light
FB-21	Illumination control module
	Keyless entry control module
FB-22	AT shift lock control module
	Front accessory power supply
	Remote control rearview mirror switch
	Seat heater/rear accessory power supply
	relay
 	Clock
FB-23	Noise killer
	Radio
	Front washer motor
	Front wiper motor
FB-24	Front wiper & washer switch
	Rear washer motor
	Rear wiper intermittent module
	Rear wiper motor
FB-25	Clock Combination meter
	Compass mirror
	Luggage room light
	Radio
1 0-23	Room light
	Security control module
	Spot light
	Trailer connector
FB-26	License plate light
	Tail light LH
	Tail light RH
	Trailer connector
ED 07	Front clearance light LH
FB-27	Front clearance light RH


No.	Load
FB-28	Combination meter Hazard switch Rear turn signal light LH Trailer connector Turn signal switch
FB-29	Front turn signal light LH
FB-30	Combination meter Hazard switch Rear turn signal light RH Trailer connector Turn signal switch
FB-31	Front turn signal light RH
FB-32	Wiper deicer relay

B: GROUND DISTRIBUTION







WIRING DIAGRAM




C: AIRBAG SYSTEM



D: AIR CONDITIONING SYSTEM







SU45-04B


SU45-04B


E: ANTI-LOCK BRAKE SYSTEM






F: A/T CONTROL SYSTEM







G: A/T SHIFT LOCK SYSTEM




H: AUDIO SYSTEM




I: CHARGING SYSTEM







J: COMBINATION METER



SU64-03

K: COMPASS MIRROR SYSTEM







SU97-01


SU97-01

L: CRUISE CONTROL SYSTEM




M: ENGINE ELECTRICAL SYSTEM







WIRING DIAGRAM




SU10-07C



N: FUEL GAUGE SYSTEM



O: HORN AND FRONT ACCESSORY POWER SUPPLY SYSTEM



SU74-02


(B167)


(B68) (Black)

(B62)

(1) 2 3 4 5 6 7 8 9 10 11 11 12 13 14 15 16 17 18 19 20 10


P: KEYLESS ENTRY AND SECURITY SYSTEM






SU77-02B


Q: LIGHTING SYSTEM (BACK-UP LIGHT)



MEMO:


R: LIGHTING SYSTEM (CLEARANCE LIGHT AND ILLUMINATION LIGHT)






S: LIGHTING SYSTEM (FRONT FOG LIGHT)

1. WITHOUT DRL MODEL




2. WITH DRL MODEL



T: LIGHTING SYSTEM (HEADLIGHT)


1. WITHOUT DRL MODEL




MEMO:


WIRING DIAGRAM

2. WITH DRL MODEL







SU18-02A




U: LIGHTING SYSTEM (IN COMPARTMENT)




V: LIGHTING SYSTEM (STOP LIGHT)




W: LIGHTING SYSTEM (TURN SIGNAL LIGHT AND HAZARD LIGHT)




X: MULTIPLE POWER SOCKET SYSTEM (OPTION)




Y: OIL PRESSURE AND TEMPERATURE GAUGE SYSTEM




Z: OUTSIDE TEMPERATURE DISPLAY SYSTEM







AA: PARKING BRAKE AND BRAKE FLUID LEVEL WARNING SYSTEM




MEMO:

AB: POWER WINDOW SYSTEM







AC: RADIATOR FAN SYSTEM



AD: REAR ACCESSORY POWER SUPPLY SYSTEM




AE: REAR WINDOW DEFOGGER SYSTEM




SU52-03


AF: REMOTE CONTROLLED REARVIEW MIRROR SYSTEM



AG: SEAT BELT WARNING AND KEY WARNING SYSTEM




AH: SEAT HEATER SYSTEM




R42 R43 (Blue) R41 (Blue) R44 (Blue) SU84-02 1 2 3 4 5 6 7 8 9 10 1 11 12 13 14 15 16 17 18 19 20 10


SU84-02

AI: STARTER SYSTEM



AJ: SUNROOF SYSTEM







SU75-01

SU75-01


AK: TRAILER WIRE HARNESS (OPTION)



AL: WIPER AND WASHER SYSTEM (FRONT)



AM: WIPER AND WASHER SYSTEM (REAR)



AN: WIPER DEICER SYSTEM

SU78-01

WIRING DIAGRAM

MEMO: