EECS 151/251A FPGA Lab

Lab 5: AC97 (Audio) Controller and FPGA - IC Communication

Prof. Elad Alon TAs: Vighnesh Iyer, Bob Zhou Department of Electrical Engineering and Computer Sciences College of Engineering, University of California, Berkeley

Contents

1	Before You Start This Lab	2			
2	Lab Overview				
3	Introduction to the AC97 Protocol	2			
	3.1 Protocol Connections	9			
	3.2 How Data is Transmitted	9			
	3.3 Sending the Frame Tag (Slot 0) \dots	4			
	3.4 Setting Control Registers With Slots 1 and 2	Ę			
	3.5 Sending Linear PCM (pulse code modulation) Samples in Slots 3 and 4	6			
	3.6 Codec Timing	6			
	3.6.1 Codec Reset	6			
	3.6.2 SYNC Signal for Frame Timing	7			
4	Copy Over Lab 3+4 Designs	7			
5	Building the AC97 Controller	7			
	5.1 I/O Ports	7			
	5.2 General Operation	8			
	5.3 Resetting the Codec	8			
	5.4 Resetting Controller Registers	(
	5.5 Clock Crossing	(
	5.6 Volume Control	Ś			
	5.7 SYNC Signal Timing	10			
	5.8 Testing in Simulation	10			
6	Connect the music_streamer and tone_generator	10			
	6.1 Testing in Simulation	10			
7	Try it on the FPGA!	11			

8	Con	clusion + Checkoff	11
	8.1	Checkoff Tasks	11

1 Before You Start This Lab

These documents will be helpful as you work through this lab.

1. labs_sp17/docs/AC97_Spec.pdf

The official specification of the AC97 protocol which you will partially implement in this lab. This is a large document but there are only a few sections that are important to us. They will be referenced later in the spec.

2. labs_sp17/docs/AD1981B_Datasheet.pdf

The datasheet of the AD1981B AC97 Audio Codec. We will be writing a controller that lives on the FPGA which will communicate with this IC using the AC97 protocol. This IC receives audio data over the AC97 protocol and converts the digital audio data to an analog signal which is sent through the headphone jack.

We strongly recommend you read through Section 3 of this lab document before coming to lab.

2 Lab Overview

Run git pull in your git cloned labs_sp17 directory to fetch the latest skeleton files for this lab.

In this lab, we will create a AC97 controller that lives on the FPGA. The controller will interact with an AC97 audio codec IC on the ML505 development board. Your controller will implement a portion of the AC97 protocol that will allow it to send digital audio data and control signals to the IC.

This lab will be done in teams of two; it will involve building a peripheral used in the project. Once you have formed a team with another student, please email the TAs (vighnesh.iyer@berkeley.edu and bob.linchuan@berkeley.edu) with both of your names, lab sections, and Github usernames.

3 Introduction to the AC97 Protocol

AC97 is a 5-wire protocol which is used for communication between a source/producer of audio data and an audio codec. The audio codec present on our FPGA development board (ML505) is the Analog Devices AD1981B Codec. Our AC97 controller will send digital packets to this codec using the AC97 protocol. The AC97 codec will decode the signals sent to it and will use its DAC (digital to analog converter) to send a audio signal through the headphone jack on the back of the ML505 board. You can plug in your headphones and listen to its output. You can find the headphone jack by looking at the silkscreen (text) on the ML505 board.

Refer to the AD1981B Codec datasheet and the official AC97 spec when working through this lab. They are in the labs_sp17/docs folder.

3.1 Protocol Connections




Figure 1: Codec - Controller Connections

The AC97 controller will be a module that you design in this lab. It is instantiated on the FPGA and has 5 wires between it and the codec. The wires are:

- 1. SYNC tells the codec when a frame is about to start
- 2. BIT_CLK a clock from the codec which your controller should synchronize its data transfers with
- 3. SDATA_OUT the serial line on which your controller transmits data to the codec
- 4. SDATA_IN the serial line on which the codec transmits data to your controller (not used in this lab)
- 5. RESET a signal driven by your controller that resets the codec

The way in which your controller transmits audio samples (linear PCM) to the codec is through the SDATA_OUT wire. There is a specific method of framing the samples so that the codec knows how to read them which is defined by the AC97 spec.

3.2 How Data is Transmitted

AC97 is a **serial interface**: data is transmitted to and from the codec one bit at a time. On every cycle of the AC97 bit clock (BIT_CLK), one bit of data is transferred from the AC97 controller (on the FPGA) to the codec over the SDATA_OUT wire, and one bit of data is transferred from the codec to the FPGA over the SDATA_IN wire.

The constant streams of data passing between the codec and the FPGA are divided into frames. The bit clock is generated by the codec, and runs at 12.288MHz. There are 256 bits per frame, so

48,000 frames are sent per second. This is where the 48kHz sampling rate of the codec comes from. Each frame sent to the codec provides one 20-bit audio sample for each of the DACs in the codec, and each frame sent by the codec provides one 20-bit sample from each of the codec's ADCs.

Frames are divided into twelve slots of 20 bits each, plus a 16-bit tag field, which serves as the frame header. Each slot serves a different purpose and contains various types of data to be sent to the codec. Each slot should be sent with the MSB first going down to the LSB. For example if you were to send data[19:0] in slot 1, you would begin by sending data[19] and finish by sending data[0].

The start of each frame is indicated by a rising edge of the SYNC signal. The SYNC signal goes high one clock cycle before the first bit of a frame, and goes low at the same time as the last bit of the tag field is sent. The diagrams below will summarize how frames are sent using the AC97 protocol.




Figure 2: Framing for AC97




Figure 3: Framing for AC97 with Timing Details

3.3 Sending the Frame Tag (Slot 0)

The bits in the tag (slot 0) are indicate which, if any, of the other slots in the frame are valid. The tag bits are assigned as follows:

Bit	Description	Value
15	Frame Valid	Should be 1 always
14	Slot 1: Valid Register Address	Should be 1 if we are writing or reading from a
		control register in the codec
13	Slot 2: Valid Register Data	Should be 1 if we are writing to a control register
		in the codec
12	Slot 3: PCM Left Channel Valid Data	Should be 1 if we have a sample to send to the
		codec
11	Slot 4: PCM Right Channel Valid Data	Should be 1 if we have a sample to send to the
		codec
10-0	Etc. Valid Bits	Should be set to 0

3.4 Setting Control Registers With Slots 1 and 2

After you send the correct tag through SDATA_OUT, you will then need to send slots 1 and 2. These slots contain an address and a value which refer to some control register on the codec IC. The codec contains a multitude of registers which control various features (volume/gain, mute, etc.). Our controller will need to manipulate some registers to unmute the codec and to set the volume appropriately.

You should refer to the codec datasheet, specifically the table on page 12 to get the details of these control registers. We have specified below the registers that you will need to manipulate.

Reg Address	Description	Value
0x02	Master Volume	Should unset the mute bit and set right and left volume
0x04	Headphone Volume	Should unset the mute bit and set right and left volume
0x18	PCM-Out Volume	Should unset the mute bit and set right and left volume

In **slot 1**, the command register address needs to be specified as follows in 20 bits.

- 1. Bit [19] Read/Write Command (1 = read, 0 = write)
- 2. Bit[18:12] Control Register Address (64 16-bit locations, addressed on even byte boundaries)
- 3. Bit[11:0] Set to 0

The first bit (MSB) sampled by the AC97 codec indicates whether the current control transaction in this frame is a read or write operation. The following 7 bit positions communicate the targeted control register address. The trailing 12 bits should be 0.

In slot 2, the command register data needs to be specified as follows in 20 bits:

- 1. Bit[19:4] Control Register Write Data (16 bits)
- 2. Bit[3:0] Set to 0

If we are writing data to a register, you must send the data with the MSB first in the first 16 bits of slot 2. If you are reading data, the entire slot 2 must be filled with 0s.

3.5 Sending Linear PCM (pulse code modulation) Samples in Slots 3 and 4

The next 2 slots (slots 3 and 4) are used for sending the actual audio samples you want the codec to drive to the headphone output. Remember that the samples must be transmitted MSB first and each sample is 20 bits wide. Also note that each sample is a signed integer encoded with 2s complement, so the total range is roughly $\pm 2^{19}$. Each sample represents the amplitude of the audio wave to be played.

Fill the remaining slots (slots 5-12) with all 0s for each 20-bit slot.

3.6 Codec Timing

The datasheet is useful for figuring out how the timing works with the codec. Pay close attention to the timing parameters and diagrams on **pages 6-7 of the datasheet** as your controller needs to be coded with those in mind.

Your controller will need to send bits on the rising edges of BIT_CLK, and the codec will sample them on the falling edge of the BIT_CLK. Recall, that the BIT_CLK is provided by the codec.

3.6.1 Codec Reset

Your controller will have to perform a cold reset of the codec when it receives a reset signal from the FPGA board (when you press the CPU_RESET button). The cold reset timing is critical, since if your controller doesn't hold the reset properly, the codec may lose its clock.

This timing diagram below is critical to understanding how to reset the codec.




Figure 1. Cold Reset Timing (Codec Is Supplying the BIT_CLK Signal)

Figure 4: Reset Timing Diagram from Datasheet

You will notice from the diagram, that the reset signal that your controller will send to the codec is active low, which means that to assert the reset signal, you have to pull the line low. You will need to pull the reset signal low for at least t_{RST_LOW} which is defined in the datasheet. While the

reset signal is being asserted, the codec will stop producing the BIT_CLK and thus you cannot rely on it during reset; you must instead rely on a different clock to time the reset.

Once the reset signal has been asserted for the required time, after a delay of $t_{RST2CLK}$, the BIT_CLK will begin to oscillate, after which the controller can begin transmitting frames to the codec. When the codec undergoes a cold reset, all of its registers are set to their default values as specified in the datasheet.

3.6.2 SYNC Signal for Frame Timing

The codec needs a way to know when a frame is about to begin so that it can interpret its content appropriately. This is done using the SYNC signal which is sent from your controller to the codec. You should assert SYNC for a total duration of 16 BIT_CLKs at the beginning of each audio frame. Refer back to Figure 3 in Section 3.2 to understand how the SYNC signal should be asserted with each frame.

4 Copy Over Lab 3+4 Designs

You should copy over your lab 4 input processing circuits. Copy over your implementations of synchronizer.v, debouncer.v, edge_detector.v, and rotary_decoder.v. Then copy over your tone_generator.v and music_streamer.v. You can directly copy these files over from your labs_sp17/lab4 directory.

5 Building the AC97 Controller

Open up labs_sp17/lab5/src/ac97_controller.v. You will be implementing your AC97 controller in this module.

5.1 I/O Ports

• sdata_in, bit_clk, sdata_out, sync, reset_b

These are the signals comprising the AC97 protocol. They behave as mentioned in the previous section. The reset_b signal flows directly to the AC97 codec and the sdata_out, sync signals go through a register in ml505top clocked by the bit_clk before going to the AC97 codec. The reset_b signal is an active low reset, which means that to assert the reset to the codec, you must pull the signal low.

• system_clock, system_reset

The system_clock is a 33Mhz clock that will continuously operate. The system_reset is a 1 clock cycle reset pulse that is generated when you press the CPU_RESET button. The system_reset comes from a synchronizer \rightarrow debouncer \rightarrow edge detector chain.

• volume_control [3:0]

This input will be explained in more detail in the Volume Control section. This signal is tied to the GPIO DIP switches 3, 4, 5, 6.

• square_wave

This input comes from your tone_generator and is either 0 or 1, indicating the state of the square wave to play. Your AC97 controller will output this square wave input to the codec using the AC97 protocol.

5.2 General Operation

In the general case, the bit_clk will operate at its specified frequency. Your controller's job is to send AC97 frames to the codec. It will need to set sdata_out and sync in accordance to the AC97 specification.

For sending data to the codec, the AC97 protocol defines 2 20-bit slots for PCM data per AC97 frame. The data you send corresponds to DAC codes on the codec. These slots should be filled with the integer -250000 or 250000 based on whether the square_wave input signal is high or low. Since we are sending signed PCM samples to the codec, you will need a way of holding a signed number. To do this in Verilog, we can use the 'signed' keyword on a wire or reg net as such:

```
wire signed [19:0] pcm_data;
assign pcm_data = -20'd250000;
```

You are also in charge of setting the three previously specified registers of the AC97 codec so that the volume level is set properly and so that the output is unmuted. It is recommended that you write to these registers in a loop so that you are performing a register write every frame; this will make your controller simpler.

5.3 Resetting the Codec

When we assert the reset_b signal to the codec, the bit_clk stops oscillating and only begins again after the reset_b signal has been deasserted. However, we need to precisely time how long the reset signal is asserted. To do this, we will use the system_clock which is always oscillating, and use the system_reset input to trigger a codec reset.

You should read the datasheet for the codec and understand how to reset it. Make sure you reset the codec for the required amount of time.

Be careful, however, since resetting the codec too frequently or for too long can cause the codec to lose its clock and stop operating. If this happens to you, you can recover by re-running make impact.

5.4 Resetting Controller Registers

When the system_reset is asserted, you should only touch one register, which is your reset clock counter that times the reset. Other registers that are modified by the posedge of the bit_clk shouldn't be touched.

In order to get simulation working and your other design registers (frame shift register, frame counter, etc.) in your design to a default state, you should use reg assignments.

```
reg [255:0] frame_to_send = 256'd0;
```

5.5 Clock Crossing

The design of the AC97 controller is tricky since it involves 2 clocks. Generally, you do not want registers that are set by one clock, to be used in combinational logic and then registered by another clock. However, we have that situation in this design.

Our music_streamer and tone_generator are being clocked by the 33 Mhz system clock, while the logic that sends data over sdata_out is being clocked by the bit_clk. Ordinarily, this would pose a problem, since the square_wave register is being set in the system clock domain, and its value is being read, used, and registered in the bit_clk domain.

However, in this particular case, since the square_wave register updates are so infrequent with respect to both the clocks, and a brief glitch in the square wave would make hardly any impact on the audio output, we can use the square_wave value in the bit_clk domain without much worry.

This happy circumstance will not persist into the project. In the next lab and the project you will design a more sophisticated synchronization scheme to move multiple bits in parallel from the system clock domain to the bit_clk domain using an async FIFO.

5.6 Volume Control

Your AC97 controller needs to unmute and set the volume of the audio output using three registers in the codec. These registers should be set as such (look at the datasheet for the details):

Reg Address	Description	Value
0x02	Master Volume	Unmute and set R/L attenuations equal to
		{1'b1, volume_control}
0x04	Headphone Volume	Unmute and set R/L attenuations equal to
		{1'b1, volume_control}
0x18	PCM-Out Volume	Unmute and set R/L gain to 0dB

WARNING: If sufficient attenuation isn't applied, the codec may supply too much power to your headphones and destroy them. Check with the TA if you wish to modify this volume setting scheme.

5.7 SYNC Signal Timing

As a note, if you create registers for the sync and sdata_out signals, make sure that they are both registered the same number of times and march in line.

You will need to make sure the sync signal is applied properly as you send each AC97 frame. Refer to Figure 3 in Section 3.2 for details. You should raise the sync signal on the last bit of the previous frame and hold it high until the last tag bit is being sent.

5.8 Testing in Simulation

To test our AC97 controller, we will be using a **block-level testbench**. This testbench will simulate our AC97 controller in isolation to see if it performs to spec.

The source for this testbench is lab5/src/ac97_controller_testbench.v. Run the testbench as usual by running make CASES="tests/ac97_controller_testbench.do" in the lab5/sim directory. This testbench isn't self checking so you should look at the Verilog file and manually inspect the output waveform to verify that all specifications are met. You should especially check that the reset behavior of your AC97 controller is in spec. You can extend the testbench so that it sends more stimulus to the AC97 controller (like changing the volume).

We have provided you with a AC97 codec model in src/ac97_codec_model.v. This module simulates an AC97 codec and interprets the signals your controller sends it on sdata_out. It prints out debug messages during the testbench to let you know what data it received.

The AC97 codec model has a few timing checks in the form of specify blocks; these timing checks aren't always accurate, so if you see them when running the testbench, verify that they are accurate using Modelsim.

You should make sure that ALL the signals in your AC97 controller are not undefined (X / red line) for the entirety of the simulation.

6 Connect the music_streamer and tone_generator

6.1 Testing in Simulation

We previously used a block-level testbench to just test the AC97 controller in isolation. Now we will use a **system/chip-level testbench** to test our entire system at a higher level. This dichotomy is similar to the difference between unit tests and integration tests in software.

Take a look at the source for this testbench in lab5/src/system_testbench.v. You will notice that instead of instantiating the AC97 controller, it instantiates ml505top. Now, the stimulus that we supply to our DUT represent signals coming into the FPGA.

This testbench will simulate the entire system which connects your AC97 controller to the tone_generator, which is connected to the music_streamer, which has connections from your input conditioning circuits (synchronizer, debouncer, edge detector, rotary decoder). This testbench isn't self-checking

either, so you should add stimulus to the DUT to make it respond in some way and see that it is reflected in the waveform.

The codec model can be forced to print debug messages like in the previous testbench if you set its DEBUG_MODE parameter to 1 in its instantiation.

You should make sure that ALL of the signals in your entire system are well defined (not X) for the entirety of the simulation.

7 Try it on the FPGA!

With both simulations indicating that everything seems to be working, run make and make impact from the lab5 directory. When your design is on the FPGA, your music streamer FSM from Lab 3 should still work as usual. By turning on the 1st and last DIP switches, the piezo output will be enabled. But now, as long as the 1st DIP switch is turned on, you can plug in a pair of headphones to listen to the output of the music streamer FSM too!

You can use DIP switches 3-6 to change the volume of the audio output. Keep in mind that making all the switches high will give you the max attenuation, which corresponds to the quietest volume level.

8 Conclusion + Checkoff

You are done with lab 5! Please write down any and all feedback and criticism of this lab and share it with the TA. This is a brand new lab and we welcome everyone's input so that it can be improved.

The differences between a block and system level testbench will be critical in the testing of your project. You will use both types of testbenches extensively to verify correct behavior of all the modules you write.

8.1 Checkoff Tasks

- 1. Show the TA your working AC97 controller by demonstrating the state machine in the music_streamer working and sending audio to the AC97 codec.
- 2. Demonstrate that your volume control functionality works by toggling the DIP switches and observing a change in the volume of the headphone output.