



Comment	Description	Designator	Footprint	LibRef	Quantity
	4Standard 4-				
	pin 0.1"				
	header. Use				
	with straight				
	break away				
	headers				
	(SKU : PRT-				
	00116), right				
	angle break				
	away				
	headers				
	(PRT-00553),				
	swiss pins				
	(PRT-00743),				
	machine				
	pins (PRT-				
	00117), and				
	female				
	headers				
	(PRT-00115).				
	Molex				
	polarized				
	connector				
	foot print				
	use with				
	SKU : PRT-				
	08231 with				
	associated				
	crimp pins				
M04NO_SIL	and		1X04_NO_SI	l	
K_ALL_ROU	housings.	ina ino ino	LK_ALL_ROU	l	
ND	1MM SMD	JP1, JP2, JP3	ND	ND	3
	Standard 6-				
	pin 0.1"				
	header. Use				
	with straight				
	break away				
	headers				
	(SKU : PRT-				
	00116), right angle break				
	-				
	away headers				
	(PRT-00553), swiss pins				
	(PRT-00743),				
	machine				
	pins (PRT-				
	00117), and				
	female				
	headers				
	(PRT-00115).				
	Molex				
	polarized				
	connector				
	foot print				
	use with				
	SKU : PRT-				
	08094 with				
	associated				
	crimp pins				
	and				
	housings.			M06VERNIE	
BTA	NOTES ON	JP5	BTA	R-ANALOG	1
RESISTORPTI			AXIAL-0.4	RESISTORPTH	2
	5.0.00310	,			