#### 21CSS201T C - COMPUTER ORGANIZATION AND ARCHITECTURE

Dr. S. Anbukkarasi AP/CSE

# Number System

The technique to represent and work with numbers is called number system.

- Binary
- Decimal
- Octal
- Hexadecimal

# **Decimal Number System**

- Decimal number system is a base 10 number system having 10 digits from 0 to 9.
- This means that any numerical quantity can be represented using these 10 digits.
- Decimal number system is also a positional value system.

10 <sup>5</sup>	104	10 <sup>3</sup>	10 <sup>2</sup>	10 <sup>1</sup>	10 <sup>0</sup>

## **Binary Number System**

The easiest way to vary instructions through electric signals is two-state system – on and off.


On is represented as 1 and off as 0, though 0 is not actually no signal but signal at a lower voltage.

The number system having just these two digits -0 and 1 – is called binary number system.

Each binary digit is also called a bit. Binary number system is also positional value system, where each digit has a value expressed in powers of 2, as displayed here

2 <sup>5</sup>	24	23	22	21	20

In any binary number, the rightmost digit is called least significant bit (LSB) and leftmost digit is called most significant bit (MSB).



Decimal Equivalent of: 110011

# Memory

Computer memory is measured in terms of how many bits it can store. Here is a chart for memory capacity conversion.

- 1 byte (B) = 8 bits
- 1 Kilobytes (KB) = 1024 bytes
- 1 Megabyte (MB) = 1024 KB
- 1 Gigabyte (GB) = 1024 MB
- 1 Terabyte (TB) = 1024 GB
- 1 Exabyte (EB) = 1024 PB
- 1 Zettabyte = 1024 EB
- 1 Yottabyte (YB) = 1024 ZB

### **Octal Number System**

Octal number system has eight digits -0, 1, 2, 3, 4, 5, 6 and 7. Octal number system is also a positional value system with where each digit has its value expressed in powers of 8, as shown here -

8 <sup>5</sup> 8 <sup>4</sup> 8 <sup>3</sup> 8 <sup>2</sup> 8 <sup>1</sup> 8 <sup>0</sup>
---

Decimal Equivalent of : 645<sub>8</sub> ->

## Hexadecimal Number System

Octal number system has 16 symbols – 0 to 9 and A to F where A is equal to 10, B is equal to 11 and so on till F. Hexadecimal number system is also a positional value system with where each digit has its value expressed in powers of 16, as shown here –

16 <sup>5</sup>	164	16 <sup>3</sup>	16 <sup>2</sup>	16 <sup>1</sup>	16 <sup>0</sup>
-----------------	-----	-----------------	-----------------	-----------------	-----------------

35AB<sub>16</sub> equivalent to: ?

#### **ASCII**

Besides numerical data, computer must be able to handle alphabets, punctuation marks, mathematical operators, special symbols, etc. that form the complete character set of English language.

The most widely used alphanumeric code is **American Standard Code for Information Interchange** (ASCII).

ASCII is a 7-bit code that has 128 (27) possible codes.

Unicode

# Conversion

# **Decimal to Binary**

Decimal numbers can be converted to binary by repeated division of the number by 2 while recording the remainder. Let's take an example to see how this happens.

	Remainder		
		43	2
MSE	1	21	2
Î	1	10	2
	0	5	2
	1	2	2
	0	1	2
LSB	1	0	

ne remainders are to be read from bottom to top to obtain the binary equivalent.

$$43_{10} = 101011_2$$

### **Decimal to Octal**

Decimal numbers can be converted to octal by repeated division of the number by 8 while recording the remainder. 47310 = 7318

		Remainder	
8	473		
8	59	1	MSD
8	7	3	<b>†</b>
	0	7	LSD
56			

# Decimal to Hexadecimal

Decimal numbers can be converted to octal by repeated division of the number by 16 while recording the remainder.

Remainde		12
	423	16
7	26	16
Α	1	16
1	0	


42310 = 1A716

## Binary to Octal and Vice Versa

To convert a binary number to octal number, these steps are followed –

Starting from the least significant bit, make groups of three bits.

If there are one or two bits less in making the groups, 0s can be added after the most significant bit Convert each group into its equivalent octal number



## Binary to Hexadecimal

To convert a binary number to hexadecimal number, these steps are followed –

Starting from the least significant bit, make groups of four bits.

If there are one or two bits less in making the groups, 0s can be added after the most significant bit.

Convert each group into its equivalent hexa number.

# Decimal to Binary (With Fractions)

8.235

$$.235 \Rightarrow .235 * 2 \Rightarrow 0.470$$

$$0.470 \Rightarrow 0.470 * 2 \Rightarrow 0.94$$

$$0.94 \Rightarrow 0.94 * 2 \Rightarrow 1.88$$

ANSWER: 1000.001

# Binary to Decimal (With Fractions)

1110.001

$$.001 => 0 * 2^{-1} + 0 * 2^{-2} + 1 * 2^{-3}$$

$$=> 0 + 0 + \frac{1}{8} = > 0.125$$

ANSWER: 14.125


# Binary Representation (Other way)

	8	4	2	1
0 =>	0	0	0	0
1=>	0	0	0	1
2 =>	0	0	1	0
•••				

10 => 1 0 1 0


# Codes

Group of symbols - Codes



- Weighted Codes Binary, 8421
- Non Weighted Codes XS- 3, Gray
- Reflective codes (Self complementing code) 2421,XS-3 [9 and 0, 8 and 1 etc are compliments with each other)
- Sequential code 8421, XS-3
- Alphanumeric codes ASCII
- Error Detecting and Correcting codes Hamming

# Gray



-> Uses in Digital operations

ecimal	Binary			Gr	yay	Coc	le	
0	0	0	0	0	0	0	0	0
1	0	0	0	1	0	0	0	1
2	0	0	1	0	0	0	1	1
3	0	0	1	1	0	0	1	O
4	0	1	0	0	0	1	1	0
5	0	1	0	1	0	1	1	1
6	0	1	1	0	0	1	0	1
7	0	1	1	1	0	1	0	0
8	1	0	0	0	1	1	0	0
9	1	0	0	1	1	1	0	1
10	1	0	1	0	1	1	1	1
11	1	0	1	1	1	1	1	O
12	1	1	0	0	1	0	1	C
13	1	1	0	1	1	0	1	1
14	1	1	1	0	1	0	0	1


1 1 1 1

15

Binary to Gray:

$$(1+0) (0+1) (1+1)$$

Gray to Binary:



## Binary Coded Decimal (BCD) code

- In this code each decimal digit is represented by a 4-bit binary number. [0-9]
- BCD is a way to express each of the decimal digits with a binary code.
- In the BCD, with four bits we can represent sixteen numbers (0000 to 1111).
- But in BCD code only first ten of these are used (0000 to 1001).
- The remaining six code combinations i.e. 1010 to 1111 are invalid in BCD. (only decimal digits not numbers)
- Positional values 8 4 2 1

Decimal	0	1	2	3	4	5	6	7	8	9
BCD	0000	0001	0010	0011	0100	0101	0110	0111	1000	1001

#### Advantages of BCD Codes

It is very similar to decimal system.

We need to remember binary equivalent of decimal numbers 0 to 9 only.

## Disadvantages of BCD Codes

The addition and subtraction of BCD have different rules.

The BCD arithmetic is little more complicated.

BCD needs more number of bits than binary to represent the decimal number. So BCD is less efficient than binary.

#### Decimal to BCD:

Convert (123)10 in BCD = Packed BCD

From the truth table above,

*1* -> *0001* 

*2* -> *0010* 

*3* -> *0011* 

thus, BCD becomes -> 0001 0010 0011

#### BCD to Decimal:

- 1. 0001 0010 0011
- 123
  - *1.* 10 100
- $0001\ 0100 => 14$

# **BCD** Addition

Simple Binary Addition

- 1. Sum  $\leq$  9 Final Carry = 0 (Answer Correct)
- 2. Sum <= 9 Final Carry = 1 (Answer InCorrect, add 0110)
- 3. Sum > 9 Final Carry = 0 (Answer InCorrect, add 0110)

1. 2+6

1. 3+7

1. 8+9

2. 57 + 26

#### Excess-3 code

- The Excess-3 code is also called as XS-3 code.
- It is non-weighted code used to express decimal numbers.
- The Excess-3 code words are derived from the 8421 BCD code words adding (0011)2 or (3)10 to each code word in 8421. The excess-3 codes are obtained as follows:

# • Self Complementing Code [0-9, 1 - 8, 2-7 and so on]

Decimal	1	BCD		Excess-3		
	8 4	2	1	BCD + 0011	Ļ	
0	0 0	0	0	0 0 1	1	
1	0 0	0	1	0 1 0	0	
2 3	0 0	1	0	0 1 0	1	
3	0 0	1	1	0 1 1	0	
4	0 1	0	0	0 1 1	1	
5	0 1	0	1	1 0 0	0	
6	0 1	1	0	1 0 0	1	
7	0 1	1	1	1 0 1	0	
8	1 0	0	0		1	
9	1 0	0	1	1 1 0	0	

### **Decimal To Xs-3:**

# XS-3 Addition

Ex: 
$$2_{10} + 5_{10}$$

BCD - 
$$Xs-3$$
  
 $0010 + 0011 \Rightarrow 0101$   
 $0101 + 0011 \Rightarrow 1000$ 

1101 (Excess of 6, so subtract 3) 1101 - 0011 =>1010

## **ASCII Code**

- The ASCII stands for American Standard Code for Information Interchange.
- The ASCII code is an alphanumeric code used for data communication in digital computers.
- The ASCII is a 7-bit code capable of representing  $2^7$  or 128 number of different characters.
- The ASCII code is made up of a three-bit group, which is followed by a four-bit code.

# Parity

- To detect errors
- Single bit error can be detected
- Additional bit which is sent along with the input signal

Two Types:

Odd Parity

**Even Parity** 

ODD => Number of ones should be odd along with parity


EVEN => No of ones should be even along with parity

For Ex: Data word: 1101

If want use ODD Parity then, 1101 0(Parity)

If want to use EVEN Parity then, 1101 1(Parity)

#### Data Representation using Signed Magnitude



#### **Unsigned:**

$$+6 => 0110$$

-6=> No representation

Signed:

Range of Sign Magnitude:  $-(2^{n-1}-1)$  to  $+(2^{n-1}-1)$  #n => no of variables

If n=4, range will be -7 to 7

#### 1's Complement

There are two types of complement of Binary number: 1's complement and 2's complement.

To get 1's complement of a binary number, simply invert the given number.

To get 2's complement of binary number is 1's complement of given number plus 1 to the least significant bit (LSB).

Uses of 1's Complement Binary Numbers:

Mainly in signed Binary number representation and various arithmetic operations for Binary numbers, e.g., additions, subtractions, etc.

Example: 110011 => 001100

## Negative numbers in 1's complement

```
+6 \Rightarrow 0110
-6 \Rightarrow 1001

Problem: -0 \& +0
0 \Rightarrow 0000 -0 \Rightarrow 1111

Range: -(2^{n-1}-1) to +(2^{n-1}-1) #n \Rightarrow no of variables

If n=4, range will be -7 to 7
```

#### 2's Complement

 $10101110 \Rightarrow 01010001 + 1 \Rightarrow 01010010$ 

Find 2's complement of binary number 10001.001.

#### Uses of 2's Complement Binary Numbers

There are various uses of 2's complement of Binary numbers, mainly in signed Binary number representation and various arithmetic operations for Binary numbers, e.g., additions, subtractions, etc.

Since 2's complement representation is unambiguous, so it very useful in Computer number representation.

$$+6 => 0110$$

Range: 
$$-2^{n-1}$$
 to  $+(2^{n-1}-1)$  #n => no of variables

If 
$$n=4$$
 (4 bits) => -8 to 7

In 2's comp => MSB represents sign

1 means -ve

0 means +ve

#### Subtraction using 1's complement:

#### Binary Subtraction using 1's Complement

$$A - B = A + (-B)$$

Step 1: Convert number to be subtracted to it's 1's complement form.

Step 2: Perform the addition.

Step 3: If the final carry is 1, then add it to the result obtained in step 2. If final carry is 0, result obtained in step 2 is negative and in the 1's complement form.

# Examples: Subtraction using 1's complement:

```
1100_{2} - 0101_{2} => ?
1100
1010 => 1's comp
10110 => Addition
Add 1 => 0111
```

 $0101_2 - 1100_2 => ?$ 

#### Subtraction using 2's complement:

#### Binary Subtraction using 2's Complement

Step 1: Find 2's complement of number to be subtracted.

Step 2: Perform the addition.

Step 3: If final carry is generated then the result is positive and in its true form.

If final carry is not produced, then the result is negative and in its 2's complement form.

# Examples: Subtraction using 2's complement:

```
1001_2 - 0100_2 \Rightarrow ? (9-4)

2's comp of 0100 \Rightarrow 

1011 + 1 \Rightarrow 1100

1001 (+) \Rightarrow 9

10101 \Rightarrow 5
```


Find: 0110<sub>2</sub> - 1011<sub>2</sub>


# Binary Multiplication


- $\bullet \quad 0 \times 0 = 0$
- $0 \times 1 = 0$
- $1 \times 0 = 0$
- $1 \times 1 = 1$

10 \* 5 = 50

# **Binary Division**







#### **BCD** Arithmetic

BCD Addition

**BCD** Subtraction

# **Binary Coded Decimal Addition**

1. 
$$Sum < 9$$
 and  $Carry = 0$ 


2. Sum < 9 and Carry = 1


3. Sum > 9 and Carry = 0


Correct

Incorrect and add 6 (0110)


Incorrect and add 6 (0110)







# Multi digit BCD Addition 3. 758+879



#### **BCD** subtraction

Step 1 – convert to numbers into BCD

Step 2 - Take 9's complement of subtrahend


Step 3- Add the complement number with minuend

Step 4 – If a four bit number is equal to or less than 9, then the result is valid BCD number.

Step 5 – If a four bit number is more than 9, then the result is invalid. Add 6 to get valid BCD number.

# BCD subtraction

1. 695 - 238



#### Logic gates

- · Building block of digital circuits.
- Make decisions based on a combination of digital signals coming from its inputs.
- · Logic gates are based on Boolean algebra.
- False represents 0, and true represents 1.
- Seven basic logic gates: AND, OR, XOR, NOT, NAND, NOR, and XNOR.

#### GATES Boolean Algebra

AND 
$$\Rightarrow$$
 C (output) = A . B  
OR  $\Rightarrow$  C (output) = A+B  
NAND  $\Rightarrow$  C (output) =  $\overline{A}$ .  $\overline{B}$   
NOR  $\Rightarrow$  C (output) =  $\overline{A}$ +B  
XOR  $\Rightarrow$  C (Output) =  $\overline{A}$ .B + AB  
XNOR  $\Rightarrow$  C (Output) =  $\overline{A}$ B + AB

# **NOT** gate



- Also called as the inverter gate.
- Has only one input.
- It just inverts the input.


Input 1	Result
1	0
0	1

# **AND** gate



• If both the inputs are true, the result is true else the result is false.

Input 1	Input 2	Result
1	1	1
1	0	0
0	1	0
0	0	0



- AND gate followed by an inverter.
- The output is false if both inputs are true.


Input 1	Input 2	Result
1	1	0
1	0	1
0	1	1
0	0	1

# OR gate



• If any one of the input is true, the result is true else the result is false.


Input 1	Input 2	Result
1	1	1
1	0	1
0	1	1
0	0	0



- NOR gate followed by an inverter.
- The output is true if both inputs are false.

Input 1	Input 2	Result
1	1	0
1	0	0
0	1	0
0	0	1

# **XOR gate (eXclusive OR)**



- If either one of the input is true, the result is true else the result is false.
- If both the inputs are same, the result is false.

Input 1	Input 2	Result
1	1	0
1	0	1
0	1	1
0	0	0

# eXclusive NOR (XNOR) gate



- XOR gate followed by an inverter.
- The output is true if both inputs are same.

Input 1	Input 2	Result
1	1	1
1	0	0
0	1	0
0	0	1