
Sensor Inputs
Joystick
Arcade Button
2× Force Sensors
6× Rotary Encoders
Expression Pedal In
8× Momentary Buttons
Gyroscope/Accelerometer
Ultrasonic Distance Sensor
4× NeoPixel LEDs
3.5" Touchscreen
ChucK
OSC
Python
Audio I/O
Contact Mics
1/8" In L/R
ADC
DAC
1/8" Out L/R
Teensy 4.1
Raspberry Pi 5
Teensy 4.0
External USB
USB-C Power