Proyecto de ejemplo de AVR de baja potencia

Objetivo

Esta página illustra varios métodos para configurar un MCU AVR ® de 8 bits para que funcione con bajo consumo de energía. Con este ejercicio lograrás:

- Cree un proyecto y agregue un código simple para hacer parpadear un LED
- Ejecutar el proyecto y medir el consumo de energía
- · Hacer modificaciones al código para reducir la potencia
- Ejecute el proyecto modificado y observe un consumo de energía reducido

✓ Materiales

Requisitos de Software



Requisitos de hardware

- ATmega328PB Mini tablero explicado
- Kit depurador de energía
- · Dos cables micro USB
- · Tres cables hembra a macho y un cable macho a macho



ATmega328PB Tarjeta explicada

The ATmega328PB Xplained Mini Evaluation Kit is a hardware platform for evaluating the Atmel ATmega328PB microcontroller. An external debugger is NOT needed to run these exercises. The ATmega328PB has a fully integrated embedded debugger on-board.



(/local--files/8avr:low-power-example/xplained-board.png)

Power Debugger Kit

The Power Debugger is a CMSIS-DAP compatible debugger which works with Atmel Studio v7.0 or later. The power Debugger sends runtime power measurement and application debug data to the Data Visualizer.



(/local--files/8avr:low-power-example/power-debug.png)

The Power Debugger has two independent current sensing channels for measuring and optimizing the power consumption of a design.


The 'A' channel is the recommend channel for accurately measuring low currents.

The 'B' channel is the recommended channel for measuring higher currents with lower resolution.

Hardware Setup


Connecting the Power Debugger to the ATmega328PB Xplained Board.

The 'A' and 'B' channel current measurement ports on the Power Debugger board are depicted with ammeter symbols on the silkscreen. The voltage supply is connected to the input of the ammeter, and the load (target) is connected to the output. With the following steps, the power debugger measures the consumption on the AVR core. Table 1-1 Power Debugger and ATmega328PB Xplained Mini connection.




(/local--files/8avr:low-power-example/table.png)

Figure 1-1 Power Debugger and ATmega328PB Xplained Mini connection.



(/local--files/8avr:low-powerexample/connection.png)

Hardware Configuration



(/local--files/8avr:low-powerexample/hw.png)

Measuring the Current in Active Mode

!! Procedure


A Project Creation

- Open Atmel Studio 7
- Select File > New > Project
- Select GCC C Executable Project and give it the name LowPower.
- Choose a location to save the project on your computer.



(/local--files/8avr:low-power-example/location.png)

• When the Device Selection window appears, enter 328P into the search window and then select the Atmega328PB. Click OK.



(/local--files/8avr:low-power-example/device-


selection.png)

• A project will be created containing an empty while(1) loop in main().




Select View > Solution Explorer from the menu bar.

In the Solution Explorer, right click the project and select Properties.



(/local--files/8avr:low-power-example/se.png)

Under Tool, Select mEDBG and debugWIRE




(/local--files/8avr:low-power-example/debugwire.png)

B Add Code to the Project

• Add the following two statements in <code>main()</code> to call <code>TMR0_init</code> and set an I/O pin as an output:



Add the Timer 0 initialization routine



• Provide the TMR0 interrupt service routine to the project, and make the LED blink at about 1 Hz.



The complete program is as follow,


```
#include <avr/io.h><font></font>
#include "avr/interrupt.h"<font>
<font></font>
uint8_t count;<font></font>
/* Timer 0 Interrupt */<font></fon
ISR(TIMER0_OVF_vect){<font></font>
<font></font>
     count++;<font></font>
if(count==20){<font></font>
           count=0;<font></font>
// Toogle LED<font></font>
           PORTB=PORTB ^ 0x20;<font><
     }<font></font>
}<font></font>
<font></font>
int main(void)<font></font>
{<font></font>
TMR0_init();<font></font>
<font>
     DDRB |= 1<<DDRB5;
     DDRB |= 1<<DDRB5; // Directi
/* Replace with your applicati
while (1) <font></font>
      {<font></font>
      }<font></font>
}<font></font>
<font></font>
/*********
***********
void TMR0_init( void ){<font></fon</pre>
<font></font>
     // enable timer overflow inter
TIMSK0=(1 <<TOIE0) ;<font></fo</pre>
<font></font>
     // set timer0 counter initial
      TCNT0=0x00;<font></font>
<font></font>
     // start timer0 with /1024 pre
TCCR0B = (1 <<CS02) | (1<<CS00
<font></font>
     // enable interrupts<font></fo</pre>
     sei(); <font></font>
```

 }

C Verify the Project Runs

• Build the project and program the device by selecting **Debug > Continue**.



The LED will blink if the project is working correctly

• Ensure debugging for the project is terminated by selecting **Debug > Disable debugWire** then **Close**.

Measure the Power Consumption in Active Mode

• In Atmel Studio 7, open the menu Tools > Data Visualizer

Power Debugger Data Gateway should be selected by default in DGI Control Panel, select it if not. Click on **Connect.**




(/local--files/8avr:low-power-example/connect.png)

• Select Power and Start



(/local--files/8avr:low-power-example/power-and-start.png)



(/local--files/8avr:low-power-example/power-monitor.png)

Turn off the target Power Supply to Xplained board and enable power measurement



(/local-files/8avr:lowpowerexample/enablepower.png)

- · Close the Device Programming
- · Verify that the average current consumption is about 2.6 mA

Reducing the power consumption

There are several methods you can use to reduce the power consumption of an AVR[®] microcontroller. This example reduces power by:

- · turning off unused peripherals
- · Stopping leakage current on the digital I/O pins
- Using sleep mode. Power consumption optimization techniques are implementing in the function Optimize_power_consumption() which is called from main().

Disable digital input buffers and Analog comparator

For analog input pins, the digital input buffer should be disabled.

The digital input buffer measures the voltage on the pin and represents the value as a logical one or zero. An analog signal level close to VCC/2 on an input pin can cause significant additional current consumption. If the pin is used as analog pin there is no need to know if the analog signal's digital value would be a one or zero; these digital pins should be disabled.

Turn off unused peripherals

Disable the peripherals not used in the application. The **Power Reduction Register** (**PRR0**) and (**PRR1**) can stop the clock to individual peripherals to reduce power consumption. Resources used by the peripheral remain occupied when the clock is stopped. In most instances, peripherals should be disabled before the clock is halted.

1. Include the <power.h> file in the main program

#include <avr/power.h>

Add below code to optimize_power_consumption().



3. Add and #include for <wdt.h> to main.c.

#include <avr/wdt.h>

4. Add the following code in optimize_power_consumption() to turn off watch dog timer.



Apply pull-up resistors

Unused and unconnected pins consume power. The un-needed power load of floating pins can be avoided by using the AVR's internal pull-up resistors on the unused pins. Port pins can be set to input pull-ups by setting the **DDxn** bit to 0 and **PORTxn** bit to 1. (where \mathbf{x} is PORT B,C,D,E and \mathbf{n} is 0 to 7)

```
<font></font>
.C
                      /* Unused pins set as inpu
            3
                            DDRB
                                    &= 0xE0;<font></
                           DDRC &= 0xC9;<font></id>

DDRD &= 0x03;<font></id>

            4
            5
            6
                            DDRE &= 0xF3;<font></1
                 <font></font>
                                     |= ~(0xE0);<font
|= ~(0xC9);<font
            8
                            P0RTB
                            PORTC
                                    = ~(0x03);<font
= ~(0xF3);<font
           10
                            P0RTD
           11
                            P0RTE
                 <font></font>
```

Use Sleep function

Sleep mode allows the application to save power by shutting down unused modules. The AVR provides various sleep modes allowing the user to tailor the power consumption to the application's requirements.

- 1. Include <avr/sleep.h> header file from AVR library at the top of file.
- 2. Set the desired sleep mode in the <code>optimize_power_consumption</code> () function by configuring the microcontroller to use the sleep mode <code>SLEEP_MODE_PWR_DOWN</code> for minimum power consumption.

```
/* Set sleep mode */<
set_sleep_mode(SLEEP_MOD)
</pre>
```

3. Call the function sleep_mode() from main() to enter sleep mode.



Using Pin Change Interrupt

To wake up the microcontroller from **SLEEP_MODE_PWR_DOWN** the **Pin Change Interrupt** is used. The **ATmega328PB Xplained Mini** board's switch (SW0) is connected to **PB7**. Pin **PB7** is the source for the pin change interrupt. Make the following additions to main():

#include avr/interrupt.h

Configuring bit PCINT7 and PCICR register:

```
<font></font>
PCMSK0 |= (1<<PCINT7); //Enable P
PCICR |= (1<<PCIE0); //Enable
sei();<font></font>

<font>/
```

Add the interrupt service routine:

In order to enable the ISR routines, the vector name for the PCINT7 is ISR (PCINT0_vect), defined in device header file.



Completed Code

After making the previous changes the complete code should like the following:



```
<font></font>
/*<font></font>
 * lowpower2.c<font></font>
*/ <font></font>
<font></font>
//#include <avr/io.h><font></font>
<font></font>
#include <avr/io.h><font></font>
#include "avr/interrupt.h"<font>/
#include "avr/wdt.h"<font></font>
#include "avr/sleep.h"<font></font</pre>
<font></font>
#include <avr/power.h><font></font</pre>
#include <avr/interrupt.h><font><,</pre>
//#include <util/delay.h><font></f
<font></font>
          optimize_power_consumption
void
<font></font>
     /* Disable digital input buffe
DIDR0 = (1 << ADC5D) | (1 << A
     DIDR0 |= 0xC0;
                            /*ADC7D and
<font></font>
     /* Disable digital input buffe
     DIDR1 |= (1 << AIN1D) | (1 <<
     /* Disable Analog Comparator *
ACSR |= (1 << ACD);<font></fon
<font></font>
     /*Power shutdown to unused per
PRR0 = 0xDF;<font></font>
PRR1 = 0x3F;<font></font>
     /*Unused pins set as input pul
DDRB &= 0xE0;<font></font>
DDRC &= 0xC9;<font></font>
DDRD &= 0x03;<font></font>
     DDRE &=0xF3; <font></font>
<font></font>
     PORTB |=~(0xE0);<font></font>
PORTC |=~(0xC9);<font></font>
PORTD |=~(0x03);<font></font>
PORTE |=~(0xf3);<font></font>
<font></font>
     /*Watchdog Timer OFF*/<font></
<font></font>
     /* Disable interrupts */<font>
     cli();<font></font>
     /* Reset watchdog timer */<fon
     wdt_reset();<font></font>
/* Clear WDRF in MCUSR */<font</pre>
     MCUSR &= ~(1<<WDRF);<font></fo
/* Turn off WDT */<font></font
     WDTCSR = 0x00;<font></font>
<font></font>
     /* Set sleep mode */<font></fo
set_sleep_mode(SLEEP_MODE_PWR_
<font></font>
}<font></font>
<font></font>
/**********
***********
void TMR0_init( void ){<font></fo</pre>
<font></font>
     // enable timer overflow inter
     TIMSK0=(1<<T0IE0) ;<font></fon
<font></font>
     // set timer0 counter initial
     TCNT0=0x00;<font></font>
```

```
<font></font>
     // start timer0 with /1024 pre
     TCCR0B = (1<<CS02) | (1<<CS00)
<font></font>
     // enable interrupts<font></fo
     sei(); <font></font>
<font></font>
   <font></font>
      uint8_t
                    count;<font></font
/* Timer 0 Interrupt */<font></fon
ISR(TIMER0_OVF_vect) {<font></font</pre>
<font></font>
     count++;<font></font>
if(count==20){<font></font>
          count=0;<font></font>
          // Toogle LED<font></font>
PORTB=PORTB ^ 0x20;<font><
     }<font></font>
}<font></font>
<font></font>
ISR (PCINT0_vect)<font></font>
{<font></font>
      if (!(PINB & (1<<PINB7))) //</pre>
     {<font></font>
          PORTB |= (1<<PORTB5); // T
     }<font></font>
else<font></font>
     {<font></font>
          PORTB &= ~(1<<PORTB5); //
       <font></font>
}<font></font>
<font></font>
int main(void)<font></font>
{<font></font>
     TMR0_init();<font></font>
<font></font>
     <font></font>
     optimize_power_consumption();<</pre>
<font></font>
     PCMSK0 |= (1<<PCINT7); //Enabl
     PCICR |= (1<<PCIE0); //Enable
     sei();<font></font>
<font></font>
     //set_sleep_mode(SLEEP_MODE_PW
//sleep_enable();<font></font>
     //sleep_cpu();<font></font>
//steep_cpot/, fonts
/fonts
/fonts
/* Replace with your applicati
while (1) <fonts</fonts
{<fonts</fonts</fonts</fonts//fonts</pre>
     sleep_mode();<font></font>
}<font>
}<font></font>
<font></font>
4
```

Program the application and measure power consumption.

- 1. Program the code by selecting **Debug > Continue**.
- 2. Wait until the application is programmed and the message at the bottom of the window appears as Running.
- 3. Exit the debugger by selecting **Debug > Disable debugWire** then **Close**.
- 4. Open the DataVisualizer window and check the power consumption as shown below.



(/local--files/8avr:low-powerexample/one-five.png)

Current consumption observed should be down to around 1.52 mA.

• Set target power switch off: Tools > Device Programming > Tools setting



(/local--files/8avr:low-powerexample/threema.png)

Current consumption should have been lowered to approximately 20.7 µA.



Note that the Timer does not wake the device from SLEEP mode. The application is set to exit sleep mode when the **Pin Change Interrupt** occurs.

Conclusions

This example demonstrated several different techniques to lower the power consumption of an AVR application. The power consumption can be significantly reduced by:

- · Intelligent design
- · Using sleep modes
- · Switching off unused peripherals

This example used the Atmel Studio 7 Data Visualizer and the Power Debugger Board to measure the power.