





Power Low Level Bootloader GND P2 + GND Serial Pin Analog Pin Boot modes and safe boot Control Physical Pin P12 + 3V3 Port Pin 1-3 sec Safe boot, latest firmware is selected Touch Pin 4-6 sec Safe boot, previous user update selected DAC Pin -**∨** PMW Pin 7-9 sec Safe boot, the factory firmware is selected

Internal Functions	
35	External Antenna Switch

23/11/17

Distributed and manufactured by Pycom Ltd. Registered office:

High Point, 9 Sydenham Road, Guildford, Surrey GU1 3RX, UK Copyright © 2017 by Pycom Ltd. All rights reserved. No part of this

document may be reproduced, distributed, or transmitted in any form or by any means, including photocopying, recording, or other electronic or mechanical methods, without the prior written permission of Pycom Ltd, except in the case of brief quotations embodied in critical reviews and certain other noncommercial uses permitted by copyright law.

To order contact sales@pycom.io