



AUTOLUBE PUMP

- ① Autolube pump
- ② Gasket
- ③ Washer
- ④ Drive shaft
- ⑤ Pin
- ⑥ Oil seal
- ⑦ Circlip
- ⑧ Autolube pump gear

