


FAULTY GEAR SHIFTING


HARD SHIFTING

PROBABLE CAUSE



CHANGE PEDAL DOES NOT MOVE

PROBABLE CAUSE



JUMP-OUT GEAR

PROBABLE CAUSE

