



SPECIAL TOOLS

The proper special tools are necessary for complete and accurate tune-up and assembly. Using the correct special tool will help prevent damage caused by the use of improper tools or improvised techniques.

**FOR TUNE UP**


1. Inductive Tachometer
P/N YU-08036
P/N 90890-03113

This tool is needed for detecting engine rpm.




2. Fuel Level Gauge
P/N YM-01312-A
P/N 90890-01312

This gauge is used to measure the fuel level in the float chamber.

**FOR ENGINE SERVICE**

1. Piston Pin Puller
P/N YU-01304
P/N 90890-01304

This tool is used to remove the piston pin.



2. Universal Clutch Holder
P/N YM-91042
P/N 90890-04086

This tool is used to hold the clutch when removing or installing the clutch boss securing nut.