



LUBRICATION POINTS AND LUBRICANT TYPE

ENGINE

Lubrication Points	Lubricant Type
Bearing Retainer (All)	
Oil Seal Lips (All)/O-Rings (All)	
Crank Pins	
Piston Rings, Piston Pins and Pistons	
Kick Idle Gear	
Kick Axle	
Primary Driven Gear (Clutch Housing)	
Push Rod	
Push Lever Axle	
Guide Bar (Shift Forks)	
Crankcase Mating Surfaces	Sealant (Quick Gasket®) Yamaha Bond No. 4
Throttle Cable Ends (Carburetor Switch)	

CHASSIS

Lubrication Points	Lubricant Type
Oil Seal Lips (All)/O-Rings (All)	
Swingarm (Pivot Shaft, Bushe, Bearing)	
Steering Shaft (Upper and Lower Bushes)	
Front Wheel (Pivoting Points)	
Bushes (Front Shock Absorber)	
Pivot Shaft (Front Arm)	
Front Drum Brake Brake Cam Shaft Pivot Pin Backing Plate	
Front Brake Cable Joint	
Front Brake Lever Pivot	
Clutch Lever Pivot	
Throttle Lever Holding Cable End	
Bushes (Rear Shock Absorber)	
Pivot Shaft (Swing Arm)	
Rear Brake Disc Bracket	