



- ① Oil hose
- ② Oil delivery hose
- ③ Ventilation hose
- ④ CDI magneto lead
- ⑤ Clutch cable

- [A] Tighten the oil hose holder with the crankcase cover (Right).
- [B] Position the stopper of the oil hose and oil delivery hose against the autolube pump cover.
- [C] Route the CDI magneto lead through the clamp of the crankcase cover (Left).

