



Tightening Torque:					
Part to be tightened	Thread size	Tightening Torque			Remarks
		Nm	m • kg	ft • lb	
Cylinder Head	M8 x 1.25	27	2.7	20	
Cylinder	M8 x 1.25	25	2.5	18	
Spark Plug	—	25	2.5	18	
Reed Valve Assembly	M6 x 1.0	8	0.8	5.8	
Reed Valve	M3 x 0.5	1	0.1	0.7	
Primary Drive Gear	M12 x 1.25	80	8.0	58	
Clutch Boss	M12 x 1.25	80	8.0	58	
Clutch Spring	M5 x 0.8	6	0.6	4.3	
Clutch Adjuster Locknut	M6 x 1.0	7	0.7	5.1	
Drive Sprocket Stopper	M6 x 1.0	10	1.0	7.2	
Kick Crank	M12 x 1.25	65	6.5	47	
Shift Pedal	M6 x 1.0	14	1.4	10	
Flywheel Magneto	M12 x 1.25	73	7.3	53	
Stator Assembly	M6 x 1.0	8	0.8	5.8	
Exhaust Pipe	M8 x 1.25	21	2.1	15	
Drain Plug (Transmission)	M12 x 1.25	20	2.0	14	
Oil Level Check Bolt	M10 x 1.25	18	1.8	13	
Crankcase Cover (Right)	M6 x 1.0	10	1.0	7.2	
(Left)	M6 x 1.0	10	1.0	7.2	
Autolube Pump Cover	M6 x 1.0	7	0.7	5.1	
Bearing Stopper (Crankshaft)	M8 x 1.25	16	1.6	12	
(Main axle)	M6 x 1.0	10	1.0	7.2	
Crankcase	M6 x 1.0	8	0.8	5.8	
Shift Cam Stopper Lever	M6 x 1.0	14	1.4	10	
Carburetor Switch	—	10	1.0	7.2	
Autolube Pump	M5 x 0.8	5	0.5	3.6	