



STEERING SYSTEM

- | | | |
|----------------------------|--------------------|---------------|
| ① Handlebar cover stay | ⑨ Cable holder | ⑰ Knuckle arm |
| ② Handlebar holder (Upper) | ⑩ Lock washer | ⑱ Washer |
| ③ Handlebar holder (Lower) | ⑪ Steering column | ⑲ Bushing |
| ④ Headlight stay | ⑫ Cotter pin | ⑳ O-ring |
| ⑤ Bearing (Lower) | ⑬ Rod-end | |
| ⑥ Oil seal | ⑭ Locknut | |
| ⑦ Bearing (Upper) | ⑮ Tie-rod | |
| ⑧ Collar | ⑯ Steering knuckle | |

