






**REMOVAL****1. Remove:**

- Protector ① (Handlebar)
- Bands ②

2. Disconnect:

- Fuel breather hose ③ (from handlebar cover ④)

3. Remove:

- Lever holder
- Lever holder

- A** Right
B Left

NOTE:

Place an aligning mark ① next to the separating line ② of the lever holder before removal so that it can be reinstalled in the original position.

4. Remove:

- Handlebar switch ①
- Throttle housing ②

5. Remove:

- Cover ① (Front)