






6. Disconnect:

- Main switch leads ①



7. Remove:


- Cover ① (Handlebar)



8. Remove:


- Stay ① (Handlebar cover)
- Handlebar holders ②
- Handlebar ③

6



9. Remove:

- Headlight lens unit ①



10. Disconnect:

- Headlight leads ①
- Oil level indicator light leads ②