

REMOVAL


1. Remove:

- Front wheel
- Wheel hub
- Brake shoe plate

Refer to the "FRONT WHEEL AND FRONT BRAKE" section.

2. Remove:

- Front bumper




A Upper

B Lower


3. Remove:

- Shock absorber ① (Front)



4. Remove:

- Cotter pin ①
- Nut ②
- Tie-rod ③
(from knuckle arm side)



5. Remove:

- Cotter pins ①
- Bolts ②
- Knuckle arm ③

