

5. Calculate:

•Swingarm side clearance

Out of specification → Adjust side clearance using shim.

By using formula given below.

Side Clearance:

$$= (a) + (b) + (c) - (d) + (e) \times 2$$



Side Clearance:

0.4 ~ 0.7 mm (0.016 ~ 0.028 in)

Example:

a. If the engine mounting boss width (a) , inner collar length (b) and (c) are below.

(a) = 59.68 mm (2.350 in)

(b) = 91.35 mm (3.596 in)

(c) = 69.35 mm (2.730 in)

b. If the pivot width d and washer thickness (e) are below.

(d) = 215.5 mm (8.484 in)

(e) = 2.00 mm (0.079 in)

Side clearance

$$= (59.68 + 91.35 + 69.35)$$

$$(215.5 + 2.00 \times 2) =$$

$$= 0.88 \text{ mm (0.035 in)}$$

Then, install the one shim.

NOTE: _____

When installing the shim on the left side only.



Shim Thickness:

0.3 mm (0.012 in)