



USER MANUAL RAPTRIC ELECTRIC CYCLE

Address: #367, 10T Main, Vidyapeetha Main Road,
Banashankari 3rd Stage, Bengaluru, Karnataka 560085

Email: info.esthira@gmail.com

Ph.No: +91-93802-76355

Website: <https://raptric.in>

I. Introduction

Congratulations on purchasing the eSthira's Raptric electric cycle (eBike). We are happy to welcome you to the family of eSthira.

This user manual is designed to provide you with essential information and guidelines to ensure safe and enjoyable experience of your Raptric eBike.

II. Important Links

Link for [Warranty activation](#)

Link for [Warranty Manual](#)

Link for [Safety Tips](#)

Link for [FAQ](#)

III. Safety Precautions

Before using your Raptric eBike, please read and understand the [safety tips](#):

- Always wear a helmet and follow traffic rules and regulations.
- Ensure proper maintenance of the eBike to prevent mechanical failures.
- Avoid riding on uneven or slippery surfaces.
- Keep children away from the eBike when not in use.

IV. Getting To Know Your Ebike




Fig. 1




Fig. 2



Fig. 3




Fig. 4




Fig. 5



Fig. 6

V. Getting Started

- **Assembly:** The Raptric eBike passes through several quality checks before it is sold to the customer. However, make sure to check if all the parts are in place before you start to ride the eBike.
- **Battery Care:** Charge the battery according to the instructions. Avoid over-discharging or under-charging. Make sure the battery is charged sufficiently before you go for a ride.
- **Initial Ride:** Take your eBike for a test ride in a safe and open area to get familiar with its features and performance.
- **Error Codes:** Watch out for error codes when the display (if available) is switched on. If you find any error code, please refer to the section [1.1](#) and contact Raptric customer care. Do not ride the eBike until you are informed by the customer care representative.
- Refer to our [FAQ](#) page on our website for all other questions that you still might have on the product.

VI. Operational Guidelines

Before starting the eBike, please make the following checks:

- Check if the battery is inserted properly and secured by the lock using the key provided with the eBike (see fig.2)
- Check if both the brakes are holding the eBike properly
- Check for the tire pressure. Recommended is **25 PSI in front** and **30 PSI in the rear** tire.
- Check if the headlight and horn is working properly
- Check if the rear light and brake light (if assembled) are working properly

Starting the eBike

- Switch on the battery button which is shown in fig.4
- Turn the ignition lock ON using the key provided with the eBike
- Long press the power button on the display (if assembled) to turn on the eBike

Braking – It is recommended that you use both the brakes simultaneously for best and safe braking

Riding – Ride safely, maintaining a stable speed and avoiding sudden turns or maneuvers.

Throttle – please use the throttle in a safe manner. Only throttle as much as you need and if you feel safe to control the eBike.

NOTE: Excessive use of throttle will impact the mileage of the eBike.

Pedal Angle Sensor (PAS) mode – the PAS mode on the eBike is set to 1 (by default) when the eBike is switched ON (in case of cycle with display). Switch the PAS levels using the +/- or Up/Down arrow from 1 to 5 levels based on your comfort. In case of no display, check the switch position to know the level of PAS (Low/Medium/High OR 1/2/3).

NOTE: Higher levels of PAS (high/3 in case of models without display & 3 or above in case of models with display) will impact the mileage of the eBike.

Note: In some of the models, setting the PAS level to 0 will result in disabling of both throttle and PAS mode.

Horn – use the horn wisely and follow the traffic rules. Make sure not to honk unnecessarily.

Shifting Gears – In case you have a 6/7 Speed gear assembled on your eBike, use the gear shifter to adjust the gear according to your riding conditions while constantly pedaling. Changing the gears while not pedaling might not shift the gears properly. In case of a 21 Speed gear assembled, use the gear shifter as show in the below image.



Over-Loading – eBike is capable to work as expected for a max load of 100 kgs. Please do not overload beyond this weight. It is strictly recommended not to ride the eBike with more than one person.

Lock – please make sure to carry a lock to secure your eBike when you are going out. Please secure the eBike in the right manner to keep your eBike safe.

VII. Maintenance Tips

1. Regular Cleaning:

- Clean the eBike regularly to maintain its appearance and performance.
- Do not pressure wash any area of the eBike. Just use a moist cloth to wipe all the areas of the eBike.

2. Tire Pressure: Check and maintain the recommended tire pressure for optimal performance and safety. Low tire pressure can lead to frequent puncture and drop in mileage.

3. Battery Maintenance:

- a. Store the battery in a dry place while kept for charging.
- b. Don't leave the battery for overnight charging or don't put for charging without anyone's supervision
- c. Don't use any charger other than the one that is provided along with the eBike
- d. In case the charger is not working as expected, please reach out to the customer care
- e. Put the battery on charge if you hit the red/last level of light on the battery. Using the battery beyond this level will reduce the life-span of the battery
- f. Charge the battery until the charger cuts-off the charging (charging light turns from red to green). Shorter charging cycles (switching off before auto-cutoff) will reduce the life-span of the battery

4. Accident: In case of any accident or if the eBike falls, please get the cycle to the store and get it checked completely before you restart the ride

5. Regular Maintenance: We recommend for a service of your eBike every 3 months to make sure of a smoother ride and performance. Please visit the service center for the same.

6. Nuts and bolts: Due to vibrations, the various nut/bolts of the eBike might get lose. Please tight the nuts and bolts of the eBike on weekly basis.

NOTE:

- In case of any issue or malfunctioning of any part of eBike, do not self-repair as this will void the warranty. Instead, please contact the customer care.
- Don't use any other parts or additional gadgets which is not given from the company, this may void the warranty.
- Do not ride the eBike in deep or stagnant waters. Although the eBike parts are safer to ride in rain, it is not recommended to use during heavy rain as it might lead to motor damage.
- In case the eBike is left in rain without battery, then please wipe the base-plate area with a dry cloth and leave it for natural drying for minimum one hour before inserting the battery and using it. Failing to do so might lead to short-circuit.
- Store the complete eBike in the dry and cool place. Don't expose to direct sunlight or rain which can lead to rusting of parts, or over-heating of the components.

VIII. Features

1. Display

Following information is displayed on the display (see fig 5):

- Battery Level – either in the form of bars or percentage
- Speedometer – in kms
- Pedal Assist Mode level – 0 to 5
- Odometer – in kms
- Error Code
- Trip Info – in kms and in time
- Voltage – in volts

1.1. Error codes

Code (Decimal)	Indication	Note
0	Normal	
1	Reserved	
2	Brake	
3	Power Sensor Error (riding mark)	Not realizable
4	Cruise at 6km/h	
5	Real-time Cruise	
6	Low Battery Voltage	
7	Motor Error	
8	Handlebar Error	
9	Controller Error	
10	Communications Receiving Error	
11	Communications Sending Error	
12	BMS Communications Error	
13	Light Error	

Fig. 7

Note: Please do not try to resolve the error by yourself. If you find any of the above codes on the display, please reach out to the customer care.

Few other variants of displays are below. Information however might be similar.



2. Arrangement of Keys

- Long press the power button to turn on/off.
- Short press the power button to change between the interfaces like odometer, trip, voltage, & time.
- Press the +/- or up/down button to change the PAS mode levels.
- Pressing the -/down button can activate the walk-assist mode
- Press the light push button to switch on/off the headlight/backlight.
- Press the horn push button for honking.
- Long press of the -/below arrow button to switch to walk assist mode

3. Throttle With Ignition Lock

- The throttle is with the ignition lock. Until you turn the ignition to ON position using the key provided with the key, the eBike cannot be turned ON.
- If you hold the throttle steady at any speed for about 5 seconds, the eBike will enter cruise mode. The same will be shown on the display with a "P" symbol or cruise symbol instead of PAS Level. Once in this mode, there is no need to throttle or pedal anymore. The eBike will cruise at the locked speed. To exit, either press brake or throttle. However, use this mode carefully and only on open roads.

4. Electronic Brakes

- The eBike is equipped with digital brakes. So, whenever you brake, the system will cutoff the motor to keep the rider and the motor safe.
- Always use both the brakes simultaneously for best and safe braking performance.

IX. Troubleshooting

- **Common Issues:** Most of the common issues can be rectified by visual inspection. In case you are not able to understand the issue, please drop us a message in whatsapp or call us for our support team for assistance.
- **Error Codes:** Refer to the [error code](#) chart in this manual or contact our support team for assistance.

X. Warranty and Support

Your Raptric eBike is covered under warranty. For any questions, concerns, or assistance, please contact our support team at info.esthira@gmail.com or +91-93802-76355.

The warranty period is as mentioned below

- For Frames – 5 years
- For Battery and Motor – 2 years
- For Electronics components – 6months

Unauthorized Settings Modification – Warranty Disclaimer

- Customers are strictly advised **not to modify or alter any system, controller, or software settings** of the electric cycle.

- **Any change in factory-set parameters will automatically void the warranty**, without prior notice.
- If any malfunction, damage, or performance issue arises due to such unauthorized settings changes, **the responsibility shall solely lie with the customer**.
- In such cases, **all repair, replacement, and service costs will be entirely borne by the customer**, including parts and labour.

XI. Additional Resources

For more information, tips, and updates, visit our website at <https://raptric.in> or follow us on social media.

XII. Disclaimer

eSthira Mobility Pvt Ltd is not responsible for any damages or injuries resulting from misuse or negligent use of the eBike. Ride safely and responsibly.

By following the guidelines and precautions outlined in this manual, you will be able to enjoy a safe and enjoyable riding experience with your eSthira Raptric electric cycle.

We wish you a very happy and joyful experience riding the Raptric eBike. Please do follow us on [Instagram](#) and leave a review on our [Google](#) profile.

Visit our [website](#) for more information.